

SKYFOX AVIATION

CA-25N 25TH HOUR INSPECTION SCHEDULE

CH-25-N

AIRCRAFT REGISTRATION: VH-

DATE : / /

VDO : _____

Air Switch Hours : _____

The following 25TH hour inspection schedule is to assist the maintenance personnel in carrying out a 25TH hour inspection in accordance with the Skyfox maintenance manual. Additional items may be required by the airworthiness authority in the country in which the aircraft is registered. These additional requirements must also be complied with.

It is necessary to also consult data supplied by the manufacturer of components not manufactured by Skyfox Aviation such as engine, propeller, wakes, wheels, nose wheel etc, for additional servicing information. Refer to list of vendor publications in the maintenance manual.

In addition to the requirements listed above, service bulletins and letters issued by the manufacturer of the aircraft, or components fitted to the aircraft must also be complied with.

The following schedule contains a list of tasks to be carried out, and a column for the signatures of both the person carrying out the task and the person coordinating or making the certification for the work. If the person carrying out the work and the person making the certification are the same person, then only one signature is necessary. The person making the certification must be approved or licensed by the appropriate airworthiness authority in the category for which he is making the certification and must record his license or approval number in the space provided at the bottom of each category for which he is signing for.

The inspection required by this schedule shall be a thorough functional and visual check of the nominated system, component, assembly and/or installation. The inspection should be conducted making extensive use of inspection panels, removable items, using adequate lighting and, where necessary, inspection aids such as mirrors and torches. Surface cleaning of individual components may also be required. The condition of the nominated system, component, assembly and or installation when so inspected shall be such as to maintain the continued airworthiness of the aircraft.

SKYFOX AIRCRAFT RECOMMENDED FLUIDS (NOV 97)

ENGINE Oil.----- CASTROL. GRAND PRIX

High Performance 4 Stroke Motorcycle Engine Oil
SAE 15W-50 API SG CD 3 Litres
Maintain oil level on Hat of dipstick (approx 500ml)

COOLANT----- LOCTITE ALL SEASONS RADIATOR CARE

Just under 3 Litres.
Maintain coolant level approx half-full on plastic expansion tank.
100% for aircraft pre CA25N073 (June 1997).
80% for others with 20% water, but as placarded.

BRAKE FLUID----- AEROSHELL FLUID 41

MIL-11-56061
Maintain master cylinders half full.

GREASE----- CASTROL HIGH TEMPERATURE BEARING (HTB) GREASE

Apply IAW Maintenance & Repair Manual.

FUEL----- UNLEADED MOGAS Preferred

LEADED MOGAS Second Preference
100LL AVGAS Third Preference

SKYFOX AVIATION

CA-25N

Gazelle

MAINTENANCE

&

REPAIR MANUAL

INDEX TO CHAPTERS

CHAPTER	4	AIRWORTHINESS LIMITATIONS
CHAPTER	5	TIME LIMITS/MAINTENANCE CHECKS
CHAPTER	6	DIMENSIONS AND AREAS
CHAPTER	7	LIFTING AND SHORING
CHAPTER	8	LEVELLING AND WEIGHING
CHAPTER	9	TOWING AND TAXIING
CHAPTER	10	PARKING AND MOORING
CHAPTER	11	REQUIRED PLACARDS
CHAPTER	12	SERVICING
CHAPTER	20	STANDARD PRACTICES / AIRFRAME
CHAPTER	21	ENVIRONMENTAL SYSTEMS
CHAPTER	23	COMMUNICATIONS
CHAPTER	24	ELECTRICAL POWER
CHAPTER	25	EQUIPMENT FURNISHINGS
CHAPTER	27	FLIGHT CONTROLS
CHAPTER	28	AIRCRAFT FUEL SYSTEM
CHAPTER	32	LANDING GEAR
CHAPTER	33	LIGHTS
CHAPTER	34	NAVIGATION AND PITOT STATIC
CHAPTER	39	ELECTRICAL
CHAPTER	51	STRUCTURES GENERAL
CHAPTER	52	DOORS
CHAPTER	55	STABILIZERS
CHAPTER	56	WINDOWS
CHAPTER	57	WINGS
CHAPTER	61	PROPELLER
CHAPTER	71	POWERPLANT
CHAPTER	73	ENGINE FUEL SYSTEM
CHAPTER	74	IGNITION
CHAPTER	76	ENGINE CONTROLS
CHAPTER	77	ENGINE INDICATING
CHAPTER	79	OIL SYSTEM
CHAPTER	80	STARTING
CHAPTER	91	CHARTS & WIRING

RECORD OF REVISIONS

Any revision of the present manual, except actual weighing data, must be recorded in the following table and in case of approved sections endorsed by the responsible airworthiness authority.

The new or amended text in the revised pages will be indicated by a black vertical line in the left hand margin, and the Revision No. and the date will be shown on the bottom left hand side of the page.

Rev. No	Affected Chapter	Affected Page	Effectivity Date	Date Inserted	Signature

RECORD OF REVISIONS (Cont)

Rev. No	Affected Chapter	Affected Page	Effectivity Date	Date Inserted	Signature

CHAPTER 4

AIRWORTHINESS LIMITATIONS

Skyfox Aviation

MAINTENANCE MANUAL CA-25N GAZELLE

CASA APPROVED

CHAPTER 4: AIRWORTHINESS LIMITATIONS

TABLE OF CONTENTS

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
4-00-00	AIRWORTHINESS LIMITATIONS	4-3	01 MAR 1996

Skyfox Aviation

MAINTENANCE MANUAL CA-25N GAZELLE

CASA APPROVED

4-00-00 AIRWORTHINESS LIMITATIONS

The airworthiness limitations are CASA approved and specify inspections and maintenance required under Paragraph 1529 of the Joint Aviation Requirements for Very Light Aeroplanes.

The following limitations related to the fatigue life of the aircraft and its components with respect to the CA-25N are interim estimates only and are currently under review.

MANDATORY RETIREMENTS

ITEM	COMPONENT	MAXIMUM TIME IN SERVICE
1	WING FRONT SPARS Part No's WI-8L & WI-8R	4,000 HRS
2	WING REAR SPARS Part No's WI-9L & WI-9R	4,000 HRS
3	WING LIFT STRUTS AND CARRY THROUGH STRUCTURES	4,000 HRS
4	HORIZONTAL STABILIZER SPAR Part No TP-1-9	8,000 HRS
5	ALL OTHER PRIMARY STRUCTURE	8,000 HRS

- NOTE 1 -

REFER TO THE LIMITATIONS IN THE CASA APPROVED FLIGHT MANUAL FOR DETAILED DELINEATION OF THE FLIGHT LIMITATIONS OF THE AIRCRAFT.

-NOTE 2-

REFER TO AIRCRAFT LOG BOOK FOR ENGINE TBO AND OTHER LIFED COMPONENTS AS EACH AIRCRAFT MAY DIFFER.

CHAPTER 5

TIME LIMITS/MAINTENANCE CHECKS

CHAPTER 5 TIME LIMITS/MAINTENANCE CHECKS

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
5.00.00	GENERAL	5-3	10 MAY 1995
5.10.00	TIME LIMITS	5-3	10 MAY 1995
5.10.01	INSPECTION REQUIREMENTS	5-3	05 MAR 1997
5.10.02	PREFLIGHT CHECKS	5-3	10 MAY 1995
5.10.03	OVERLIMITS INSPECTION	5-3	10 MAY 1995
5.10.04	SERVICE LIFE LIMITS	5-4	10 MAY 1995
5.20.00	SCHEDULED MAINTENANCE	5-4	10 MAY 1995
5.20.01	PERIODIC INSPECTIONS	5-4	10 MAY 1995
5.20.01	PERIODIC INSPECTIONS (Cont)	5-5/6	05 MAR 1997
5.20.01	PERIODIC INSPECTIONS (Cont)	5-7/8	05 MAR 1997
5.20.01	PERIODIC INSPECTIONS (Cont)	5-9/10	05 MAR 1997
5.20.02	CONTINUOUS INSPECTIONS	5-11	10 MAY 1995
5.50.00	UNSCHEDULED MAINTENANCE	5-11	10 MAY 1995
5.50.01	SPECIAL INSPECTIONS AS REQUIRED UPON CONDITION	5-11	05 MAR 1997

5-00-00 GENERAL

This chapter provides instructions for conducting inspections. Repair or replacement instructions for those components found to be unserviceable at inspection may be found in the section covering the applicable aircraft system.

NOTE: THE ROTAX OPERATOR'S MANUAL IS THE SOLE REFERENCE FOR THE MAINTENANCE OF THE ROTAX 912 ENGINE FITTED TO THE CA-25N

-CAUTION-

WHEN WORKING ON ENGINE, GROUND THE IGNITION PRIMARY CIRCUITS BEFORE PERFORMING ANY PRIMARY OPERATIONS.

5-10-00 TIME LIMITS

The time limits are specified in Chapter 4.

5-10-01 INSPECTION REQUIREMENTS.

Required inspection procedures are listed in inspection report. The inspection procedure is broken down into eight major groups which are propeller, engine, cabin, fuselage and empennage, wing, landing gear, operational inspection and general. The first column in each group lists the inspection or procedure to be performed. The second column is divided into five columns indicating the required inspection intervals of 100 hours, 200 [hours, 1200 hours, annual and bi-annual. Each inspection or operation is required at each of the inspection intervals as indicated by a circle (O). When performing inspections, use forms furnished by Skyfox Aviation service department available through Skyfox dealers and distributors.

-NOTE-

IN ADDITION TO INSPECTION INTERVALS REQUIRED IN INSPECTION REPORT, PREFLIGHT INSPECTIONS MUST BE PERFORMED.

5-10-02 PREFLIGHT CHECKS.

This check is for the pilot and/or mechanic and should become part of the aircraft operational routine and/or preflight check before each flight. Refer to section 4 of the flight manual for a listing of items that must be checked.

5-10-03 OVERLIMITS INSPECTIONS.

If the aircraft has been operated so that any of its components have exceeded their maximum operational limits, check with the appropriate manufacturer.

5-10-04 SERVICE LIFE LIMITS

For mandatory retirement life of the aircraft and its components, refer to Chapter 4 of this manual.

5-20-00 SCHEDULED MAINTENANCE

The scheduled of maintenance for the CA-25N "Gazelle" is laid down in this manual in accordance with CAR Schedule 5.

5-20-01 PERIODIC INSPECTIONS**- NOTE -**

Perform all inspections or operations at each of the inspection intervals as indicated by a circle (O).

For clarity of reading, all items marked with (O), are intended to have included with them, the items from the earlier time limit.

With the items that are called up by calendar times, the calendar period starts from the date of the last operation.

The service time (in hours) overrides the calendar time and visa versa, depending on which occurs first.

A 25th Hour Inspection Schedule "check list" is available from Skyfox Aviation. Part Number CH-25-N. (Included with Logbook)

A 100 Hour Inspection. Schedule "check list" is available from Skyfox Aviation. Part Number CH-100-N. (See Chapter 91)

The order laid down in this Check List has been prepared to enable a logical and time efficient process for carrying out the 100 hour check.

NOTE: IN ADDITION TO THE FOLLOWING CHECKS, THERE ARE SOME ADDITIONAL ITEMS TO BE CARRIED OUT AT THE 600 HOUR CHECK.

(SEE SECTION 6.7 IN THE ROTAX OPERATORS MANUAL.)

NOTE: AT VARIOUS TIMES, THE ROTAX SERVICE DEPARTMENT ISSUE TECHNICAL BULLETINS. CHECK WITH YOUR LOCAL ROTAX AGENT FOR THE LATEST ISSUES.

To gain access to all parts of the aircraft, remove:-

Engine Cowls.

Seat.

Centre Console.

Either Elevator Inspection Panel.

Wing Tips to access strobes.

A clearer view of the aft fuselage may be established, by removing the baggage compartment bag.

NATURE OF INSPECTION	100	200	1200	2	3
	HR	HR	HR	YR	YR
A. PROPELLER GROUP					
1. INSPECT SPINNER AND BACKPLATE.	O				
2. INSPECT BLADES FOR NICKS AND CRACKS.	O				
3. INSPECT PROPELLER MOUNTING BOLTS AND SAFETY WIRE. CHECK TORQUE IF SAFETY WIRE IS BROKEN. Refer AD107/PFP/1.	O				
4. INSPECT COMPLETE PROP AND SPINNER ASSEMBLY FOR SECURITY, CHAFING, CRACKS, DETERIORATION, WEAR AND CORRECT INSTALLATION.	O				
B. ENGINE GROUP					
CAUTION: GROUP IGNITION PRIMARY CIRCUITS BEFORE WORKING ON ENGINE					
1. REMOVE ENGINE COWL AND INSPECT FOR DAMAGE.	O				
2. CLEAN AND INSPECT COWL FOR CRACKS, DISTORTION, AND LOOSE OR MISSING FASTENERS.	O				
3. DRAIN OIL TANK.	O				
4. CLEAN OIL STRAINER AT OIL CHANGE, (INSPECT STRAINER FOR FOREIGN PARTICLES).			O		
5. CHANGE OIL FILTER.	O				
6. INSPECT OIL TEMPERATURE SENDER UNIT FOR LEAKS AND SECURITY.	O				
7. INSPECT OIL LINES AND FITTINGS FOR LEAKS, SECURITY, CHAFING, DENTS AND CRACKS.CHECK MAGNETIC PLUG (GEARBOX)	O				
8. CLEAN AND INSPECT OIL COOLER.	O				
9. FILL ENGINE WITH OIL PER LUBRICATION CHART IN CHAPTER 12.	O				
10. REPLACE ENGINE COOLANT.			O	O	
11. INSPECT COOLANT HOSES, EXPANSION TANK CAP FOR LEAKS, SECURITY, CHAFING DENTS AND CRACKS.	O				
12. CLEAN AND INSPECT COOLANT RADIATOR.			O		

NATURE OF INSPECTION	100 HR	200 HR	1200 HR	2 YR	3 YR
B. ENGINE GROUP (cont')					
13. INSPECT COOLANT TEMPERATURE SENDER UNIT FOR LEAKS AND SECURITY.	O				
14. CLEAN ENGINE.	O				
15. OPERATE ENGINE UP TO NORMAL OPERATING TEMPERATURES, INSPECT FOR OIL AND COOLANT LEAKS AFTER SHUTDOWN.	O				
16. INSPECT CONDITION OF SPARK PLUGS, ADJUST GAP AS REQUIRED. (Refer engine operators manual.)	O				
17. REPLACE SPARK PLUGS.		O			
18. CHECK CYLINDER COMPRESSION. (Refer Chapter 7.4 of engine operators manual.)	O				
19. INSPECT CYLINDERS FOR CRACKS OR BROKEN FINS..	O				
20. INSPECT TAPPET COVERS FOR OIL LEAKS. IF FOUND, REPLACE GASKET.	O				
21. INSPECT IGNITION HARNESS FOR DAMAGE AND SECURITY.	O				
22. REMOVE AIR FILTER, CLEAN AND INSPECT FOR DETERIORATION AND RE-OIL PER LUBRICATION CHART IN CHAPTER 12 OR REPLACE.	O				
23. INSPECT CONDITION OF CARB HEAT AIR DOOR AND BOX.	O				
24. INSPECT CONDITION OF AIR INTAKE SEALS	O				
25. REMOVE ALL CLAMPS ON DUCT HOSES AND INSPECT INTERNALLY AND EXTERNALLY (replace if required)	O				
26. INSPECT CONDITION OF FLEXIBLE FUEL LINES.	O				
27. INSPECT FUEL SYSTEM FOR LEAKS.	O				
28. CLEAN FILTER SCREEN IN GASCOLATOR. CHECK OPERATION OF ENGINE DRIVEN AND ELECTRIC FUEL PUMPS.	O				
29. INSPECT THROTTLE, CARB HEAT AND CHOKE CONTROLS FOR TRAVEL AND OPERATION.	O				
30. INSPECT SECURITY OF CARBURETTOR THROTTLE ARMS.	O				

NATURE OF INSPECTION	100	200	1200	2	3
	HR	HR	HR	YR	YR
B. ENGINE GROUP (cont')					
31. INSPECT EXHAUST PIPES, CONNECTIONS AND GASKETS. (Replace gaskets as required.)	O				
32. INSPECT MUFFLER, HEAT EXCHANGERS AND BAFFLES.	O				
33. INSPECT BREATHER TUBE FOR OBSTRUCTIONS AND SECURITY.	O				
34. INSPECT ENGINE CRANK CASE FOR CRACKS, LEAKS AND SECURITY OF SEAM BOLTS.	O				
35. INSPECT ENGINE MOUNTS FOR CRACKS, SECURITY AND CONDITION.	O				
36. INSPECT ALL ENGINE BAFFLES.	O				
37. INSPECT ALL WIRING CONNECTED TO THE ENGINE OR ACCESSORIES.	O				
38. INSPECT ENGINE MOUNT BUSHINGS FOR DETERIORATION. REPLACE AS REQUIRED.	O				
39. INSPECT FIREWALL SEALS.	O				
40. INSPECT CONDITION OF ALTERNATOR AND STARTER.	O				
41. LUBRICATE ALL CONTROLS. (Refer chapter 12.)	O				
42. COMPLETE OVERHAUL OF ENGINE OR REPLACE WITH FACTORY REBUILT.			O		
43. CHECK CARBURETTOR FLOAT BOWLS	O				
44. INSPECT CARB. NEEDLE VALVE CIRCLIP FOR MOVEMENT	O				
45. RE-INSTALL ENGINE COWL.	O				
C. CABIN GROUP					
1. INSPECT CABIN ENTRANCE, DOORS AND WINDOWS FOR DAMAGE AND OPERATION.	O				
2. INSPECT UPHOLSTERY FOR TEARS.	O				
3. INSPECT SEATS, SEAT BELTS FOR SECURITY OF BRACKETS AND BOLTS.	O				
4. INSPECT ELEVATOR TRIM OPERATION.	O				
5. INSPECT RUDDER PEDALS FOR PROPER OPERATION.	O				
6. INSPECT BRAKE PEDALS FOR PROPER OPERATION AND LEAKS.	O				
7. CHECK FLUID LEVEL IN BRAKE RESERVOIRS (Fill as required.)(Refer chapter 12)	O				
8. INSPECT CONTROL COLUMN, PUSHRODS, ROD ENDS AND BELLCRANKS FOR PROPER OPERATION.	O				

NATURE OF INSPECTION	100	200	1200	2	3
	HR	HR	HR	YR	YR
C. CABIN GROUP (cont')					
9. CHECK LANDING AND NAVIGATION LIGHTS FOR CORRECT OPERATION.	0				
10. INSPECT INSTRUMENTS, LINES AND ATTACHMENTS.	0				
11. INSPECT GYRO OPERATED INSTRUMENTS. OVERHAUL OR REPLACE AS NECESSARY.	0				
12. CHECK ALTIMETER. CALIBRATE ALTIMETER IN ACCORDANCE WITH CHAPTER 34 OF THIS MANUAL.(If Required)		0			
13. CHECK OPERATION OF FUEL COCK.	0				
14. INSPECT CONDITION OF HEATER CONTROLS AND DUCTS.	0				
15. INSPECT CONDITION AND OPERATION OF AIR VENTS.	0				
D. FUSELAGE AND EMPENNAGE GROUP					
1. REMOVE INSPECTION PANELS.	0				
2. INSPECT ELECTRONIC INSTALLATIONS.	0				
3. INSPECT TUBULAR STRUCTURE AND WOODEN STRINGERS FOR DAMAGE.	0				
4. INSPECT ANTENNAE MOUNTS AND ELECTRICAL WIRING.	0				
5. INSPECT FUEL LINES, VALVES AND COLLECTOR TANK FOR OPERATION AND DAMAGE.	0				
6. CHECK SECURITY OF ALL LINES.	0				
7. INSPECT VERTICAL FIN AND RUDDER FOR DAMAGE.	0				
8. INSPECT RUDDER HINGES, HORN AND ATTACHMENTS FOR DAMAGE AND OPERATION.	0				
9. INSPECT REAR FIN SPAR.	0				
10. INSPECT RUDDER HINGE PINS AND BUSHES FOR EXCESS WEAR. REPLACE AS REQUIRED.	0				
11. INSPECT ELEVATOR AND STABILIZER SURFACES FOR DAMAGE.	0				
12. INSPECT ELEVATOR HORN AND ATTACHMENTS FOR DAMAGE AND OPERATION.	0				
13. INSPECT ELEVATOR HINGE PINS AND BUSHES FOR EXCESS WEAR. REPLACE AS REQUIRED.	0				
14. INSPECT ELEVATOR TRIM MECHANISM.	0				
15. INSPECT STROBE AND LANDING LIGHTS FOR SECURITY AND OPERATION.	0				

NATURE OF INSPECTION	100 HR	200 HR	1200 HR	2 YR	3 YR
D. FUSELAGE AND EMPENNAGE GROUP (cont')					
16. INSPECT AILERON, ELEVATOR, RUDDER, TRIM CORDS, TURNBUCKLES, FAIRLEADS, PUSHRODS, RODENDS AND BELLCRANKS FOR SAFETY, DAMAGE AND	0				
17. LUBRICATE PER LUBE CHART JN CHAPTER 34.	0				
18. RE-OIL FUSELAGE TUBES.				0	
19. REPLACE BATTERY. RE-INSTALL INSPECTION PLATES AND PANELS.				0	
E. WING GROUP.					
1. INSPECT WING SURFACES AND TIPS FOR DAMAGE.	0				
2. INSPECT AILERON HINGES AND ATTACHMENTS.	0				
3. INSPECT AILERON PUSHRODS AND BELLCRANKS FOR DAMAGE AND OPERATION.	0				
4. LUBRICATE PER LUBRICATION CHART IN CHAPTER 12.	0				
5. VISUALLY INSPECT WING ATTACHMENT BOLTS AND FITTINGS FOR ANY INDICATION OF MOVEMENT BETWEEN NUTS AND BOLTS.	0				
6. VISUALLY INSPECT MAIN SPAR REINFORCING TABS FOR DAMAGE AND SECURITY.	0				
7. INSPECT FUEL TANKS, LINES, FITTINGS AND CAPS FOR LEAKS AND WATER.	0				
8. CHECK FUEL TANKS MARKED FOR CAPACITY AND FUEL GRADE.	0				
9. INSPECT FUEL TANK VENTS FOR BLOCKAGE.	0				
10. INSPECT ALL ELECTRICAL LEADS, LINES AND ATTACHING PARTS FOR SECURITY, ROUTING, CHAFING, DETERIORATIONS, WEAR AND CORRECT INSTALLATION.	0				
F. LANDING GEAR GROUP.					
1. INSPECT TYRES FOR CUTS, UNEVEN OR EXCESSIVE WEAR.	0				
2. REMOVE, CLEAN AND INSPECT WHEELS CLEAN, INSPECT AND REPACK BEARINGS.	0				
3. CHECK TYRE PRESSURE PER CHAPTER 6.	0				
4. INSPECT BRAKE LINING AND DISC FOR CONDITION AND WEAR.	0				
5. INSPECT BRAKE HYDRAULIC LINES.	0				

NATURE OF INSPECTION	100	200	1200	2	3
	HR	HR	HR	YR	YR
F. LANDING GEAR GROUP (cont')					
6. INSPECT MAIN GEAR LEGS, ATTACHMENTS AND BOLTS FOR CONDITION AND SECURITY.	0				
7. INSPECT RUBBER IN SHEAR STRUTS FOR DETERIORATION, CHAFING AND SECURITY.	0				
8. CHECK MAIN WHEELS FOR ALIGNMENT.	0				
9. CHECK NOSE OLEO EXTENSION IS NOT LESS THAN 50mm.	0				
10. INSPECT NOSE WHEEL SPRINGS FOR SECURITY, DAMAGE, CRACKS AND DEFORMATION CHECK STEERING.	0				
11. INSPECT WHEEL SPATS FOR SECURITY, DAMAGE, CRACKS & DEFORMATION	0				
12. LUBRICATE PER LUBRICATION CHART IN CHAPTER 12.	0				
H OPERATIONAL INSPECTION					
1. CHECK FUEL PUMP FOR OPERATION	0				
2. CHECK FUEL QUANTITY INDICATORS.		0			
3. CHECK FUEL PRESSURE WARNING LIGHT.	0				
4. CHECK OIL PRESSURE AND TEMPERATURE.	0				
5. CHECK ALTERNATOR OUTPUT/WARNING LIGHT	0				
6. CHECK CARBURETTOR HEAT.	0				
7. CALIBRATE COMPASS.(EVERY 3YRS)					0
8. CHECK GYRO'S FOR NOISE AND ROUGHNESS.	0				
9. CHECK CABIN HEATER OPERATION.	0				
10. CHECK IGNITION SWITCH OPERATION.	0				
11. CHECK IGNITION RPM VARIATION.	0				
12. CHECK THROTTLE AND CHOKE OPERATION.	0				
13. CHECK ENGINE IDLE.	0				
14. CHECK ELECTRONIC EQUIPMENT OPERATION.	0				
I GENERAL.					
1. AIRCRAFT CONFORMS TO CASA SPECIFICATIONS.				0	
2. ALL APPLICABLE AIRWORTHINESS DIRECTIVES FOR THE AIRCRAFT TYPE COMPLIED WITH.	0				
3. ALL MANUFACTURERS SERVICE BULLETINS AND LETTERS COMPLIED WITH.	0				
4. CHECK FOR PROPER, APPROVED FLIGHT MANUAL.	0				
5. AIRCRAFT LOGBOOKS, RECORDS AND MAINTENANCE RELEASE ARE CURRENT.	0				

5-20-02 CONTINUOUS INSPECTIONS

The continuous inspection was designed to permit the best utilization of the aircraft by scheduling inspections through the use of a planned inspection schedule.

5-50-00 UNSCHEDULED MAINTENANCE CHECKS

The items in this section do not occur at regular intervals of flight time or calendar times.

5-50-01 SPECIAL INSPECTIONS ARE REQUIRED UPON CONDITION

The special inspections given supplement the scheduled inspections as outlined in the report to include inspections which are required at intervals not compatible with airframe operating time or inspection intervals. Typical of this type are:

1. Inspections required because of special conditions or incidents, an immediate inspection would be required to ensure further safe flight.
2. Hard or overweight landing. This inspection should be performed after a known rough landing is made or when a landing is made while the aircraft is known to exceed the design landing weight.

Check the following areas and items:

- ❖ Wings for wrinkled fabric, loosened bonding joints, broken stringers.
 - ❖ Fuel leaks around the fuel tanks.
 - ❖ Wing spars, bulkheads, wing and fuselage stringers and fabric for any signs of over stress or damage.
 - ❖ A possible alignment check to clarify any doubt of damage.
3. Severe turbulence inspection. The same items and locations as stated for hard or overweight landings along with the following:
 - ❖ Top and bottom fuselage for loose or wrinkled fabric.
 - ❖ Empennage fabric and attachments.
 4. Engine overspeed, sudden stoppage, loss of oil, over temperature and lightning strike.
 - ❖ Check with the engine manufacturer for necessary corrective action.

CHAPTER 6

DIMENSIONS AND AREAS

CHAPTER 6 DIMENSIONS AND AREAS**TABLE OF CONTENTS/EFFECTIVITY**

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
6-10-00	DIMENSIONS	6-3	10 MAY 1995
6-20-00	STATION REFERENCE LINES	6-7	10 MAY 1995
6-30-00	ACCESS AND INSPECTION PROVISIONS	6-7	10 MAY 1995

DIMENSIONS

The principal aircraft dimensions are shown in Figure 601 and are listed in Chart

CHART 601 LEADING PARTICULARS AND PRINCIPAL DIMENSIONS	
MODEL	CA25N GAZELLE
ENGINE	
MANUFACTURER	BOMBARDIER/ROTAX
MODEL	912A
RATED HP AT PROPELLER RPM	80
OIL TANK CAPACITY	2.5 LITRES
FUEL GRADE	PREMIUM GRADE GASOLINE TO DIN 51600,-NORM C EURO-SUPER RON 95, UNLEADED MIN RON 90, OR AVGAS 100LL
IGNITION	ROTAX DUAL IGNITION - BREAKERLESS CAPACITOR DISCHARGE, WITH INTERFERENCE SUPPRESSION.
ELECTRODE GAP	0.5mm (0.02 inch)
FIRING ORDER	1-4-2-3
STARTER	12V/0.6kW, ENGAGEMENT VIA GEAR REDUCTION AND OVERRUNNING CLUTCH.
GENERATOR	DUCATI, PERMANENTLY EXCITED SINGLE PHASE AC- GENERATOR WITH RECTIFIER REGULATOR
PROPELLER	
MANUFACTURER	ALLSIZE AVIATION
TYPE	FIXED PITCH, WOODEN
MODEL	CHP-1
DIAMETER	1727mm (68 inches)
DIAMETER MINIMUM	1727mm (68 inches)
FUEL SYSTEM	
LEFT WING TANK	26 LITRES
RIGHT WING TANK	26 LITRES
COLLECTOR TANK	3.75 LITRES
TOTAL	55.75 LITRES
LANDING GEAR	
TYPE	TRICYCLE
TRACK	1.90m (75.0 inches)
WHEEL BASE	1.45m (57.1 inches)
NOSE WHEEL TYPE	WELDED STEEL TUBE / RUBBER DISC OLEO
MAIN GEAR TYPE	WELDED TUBE STRUCTURE WITH
MAIN WHEEL TYRE	137Kpa (20 psi)
NOSE WHEEL TYRE	206Kpa (30 psi)
TYRE MAIN	CHENG SHIN / DELI 15 x 6.00 - 6
TYRE NOSE	CHENG SHIN / DELI 13 x 5.00 - 6
BRAKES	MATCO 5BA, MC13, HYDRAULIC DISC BRAKES

Skyfox Aviation

MAINTENANCE MANUAL

CA-25N APPROVED

SPECIFICATIONS AND PERFORMANCE FOR CA25N GAZELLE

SPECIFICATIONS:

Wing Span	9.52 mts	31' 3"
Wing Area	11.6 sq mt	124.6 sq ft
Chord Length	1.01 mts	3' 6"
Chord Length (Including Ailerons)	1.29 mts	4' 3"
Aspect Ratio	7.5	
Length	5.6 mts	18' 4 1/2"
Length (Wings Folded)	6.57 mts	21' 6 1/2"
Width (Wings Folded)	2.40 mts	7' 10 1/2"
Height	2.45 mts	8' 1/2"
Tread Width (Mains)	1.90 mts	6' 3"
Wheel Base (Mains to Nosewheel)	1.45 mts	4' 9"
Tyres Size, Main	15" x 6"	
Tyres Size, Nose	13" x 6"	
Empty Weight	330 kg	730lbs
Gross Weight	520 kg	1150 lbs
Fuel Capacity (Useable)	48 lts	10.6 gal
Cabin Maximum Width	1.02 mts	3' 4"
Pilot Maximum Height	195 cm	6' 5"

ROTAX ENGINE

Powerplant	4 Stroke ROTAX 912A
Maximum Horsepower	80 @ 5800 rpm
Propeller	68 x 48 inch, 2 bleade, wooden

PERFORMANCE	Take Off Weight	520 kg
Top Speed (Sea Level)	85 kts	157 km/hr
Cruise Speed (75% at 5000 rpm)	75 kts	139 km/hr
Cruise Speed (70% at 4800 rpm)	70 kts	130 km/hr
Fuel Flow (70% power)	13.5 lts/hr	
Never Exceed Speed	93 kts	172 km/hr
Stall Speed	44.5 kts	82 km/hr
Rate of Climb (Sea Level)	657 fpm	
Range at 70% 13.5 lts/hr	250 NM	460 km
Best Rate of Climb Speed	55 kts	102 km/hr
Best Angle of Climb Speed	50 kts	93 km/hr
Service Ceiling	10000 ft	
Take-off / Landing Ground Roll	340 ft	100 mtrs
Maximum Direct Crosswind Component	20 kts	37 km/hr

(Airspeed in KIAS)

AMENDMENT 2: 05 MAR 1997

THREE VIEW DIAGRAM




Figure 601

6-20-00 STATION REFERENCE LINES

NOTE: Arm from datum (Wing Leading Edge)

Fuel	+ 379	mm
Oil	- 410	mm
Coolant	- 750	mm
Occupants	+ 396	mm
Baggage	+ 1650	mm

All Skyfox series aeroplanes use the wing leading edge as a preference datum. This datum is measured with the aircraft in the level position as shown for levelling and weighing in Section 8 of this manual, and a plumb bob hung down from the leading edge at the root of either wing. The horizontal point indicated by the plumb bob is station zero. All points aft of station zero are positive and all points forward of station zero are negative.

6-30-00 ACCESS AND INSPECTION PROVISIONS

The Gazelle access and inspection provisions are unique, as after removal of the upper and lower engine cowlings, complete access to the engine and instrument panel is available.

With the removal of the seat and centre console access is available to all flight controls and electrical installations.

An inspection panel, one either side of the fin under the stabiliser, gives access to the elevator horn and tail skid attachments.

The removal of wing tips gives access to strobe fittings.

-END-

CHAPTER 7

LIFTING AND SHORING

Skyfox Aviation

MAINTENANCE MANUAL

CA-25N GAZELLE

CHAPTER 7 LIFTING AND SHORING

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
7-10-01	JACKING	7-3	10 MAY 1995

7-10-01 JACKING

There are no jacking points as such fitted to the aircraft, however if the aircraft must be lifted up off all three wheels simultaneously then the following method is recommended:-

Support fuselage under wing strut attachment points on fuselage -and hold the tail down by attaching a heavy weight (50Kg) to the fuselage hard point above tail skid mount via chain or attach to the ground.

OR

Place timber across the fuselage just behind the nose leg struts together with the wing strut attachment points on fuselage.

NOTE: If engine is removed while in this position, the tail must be supported to prevent it from falling.

Aircraft may also be jacked by individual points under each main undercarriage leg where wheel axles are mounted.

NOTE: A suitable jacking pad must be used to ensure no damage to undercarriage components.

CHAPTER 8

LEVELLING AND WEIGHING

Skyfox Aviation

MAINTENANCE MANUAL

CA-25N GAZELLE

CHAPTER 8 LEVELLING AND WEIGHING

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
8-10-01	LEVELLING AND WEIGHING	8-3	10 MAY 1995
8-10-02	SAMPLE WEIGHT & BALANCE	8-4	10 MAY 1995

8-10-01 LEVELLING AND WEIGHING

The empty weight includes unusable fuel, undrainable oil and undrainable coolant. The aircraft must be drained of oil, coolant and fuel before weighing or if this is inconvenient, it may be weighed with full oil and full coolant but must be drained of fuel. The oil and coolant should then be subtracted from the empty weight and the C of G adjusted accordingly. To weigh aircraft, place all three wheels on load cells, (see fig 801), place spirit level from one fuselage door sill to the other and level by inflating or deflating main wheel tyres, then place spirit level along one fuselage door and deflate or inflate nose wheel. Record the weights from each load cell and repeat procedure. Refer fig 802.




Figure 801




Figure 802

When two readings are obtained where the total weights are within 0.5kg then the empty weight and C of G may be calculated as follows.

8-10-02 SAMPLE WEIGHT & BALANCE**EXAMPLE ONLY**

A/C Reg No: VH-XAB

Serial No: CA25003

		FIRST WEIGHING		SECOND WEIGHING	
LEFT MAIN		127.8		127.9	
RIGHT MAIN		127.2		127.4	
NOSE WHEEL		76.7		76.2	
TOTAL		331.6		331.5	
AVERAGE BOTH WEIGHINGS		331.6			
<u>DEDUCTION</u>					
ITEM	QTY	KG/L		KG	
OIL	2.5	0.9		2.25	
COOLANT	2.5	1.1		2.75	
OTHER TOTAL DEDUCTIONS				5.00	
<u>ADDITIONS</u>					
ITEM	QTY	KG/L		KG	
UN-USABLE FUEL	4.0	0.74		3.00	
OTHER TOTAL ADDITIONS		0.74		3.00	
AIRCRAFT EMPTY WEIGHT				329.60	
DATUM TO WEIGHING POINT		1	2	3	
DISTANCE IN mm		563	563	-912	
AVERAGE WEIGHT		127.85	127.3	76.45	
		WEIGHT IN Kg		MOMENT	
ITEM		+	-	+/-	+ -
LEFT MAIN		127.85	XXXXXX	563	71979.55
RIGHT		127.30	XXXXXX	563	71669.90
NOSE		76.45	XXXXXX	-912	-69722.40
<u>DEDUCTIONS</u>					
OIL		XXXXXX	-2.25	-410	922.5
COOLANT		XXXXXX	-2.75	-750	2062.5
OTHER		XXXXXX			
<u>ADDITIONS</u>					
UN-USABLE FUEL		3.0	XXXXXX	549	1647.0
OTHER			XXXXXX		
EMPTY WEIGHT		TOTAL INDEX UNITS		76912.05	
		TOTAL EMPTY ARM		233.35	
		EMPTY WEIGHT		329.60	
FULL OIL		2.25	XXXXXX	-410.0	-922.5
FULL COOLANT		2.75	XXXXXX	-750.0	-2062.5
BASIC WEIGHT		TOTAL INDEX UNITS		73927.05	
		TOTAL BASIC ARM		222.94	
		TOTAL BASIC WEIGHT IN Kg		331.60	

The basic weight includes 2.25kg oil at -410mm, 2.75Kg coolant at -750mm.

NOTE: Arm from datum (Wing Leading Edge)

Fuel + 379 mm
Oil - 410 mm
Coolant - 750 mm
Occupants + 396 mm
Baggage + 1650 mm

CHAPTER 9

TOWING AND TAXIING

Skyfox Aviation

MAINTENANCE MANUAL

CA-25N GAZELLE

CHAPTER 9 TOWING AND TAXIING

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	EFFECTIVITY
9-10-01	TOWING	10 MAY 1995
9-20-01	TAXIING	10 MAY 1995
9-30-01	WING FOLDING	05 MAR 1997

9-10-01 TOWING

It is recommended to obtain a purpose built trailer available from Skyfox Aviation. Fold wings on aircraft as described in this sections, secure wings into the folded position by attaching the tow struts and hardware kit to the rear wing spar attachment point on the wings to the bracket provided at the base of the fin. Load aircraft onto trailer, nose first, so that main wheels are located in the wells in the trailer floor. Raise the tail and assemble the tail support struts to the fuselage hardpoint located above the front tail skid spring mount. Tie main wheels to trailer.

9-20-01 TAXIING

Before attempting to taxi the aircraft, ground personnel should be checked out by a qualified pilot or other responsible person with CASA approval. (CAO 20.22). Engine starting and shutdown procedures should be covered as well. When it is established that the propeller back blast and taxi areas are clear, apply power to start the taxi roll and perform the following checks.

1. Taxi forward a few feet and apply brakes to determine their effectiveness.
2. While taxiing make slight turns to determine the effectiveness of the steering.
3. Observe wing clearance when taxiing near buildings or other stationary objects. If possible, position an observer outside the aircraft to guide you.
4. When taxiing on uneven ground, avoid holes and ruts.
5. Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel, or any loose material that may cause damage to the propeller blades.

9-30-01 WING FOLDING

- Chock both main wheels front and rear.
- Close both cabin doors. Remove turtle deck.
- Fold map and flight manual pocket forward.
- Ensure ailerons are at neutral.
- Remove safety pin from left front spar clevis pin, while holding wing at top of jury strut, remove clevis pin, slowly allow wing to fold back ensuring aileron does not foul fuselage.
- Replace clevis pin and safety pin in head rack.
- Lower tail skid to the ground before folding the other wing.
- Repeat for right wing.
- Fit wing hold back struts if required
- Reverse process for unfolding wings.

NOTE: Take care when inserting the wing root tongue.

- END -

CHAPTER 10

PARKING AND MOORING

Skyfox Aviation

MAINTENANCE MANUAL

CA-25N GAZELLE

CHAPTER 10 PARKING AND MOORING

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
10-10-01	PARKING	10-3	10 MAY 1995
10-20-01	MOORING	10-3	10 MAY 1995

10-10-01 PARKING

When parking the aircraft, ensure that it is sufficiently protected against adverse weather conditions and presents no danger to other aircraft. When parking the aircraft for any length of time, it is recommended that the aircraft be moored.

1. To park the aircraft, head it into wind if possible.
2. Chock both main wheels front and behind each wheel.
3. The control stick may be locked by using the seat belt.

10-20-01 MOORING

Park aircraft nose into prevailing wind, place chocks in front of and behind both main, wheels. Lock elevator and aileron controls sticks with lap seat belt. Using strong rope or chain attached to suitable pegs or mooring points in ground, secure wings by attaching rope or chain: to tie down points provided, at front wing spar attachment brackets on both wings. Secure tail skid to peg or mooring point by tying with rope. Refer Fig. 1001.




Fig. 1001

CHAPTER 11

REQUIRED PLACARDS

CHAPTER 11 REQUIRED PLACARDS

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	EFFECTIVITY
11-20-01	EXTERIOR PLACARDS AND MARKING	05 MAR 1997
11-30-01	INTERIOR PLACARDS AND MARKING	05 MAR 1997

EXTERIOR PLACARDS AND MARKINGS

- | | |
|--|---|
| 1. FUEL QUANTITY 26 LITRES PREMIUM GRADE GASOLINE TO DIN 51600, -NORM C1103 EURO SUPER RON 95 UNLEADED TO MIN RON 90, OR AVGAS 100LL | BOTH FUEL FILLER CAPS,
EUROPEAN AIRCRAFT ONLY |
| 2. FUEL QUANTITY 26 LITRES USE 95 RON MOGAS (LEADED) UNLEADED TO MIN RON 90, OR 100LL AVGAS | BOTH FUEL FILLER CAPS
AUSTRALIAN AIRCRAFT ONLY |
| 3. NO HEAVY OBJECTS
10Kg MAX | BAGGAGE HATCH |
| 4. COOLANT
80% GLYCOL
20% WATER

OIL
0-20 DEG C SAE 30
20-40 DEG C SAE 40
API SF OR SG
AUTOMOTIVE OIL ONLY
QTY 2.5 LTRS | UPPER ENGINE COWL
ACCESS HATCH |
| 5. EARTH | AT EACH EARTH TAB AT
FILLER CAPS, AND EACH
BOTTOM WING STRUT
ATTACHMENT POINTS |
| 6. OPEN ----- CLOSE | ON EACH DOOR AT EACH
DOOR LATCH |
| 7. FUEL DRAIN | GASCALATOR COLLECTOR
TANK |
| 8. CLOSE DOORS BEFORE REFUELING | AT EACH FILLER CAP |

INTERIOR PLACARDS AND MARKINGS

MINIMUM PILOT WEIGHT = 55Kg DESIGN MANOEUVRING SPEED V_a = 80Kts	INSTRUMENT PANEL
FLIGHT MANUAL STOWAGE BEHIND PILOT	INSTRUMENT PANEL
This aeroplane is classified as a very light aeroplane approved for day VFR only, in non-icing conditions. All aerobatic manoeuvres including intentional spinning are prohibited. See Flight Manual for other limitations.	INSTRUMENT PANEL
NO SMOKING	INSTRUMENT PANEL
TOTAL USEABLE FUEL 48.0 LITRES	AT FUEL COCK
USEABLE FUEL 24 LITRES	AT EACH FUEL QUANTITY INDICATOR
OPEN -----CLOSE	ON EACH DOOR AT EACH DOOR LATCH
NO TAKE OFF 10 L, GROUND FUEL LITRES	ON EACH WING FUEL TANK
CAUTION - APPLICATION OF CARBURETTOR HEAT AT HIGH POWER WILL RESULT IN SIGNIFICANT POWER LOSS	ON INSTRUMENT PANEL

- NOTE -

All controls, (other than primary flight surface controls), switches, fuses, circuit breakers, gauges and instruments are to be placarded with their function, direction of operation and limitations.

- END -

CHAPTER 12

SERVICING

CHAPTER 12 SERVICING

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
12-00-00	GENERAL	12-3	10 MAY 1995
12-00-01	REPLENISHING	12-3	10 MAY 1995
12-10-02	FUEL SYSTEM	12-4	
12-10-03	FILLING FUEL TANKS	12-4	
12-10-04	DRAINING FUEL STRAINER	12-4	
12-10-05	DRAINING FUEL SYSTEM	12-4	
12-10-06	SERVICING OIL SYSTEM	12-5	
12-10-07	DRAINING OIL TANK	12-5	
12-10-08	FILLING OIL SUMP	12-5	
12-10-09	OIL SCREEN, (SUMP)	12-6	
12-10-10	OIL FILTER	12-6	
12-10-11	RESERVED		
12-10-12	SERVICING COOLANT SYSTEM	12-6	
12-10-13	DRAINING COOLANT SYSTEM	12-7	
12-10-14	FILLING COOLANT SYSTEM	12-7	
12-20-01	SCHEDULED SERVICING	12-8	
12-20-02	LANDING GEAR, (MAIN)	12-8	
12-20-03	TAIL WHEEL	12-8	
12-20-04	BRAKE SYSTEM	12-8	
12-20-05	FILLING BRAKE SYSTEM RESERVOIR	12-9	
12-20-06	DRAINING BRAKE SYSTEM	12-9	
12-20-07	TYRE SERVICING	12-9	
12-20-08	POWER PLANT	12-10	
12-20-09	REMOVAL AND INSTALLATION OF AIR INDUCTION SYSTEM	12-10	
12-20-10	CLEANING AND INSPECTION OF AIR FILTER	12-10	
12-20-11	PROPELLER	12-10	
12-20-12	ELECTRICAL SYSTEM	12-10	
12-20-13	BATTERY SERVICING	12-11	
12-20-14	BATTERY BOX INSPECTION	12-11	
12-20-15	LUBRICATING INSTRUCTIONS	12-11	
12-20-16	APPLICATION OF OIL	12-12	
12-20-17	APPLICATION OF GREASE	12-12	
12-20-18	LUBRICATION CHARTS	12-13	
12-30-00	STORAGE OF ENGINE	12-19	
12-30-01	PREPARATION OF ENGINE FOR STORAGE	12-19	
12-30-02	PREPARATION OF ENGINE FOR INSTALLATION	12-19	

12-00-00 GENERAL

Servicing the aircraft includes the replenishment of fuel, oil, coolant, hydraulic brake fluid, tyre pressure, lubrication requirements and other required items. Refer Fig 1201.

12-10-01 REPLENISHING




Fig 1201

12-10-02 FUEL SYSTEM

At intervals of 100 hrs, clean the fuel strainer screen located in the fuel bowl, mounted on the lower right side of the firewall.

12-10-03 FILLING FUEL TANKS

Observe all required precautions for handling fuel. Fill the fuel tanks as specified in Chart 601 of Chapter 6. Each fuel tank holds a maximum of 26 litres. To obtain the standard fuel quantity of 55.75 litres total, (only 48.0 litres useable), fill both tanks to the bottom of the filler neck.

12-10-04 DRAINING FUEL STRAINER

1. The fuel strainer, equipped with an easy drain valve is mounted on the lower right hand side of the firewall. The fuel strainer should be drained regularly to check for water or dirt accumulations.
2. The procedure for draining the right and left tank lines is to open the easy drain valve for a few seconds with the fuel cock "ON", allowing enough fuel to flow out to clear the fuel lines as well as the fuel strainer.

12-10-05 DRAINING FUEL SYSTEM

The fuel may be drained from the system by operating the collector tank drain valve located under the right wing strut attachment point and the fuel filter bowl drain valve located on the lower right hand side of the firewall. The remainder is drained from the main tank fuel tank valves located on the lower, inboard surface of the wing.

- NOTE -

IT IS NOT POSSIBLE TO DRAIN ONLY ONE TANK WITHOUT MODIFYING THE FUEL SYSTEM.

- END -

12-10-06 SERVICING OIL SYSTEM

See Chapter 79 for description of the oil system.

The engine oil system should be checked before each flight and the oil changed after each 100 hrs. During the oil change, the oil filter should also be replaced.

- CAUTION -

DO NOT INTRODUCE ANY GRADE ADDITIVE TO THE BASIC LUBRICANT UNLESS RECOMMENDED BY THE ENGINE MANUFACTURER.

DO NOT USE ANY AIRCRAFT ENGINE OIL, EITHER WITH OR WITHOUT ADDITIVES -

- END -

The engine manufacturer does not recommend oils by brand names. Use a quality brand oil of the proper seasonal viscosity and specification. For information on the use of detergent oils, refer to engine operators manual.

12-10-07 DRAINING OIL TANK

To drain the oil tank, remove the engine cowls and centre console then remove the oil box base plate (Drain Cover). Provide a suitable container with a minimum capacity of that required to fill the tank (at least 3Lt). Open the oil drain valve or drain plug located at the base of the oil tank and drain the oil into the container. It is recommended that the engine be warmed to operating temperatures to ensure complete draining of the old oil.

NOTE: See Chapter 79 for "Quick Drain" oil system.

12-10-08 FILLING OIL TANK

The oil tank should normally be filled with oil, almost to the top mark on the dip stick. The quantity of oil required for the engine may be found in Chart 601 of Chapter 6. The specified grade of oil may be found in Rotax Operators Manual or on the oil access hatch on the top engine cowl. To service the engine with oil, open the oil access hatch on the top engine cowl, open the oil box lid and remove the oil filler cap with dipstick. Replenish the oil directly into the oil tank using a long funnel.

NOTE: The dipstick is marked with a flat area. The Top of the flat area is the MAX limit and the Bottom of the flat area is the MIN limit. The length of the flat area is 0.75 lts.

12-10-09 OIL SCREEN (IN OIL TANK)

The oil screen is located in the base of the oil tank and can only be serviced by removing the oil tank from the oil box. Once the oil tank has been removed from the oil box, the tank is disassembled and the oil strainer removed. Cleaning of the oil strainer should be carried out at each engine overhaul. When cleaning the strainer, take notice of any foreign particulars or metal filings which may indicate damage occurring in the engine. After reassembling the oil tank, pressurize to 14Kpa, (2psi), and check for leaks around the lid seal. Reinstall the oil tank into the oil box and attach to the firewall and reconnect all hoses.

NOTE: The Rotax Parts Manual refers to the screen as a baffle.

12-10-10 OIL FILTER

The disposable oil filter should be replaced at each engine oil change to prevent contaminants being passed on to the new oil. Loosen the oil filter clamp, (hose clamp), while leaving the lock wire intact, then remove the oil filter from the engine. Before installing the replacement filter, cut the old filter apart and examine for foreign particles and metal filings. If found, the source of the particles should be investigated further before allowing the engine back into service. When installing the new filter, tighten the filter to the engine and then rotate the oil filter clamp in an anti clockwise direction and tighten the clamp. The oil filter should now be prevented from unscrewing.

12-10-12 SERVICING COOLANT SYSTEM

The engine coolant system should be checked before each flight and changed every two years or at engine overhaul, whichever occurs first.

- CAUTION -

DO NOT INTRODUCE ANY GRADE ADDITIVE OR WATER TO THE BASIC COOLANT UNLESS RECOMMENDED BY THE MANUFACTURER.

- END -

The engine manufacturer does not recommend coolant by brand names. Use a quality brand coolant of the proper specification. For information on the use of coolants, refer to engine operators manual.

12-10-13 DRAINING COOLANT SYSTEM

To drain the coolant system, provide a suitable container with a minimum capacity of that required to fill the coolant system. Remove the engine cowls and remove the bottom coolant pump retaining bolt. It is recommended that the engine be warmed to operating temperature to ensure complete draining of the old coolant.

12-10-14 FILLING COOLANT SYSTEM

The coolant system should be filled via the expansion tank, (Part No 922 312), to the base of the filler neck. Then with the cap in place, ensure that the overflow bottle contains coolant to the bottom mark when engine is cold. The engine should be given a short run and then the coolant level rechecked in case of air locks.

12-20-01 SCHEDULED SERVICING

Scheduled Servicing is detailed in chapter 5.

LANDING GEAR

The landing gear consists of wheels, tyres, brakes, and strut assemblies. Check brake linings for wear and frayed edges, and discs for scoring. Replace if necessary. Minor servicing is described in the following paragraphs. For detailed service and overhaul instructions refer to Chapter 32.

12-20-02 LANDING GEAR, (MAIN)

The main landing gear should be visually inspected before each flight as part of the preflight inspection. In addition, a more thorough inspection should be carried out each 100 hours of airframe time in operation^ The landing gear is checked for damage, corrosion and distortion and. the bonded rubbers checked for fraying, chafing, or delamination which may indicate degradation of the internal rubber. Replace as necessary. It is also necessary to check the top pivot bolts for wear and distortion. Lubricate in accordance with the lubrication chart in Chapter 12.

12-20-03 NOSE WHEEL

The nose wheel should, be inspected before each flight as part of the pref light inspection and a more, thorough inspection carried, out. at each 100 hour interval of airframe operation. This inspection should include the steering mechanism, pivot pin, axle, bearings, steering springs for wear, deformity, corrosion and correct operation. Lubricate in accordance with the lubrication chart in Chapter 12.

12-20-04 BRAKE SYSTEM.

The braking system should be checked periodically to ensure that maximum braking efficiency is maintained. A functional test should be carried out at the beginning of the taxi roll for each flight. Refer Chapter 9.

The brakes are dual, independent, disc brakes operated by toe pedals on both rudder pedal assemblies. The brakes can be. activated by either occupant. The master cylinders have self contained reservoirs and are mounted to the left side rudder pedals. High pressure PVC brake lines carry the brake fluid to the calipers which are mounted to the undercarriage leg at the axle.

The brake discs are bolted to the wheel in a manner which allows the caliper to operate on the inside circumference of the disc.

The brake fluid level is checked by removing the vent screw from the top of the master cylinders and measuring the distance from the top of the cylinder to the top of the fluid. This distance should be no more than 20mm. To check for air in the brake system, apply pressure to the top of the brake pedal and measure the angle of deflection. If the deflection exceeds 25°, the brake system must be drained and refilled.

12-20-05 FILLING BRAKE SYSTEM RESERVOIR

The brake master cylinders are located on the left rudder pedals and can be serviced without removal. Remove the top engine cowl and lift the rubber boot, (if fitted); over the master cylinders. Remove the vent screw from the top of the brake master cylinder reservoir and inject the required quantity of MIL-H-5606E brake fluid through the bleed nipple located at the base of each wheel caliper until the master cylinder reservoir is half full. Repeat this procedure for each side if necessary. Replace the vent screw, rubber boot and top engine cowling and carry out a functional test of the brakes. Check for leaks and spilled fluid.

12-20-06 DRAINING BRAKE SYSTEM

To drain the braking system, remove the top engine cowling and: lift the rubber boot, (if fitted), over the master cylinders. Remove the vent screw from the top of the brake master cylinder reservoir and with a suitable container place under the wheel caliper, open the brake bleed nipple. Some assistance may be required to drain the fluid by pumping the brake pedal.

12-20-07 TYRE SERVICING

INSPECTION: A careful inspection of both tyres (and tubes, if applicable)r should be made.

INSTALLATION: When installing tubes into tyres, it is recommended that the inside of the tyre and the outside of the tube be dusted with talc or soapstone prior to installing the tube into the tyre. This will prevent the tube from sticking to the inside of the tyre or tyre beads. This dusting also helps the tube assume its normal position in the tyre when inflated and thus lessens the chances of tube wrinkling and thinning out. Care must be taken so as not to "pinch" the tube between the two halves of the wheel rim, when bolting them together ~ After assembly the tyres must be inflated . to a pressure of 35 psi. The pressure must remain in the type for at least 2 minutes before being reduced to normal operating pressure of 30 psi (nose), 20 psi (main). During the high pressure testing of all tyres, any deformities must be noted and rejected if found.

TYRE SERVICING (cont)

LUBRICATION: On various tyre types, lubrication of the tyre bead may be necessary. An approved solution is 10% vegetable oil, soap or plain water.

12-20-08 POWER PLANT

Regularly check the engine compartment for oil and fuel leaks, chafing of lines, loose wires and tightness of all parts. Maintenance instructions for the powerplant may be found in Chapter 72 of this manual and in the appropriate manufacturers manuals.

12-20-09 REMOVAL & INSTALLATION OF AIR FILTER

The air filter is located on the front of the engine below the propeller reduction gearbox and is mounted to the front of the induction air selector box. The air filter is removed by first removing both top and bottom engine cowls, then removing the two fixing screws on the front of the air filter. Installation is accomplished by reversing the above procedures.

12-20-10 CLEANING & INSPECTION OF AIR FILTER

The air filter should be removed and cleaned daily when operating in dusty conditions. If any holes or tears are noticed, the air filter must be replaced immediately. Wash the foam filter material in kerosene until the filter looks clean and free of dust particles, then rinse in clean soapy water and allow to dry. Recoat the foam with air filter oil as listed in the lubrication chart contained in Chapter 12.

12-20-11 PROPELLER

The propeller surfaces along with the spinner and backplate should be cleaned and inspected frequently for nicks, scratches, corrosion and cracks. Minor nicks and scratches on the prop may be removed as per instructions in Chapter 61. The face of each propeller blade should be painted when necessary with a flat black paint to reduce glare.

12-20-12 ELECTRICAL SYSTEM

Servicing the electrical system involves checking cable connections, and checking for any spilled electrolyte that would lead to corrosion. The security of all electrical connections should be checked as well as the operation of all lights, general condition of the alternator and starter. All electrical wires should be inspected for chafing and bare wires. For detailed information on this system, refer" to Chapter 39 of this manual.

12-20-13 BATTERY SERVICING

The battery in the Gazelle is a "Gel Cell" (Sealed).

i.e. Maintenance free, except for cleaning of the terminals.

Refer page 24-10.

12-20-14 BATTERY BOX INSPECTION

The battery should be checked for spilled electrolyte or corrosion at each 100 hour inspection. Should corrosion be found in the box, on the terminals or around the battery, the battery should be removed and both, box and battery be cleaned by the following procedure:

1. Clean the battery and box. Corrosion effects may be neutralized by applying a solution of -baking soda and water mixed to a consistency of thin cream. The application of this mixture should be applied until all bubbling action has ceased.
2. Rinse the battery and box with clean water and dry.
3. Reinstall battery and box into aircraft.

12-20-15 LUBRICATING INSTRUCTIONS

Proper lubrication procedures are of immeasurable value both as a means of prolonging the service life of an aircraft and as a means of reducing the frequency of extensive and expensive repairs. The periodic application of recommended lubricants to their relevant bearing surfaces, as detailed in the following paragraphs, together with the observance of cleanliness, will ensure that maximum efficiency and utmost service of all moving parts.

Lubrication instructions regarding the locations, time intervals, and type of lubricants used may be found in the lubrication charts, (Figs 12-3 - 12-6). To ensure the best possible results from the application of lubricants, the following precautions should be observed.

1. Use recommended lubricants. Where general purpose lubricating oil is specified but unavailable, clean engine oil may be used as a satisfactory substitute.
2. Check the components to be lubricated for evidence of excessive wear and replace them as necessary.
3. Remove all excess lubricant from the components in order to prevent the collection of dirt and sand in abrasive quantities capable of causing excessive wear to bearing surfaces.

12-20-16 APPLICATION OF OIL

Whenever specific instructions for lubrication of mechanisms requiring- lubrication are not available, observe the following precautions:

Apply oil: sparingly. Never more than enough to coat the bearing surfaces.

12-20-17 APPLICATION OF GREASE

Care must be taken when lubricating bearings and bearing surfaces with, a grease gun, to ensure that the gun is filled with new, clean grease of the required specified for the particular application. before applying lubricant to the grease fittings.

1. Where a reservoir is not provided around the bearing, apply the lubricant sparingly and wipe off any excess.
2. Remove wheel bearings form the wheel hub and clean thoroughly with a suitable solvent. When repacking with grease, ensure the lubricant enters the space between, the rollers and the retaining ring. Do not pack the grease into the wheel hub.

12-20-18 LUBRICATION CHARTS

The approximate location of each part of the aircraft to be lubricated is identified by an index number in the pictorial I portion, of the charts. Further identification of each, such indexed part, its proper lubricant and frequency of lubrication is given in the tabular section of the chart. Special instructions and precautionary notes applicable to specific items to be lubricated are included at the bottom of each tabular portion of the charts. The more common: notes to be observed during lubrication procedures are as follows:

1. Lubrication points - Wipe all lubrication, points clean of old lube, dirt etc, before applying; fresh lubricant.
2. Bearing; and bushings - Clean exterior with quick drying solvent before lubricating.
3. Do not apply lubricant to rubber parts except as noted.
4. Do not apply any lubrication, to black nylon bearings, flight control surface hinges or rudder cable guides.
5. Do not apply any lubrication to white nylon bearings on rudder pedal torque tube pivot points.
6. Do not apply any lubrication to rod end bearings where the bearing is housed in a teflon type liner.

CHART 1202 RUDDER PEDAL ASSEMBLY Refer figure 1203 ITEM / DESCRIPTION	LUBE INTERVAL	RECOMMENDED LUBRICANT
1. Rudder Pedal Cross Bars	100hrs	General purpose Lubricating Oil
2. Brake Pedal Pivots.	100hrs	General Purpose Lubricating Oil
3. Yoke Pivots	100hrs	MIL-G-81322A General Purpose Grease
4. Brake Master Cylinder Base	100hrs	MIL- G81322A General Purpose Grease
5. Bearing; Pedal Pivots	NIL	DO NOT LUBRICATE




Figure 1203

CHART 1201 CONTROL SYSTEM. Refer figure 1202 ITEM: / DESCRIPTION.	LUBE INTERVAL	RECOMMENDED LUBRICANT
1. Control Stick Pivot	100hrs	MIL-G-81322A General Purpose Grease
2. Control Column Pivot	100hrs	MIL-G-81322A General Purpose Grease
3. Stick Pivot Control Tube Rod End	100hrs	General Purpose Lubricating Oil
4. Swivel Joint	100hrs	MIL-G-81322A General Purpose Grease
5. Stick Pivot Control Tube Rod End	100hrs	General Purpose Lubricating Oil
6. Forward Bellcrank Rod End	100hrs	General Purpose Lubricating Oil




Figure 1202

7. Control Tube Forward Aileron Rod End	100hrs	General Purpose Grease
8. Bellcrank Forward Aileron	100hrs	MIL-G-81322A General Purpose Grease
9. Reserved		
10. Tail Control Tube Forward	100hrs	General Purpose Lubricating Oil
11. Control Tube Aft Aileron Rod End	100hrs	General Purpose Lubricating- Oil
12. Bellcrank Aileron Mid	100hrs	MIL-G-81322A General Purpose Grease
13. Bellcrank Aileron Mid Rod End	100hrs	General Purpose Lubricating Oil
14. "U" Joint	100hrs	MIL-G-81322A General Purpose Grease
15. Top Swivel Link Aileron	100hrs	MIL-G-81322A General Purpose Grease
16. Elevator Control Rod Clevis Yoke	100hrs	MIL-G-81322A General Purpose Grease
17. Elevator Control Rod Forward Rod End	100hrs	General Purpose Lubricating Oil
18. Bell crank Aileron Rear Yoke	100hrs	MIL-G-81322A General Purpose Grease
19. Bellcrank Elevator Idler Rod End	100hrs	MIL-G-81322A General Purpose Grease
20. Tail Control Tube Aft Rod End	100hrs	General Purpose Lubricating Oil




Figure 1204

CHART 1203 GENERAL Refer figure 1204 ITEM / DESCRIPTION	LUBE INTERVAL	RECOMMENDED LUBRICANT
1. Main Wheel Bearings	100hrs	MIL-G-81322A General Purpose Grease
2. Nose Wheel Top Bush	100hrs	General Purpose Lubrication oil
3. Nose Wheel Bearing & Steering Mechanism	100hrs	MIL-G-81322A General Purpose Grease

4. Undercarriage Pivot Bolts	100hrs	MIL-G-81322A General Purpose Grease
5. Wing Strut Pivot Point Yoke	1 Year	MIL-G-81322A General Purpose Grease
6. Main Wing Pivot Bolts	1 Year	MIL-G-81332A General Purpose Grease
7. Main Wing Clevis Pins	100hrs	MIL-G-81322A General Purpose Grease

- NOTE -

FOR ENGINE LUBRICATING INSTRUCTIONS, REFER TO THE MANUFACTURER'S OPERATING MANUAL.

- END -

12—30—01 PREPARATION OF ENGINE FOR STORAGE

Instructions for preparing the engine for storage are given in the engine manufacturer's operating manual.

12-30-02 PREPARATION OF ENGINE FOR INSTALLATION

Instructions for preparing an engine for installation are given in the engine manufacturer's operator's manual.

CHAPTER 20
STANDARD PRACTICES / AIRFRAME

CHAPTER 20 STANDARD PRACTICES / AIRFRAME

TABLE OF CONTENTS/EFFECTIVITY


CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
10-00-00	STANDARD PRACTICES AIRFRAME	20-3	10 MAY 1995
10-00-01	TORQUE WRENCHES	20-3	10 MAY 1995
10-00-02	METHOD OF INSTALLING ROD END BEARINGS	20-3	10 MAY 1995
20-10-00	AIRCRAFT FINISH CARE	20-4	10 MAY 1995
20-10-01	EXTERIOR SURFACES	20-4	10 MAY 1995
20-10-02	SKYLIGHT, DOORS AND WINDOWS	20-4	10 MAY 1995
20-10-03	WINDSCREEN	20-5	05 MAR 1997
20-10-04	SIDE PANELS AND SEATS	20-5	05 MAR 1997
20-10-05	ENGINE COMPARTMENT	20-5	10 MAY 1995
20-10-06	FUEL SYSTEM	20-6	05 MAR 1997
20-10-07	LANDING GEAR	20-6	10 MAY 1995

20-00-00 STANDARD PRACTICES AIRFRAME

The acceptable methods, techniques and practices are described in AC 43.13-1A.

20-00-01 TORQUE WRENCHES

Torque wrenches should be checked daily and calibrated by means of weights and a measured arm to make sure that inaccuracies are not present. Checking one torque wrench against another is not sufficient and is not recommended. Some wrenches are quite sensitive as to the way they are supported during a tightening operation. Any information furnished by the manufacturer must be followed explicitly.

20-00-02 METHOD OF INSTALLING ROD END BEARINGS**CORRECT METHOD OF CHANGING
ROD END BEARING**

- NOTE -

USING A SCREWDRIVER OR SIMILAR IMPLEMENT THROUGH THE EYE OF THE ROD END AS A MEANS OF REMOVING OR INSTALLING THE ROD END IS NOT AN ACCEPTABLE PRACTICE.

- END -

20-10-00 AIRCRAFT FINISH CARE

All exterior surfaces are painted with Dulux 2-Pack enamel. For fabric surfaces, 20% Plasticiser is added.

20-10-01 EXTERIOR SURFACES

Rinse fabric with lukewarm water; wash gently with mild soap or detergent and lukewarm water using a soft cloth or sponge. Rinse again. Dry with soft cloth or moist cellulose sponge to prevent water spotting. To remove oil or grease marks, use a petroleum based cleaner then rinse off.

20-10-02 SKYLIGHT, DOORS AND WINDOWS**LEXAN:**

Rinse sheet with lukewarm water; wash gently with mild soap or detergent and lukewarm water using a soft cloth or sponge. **DO NOT SCRUB** or use brushes or squeegees. Rinse again. Dry with soft cloth or moist cellulose sponge to prevent water spotting.

To remove wet paint, glazing compound or grease, rub lightly with a good grade of VM&P Naphtha or isopropyl alcohol, then wash and rinse. DO NOT USE GASOLINE.

Compatible Cleaning Agents:*** Aqueous Solutions of Soaps and Detergents**

- Fantastik
- Formula 409 -
- Hexcel, F.O.554
- Joy
- Lysol
- Mr. Clean
- Neleco-Placer
- Pinesol
- Top Job
- Windex

*** Organic Solvents**

- Aliphatic Hydrocarbons
- Kerosene
- Naphtha (VM&P Grade)
- Petroleum Spirits

*** Alcohols**

- Isopropyl Alcohol
- Methanol

*** Graffiti Removal**

- Butyl Cellosolve
(For removal of paints, marking pen inks, lipstick, etc.)

To minimize scratches and minor abrasions, use a mild automobile polish such as Johnson's Paste Wax, Novus Plastic Polish #1 and #2 or Mirror Glaze Plastic Polish.

20-10-03 WINDSCREEN

The windscreen in the CA25N is molded acrylic plastic.

To remove scratches and minor abrasions, use a mild automobile polish such as Johnson's Paste Wax, Novus Plastic Polish #1 and #2 or Mirror Glaze Plastic Polish.

To clean the windscreen, use a soft grit free cloth with plenty of water and mild soap.

Cracks may be stopped temporarily by drilling a small hole at the extreme ends of the cracks.

See AC 43.13-1A for more information.

20-10-04 SIDE PANELS AND SEATS**UPHOLSTERY:**

The seat cover can be removed and cleaned using upholstery cleaner or washed by hand.

The fixed upholstery is the same material as the seat cover and can be cleaned in the same manner.

The Flame Retardant product used will not be removed by washing or dry cleaning, however we recommend no more than five washes or dry cleans before returning fabric for re-treatment.

20-10-05 ENGINE COMPARTMENT

Do not spray solvent into alternator, starter motor, air intake or alternate air inlets.

With the engine cowling removed, spray or brush the engine with solvent or a mixture of solvent and degreaser, as desired. It may be necessary to brush areas where heavy grease and dirt deposits have collected in order to clean them.

Allow the solvent to remain on the engine for five to ten minutes, then rinse the engine clean with additional solvent and allow to dry.

-CAUTION-

DO NOT OPERATE ENGINE UNTIL EXCESS SOLVENT HAS EVAPORATED OR OTHERWISE BEEN REMOVED.

-END-

20-10-06 FUEL SYSTEM

1. To flush the fuel tanks and fuel cock, disconnect the fuel line at the carburettor (both carburettors for Rotax 912 engines).
2. Turn on the electric fuel pump and flush fuel through the system until it is determined that there is no dirt and foreign matter in the fuel cock or fuel tanks.
3. During this operation, agitation of the fuel within the tanks will help pick up and remove any dirt.
4. When all fuel tanks are flushed, remove and clean all filters.

NOTE: RE-FIT MAIN WING TANK FILTERS MAX. 30 IN/LBS

20-10-07 LANDING GEAR

Do not spray solvent onto rubber, brake linings, or fabric.

With the brake linings and tires covered with plastic, spray or brush the landing gear with solvent or a mixture of solvent and degreaser, as desired. It may be necessary to brush areas where heavy grease and dirt deposits have collected in order to clean them.

Allow the solvent to remain on the landing gear for five to ten minutes, then rinse the engine clean with additional solvent and allow to dry.

CHAPTER 21
ENVIRONMENTAL SYSTEMS

CHAPTER 21 ENVIRONMENTAL SYSTEMS

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
21-00-00	GENERAL	21-3	01 MAR 1996
21-00-01	DESCRIPTION AND OPERATION	21-3	01 MAR 1996
21-40-00	HEATER	21-3	01 MAR 1996
21-40-01	HEATER MAINTENANCE	21-3	01 MAR 1996

21-00-00 GENERAL

Because of the simplicity of the heating and ventilation system installed in the Skyfox, the operation and maintenance instructions of the components are combined. A pictorial description of these systems may be found in figure 21-1.

21-00-01 DESCRIPTION AND OPERATION

Heat for the cabin is provided by a hot air heat muff installed around the right-hand exhaust manifold. Fresh air enters the engine compartment through the front of the engine cowling to the heater muff. The air is then heated and vented into the cabin area through a valve which can be controlled from the instrument panel. When the valve is completely closed off, the heated air is vented back to the engine compartment. The heater outlet in the cabin is located under the center of the instrument panel. Control for the heater system is located on the left panel below the instruments.

Fresh air is able to enter the cabin via two air vents located in each cabin door. These vents are adjusted to allow control of air entering the cabin.

- CAUTION -

WHEN RE-INSTALLING THE CABIN AND CARBURETTOR HEAT HOSES, ASSURE THAT THE PROPER HOSE IS CONNECTED TO THE PROPER HEAT MUFF OUTLET.

- END -

21-40-00 HEATER

The Cabin heat is derived from cold ram air passing through a shroud on the surrounding exhaust pipe on the lower right-hand side of the engine.

21-40-01 HEATER MAINTENANCE

If the exhaust pipe should become defective, carbon monoxide fumes may be discharged into the cabin area. Therefore, it is imperative that the exhaust system be inspected regularly. Refer to Chapter 5 for inspection of exhaust system. The heat collector must be removed in order to inspect the manifold assembly. Check the operation of the push/pull controls to ensure the valve doors function properly. Refer to fig 2101 for an illustration of the heater system.




Figure 2101

CHAPTER 23

COMMUNICATIONS

CHAPTER 23 COMMUNICATIONS

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER	SECTION	SUBJECT	PAGE	EFFECTIVITY		
	23-00-00	GENERAL	23-3	01	MAR	1996
	23-10-00	VHF Tx Rx	23-3	01	MAR	1996
	23-10-01	DESCRIPTION	23-3	01	MAR	1996
	23-10-02	LOCATION	23-3	01	MAR	1996
	23-10-03	TROUBLE SHOOTING	23-3	01	MAR	1996
	23-50-01	INTERCOM	23-4	10	MAY	1995
	23-50-02	DESCRIPTION	23-4	10	MAY	1995
	23-50-03	LOCATION	23-4	10	MAY	1995
	23-50-04	TROUBLE SHOOTING	23-5	10	MAY	1995

23-00-00 GENERAL

This chapter describes the communications systems installed as standard equipment in the Skyfox. A troubleshooting chart is also included for fault finding in the various communications systems.

- NOTE -

Some aircraft may be fitted with extra equipment which is not a standard fit. For information regarding that extra equipment, refer to the data supplied with the aircraft or the manufacturer of the equipment.

- END -

23-10-00 VHF Tx Rx**23-10-01 DESCRIPTION**

The VHF communications transceiver fitted to the aircraft is a Bendix King KY97A or an ICOM IC-A200 A wiring diagram detailing the interwiring of the transceiver is shown in Chapter 91 of this manual.

23-10-02 LOCATION

The VHF transceiver is mounted in the instrument panel, to the left of the engine tachometer. The aerial is mounted to the baggage compartment hatch.

23-10-03 TROUBLESHOOTING

CHART 2301 TROUBLESHOOTING (VHF TRANSCEIVER)

TROUBLE	CAUSE	REMEDY
DISPLAY DOES NOT ILLUMINATE	Interruption to power supply. Faulty transceiver.	Check fuses, system voltage at transceiver input, replace transceiver.

Cont...

NO RECEIVER SIGNAL HEARD IN HANDSET	Faulty or damaged aerial, damaged coaxial cable, faulty transceiver, loose or broken audio output cables or connections, faulty intercom, faulty headset.	Check aerial and coaxial cable, replace transceiver, check audio output cables and connections, check intercom and head- set.
Tx INDICATOR DOES NOT ILLUMINATE WHEN PUSH TO TALK BUTTON IS PRESSED	Faulty intercom; damaged or loose key cables or connectors; faulty push to talk switch.	Replace aerial; repair or replace coaxial cable; replace intercom or headset.
Tx INDICATOR ILLUMINATES BUT NO SIGNAL IS TRANSMITTED	Faulty aerial, damaged or loose coaxial cable, faulty intercom, faulty headset.	Replace aerial, repair or replace coaxial cable, replace intercom or headset.

23-50-03 INTERCOM**23-50-02 DESCRIPTION**

The intercom fitted as standard equipment to the aircraft is a Dacom, ICS-41. This intercom has voice activated inter occupant communications, constant communications radio monitoring, and push to transmit facility with left seat priority. This means that the left push to talk button will override and cut out the right push to talk. In the event of an intercom failure, radio communications will still be received through the headsets.

23-50-03 LOCATION

The intercom unit and control panel is mounted in the instrument panel, above the VHF transceiver. The sockets for the headsets are located on the head rack at the top of the windscreen.

23-50-04 TROUBLESHOOTING

CHART 2302 TROUBLESHOOTING (INTERCOM)

TROUBLE	CAUSE	REMEDY
NO INTER OCCUPANT COMMUNICATION OR VHF TRANSMISSION	Interruption to power supply, faulty intercom, loose or damaged audio output cables, dirty or faulty headset plugs.	Check fuses, system voltage at intercom output, replace intercom, check audio output cables and clean headset plugs and sockets.
NO VHF TRANSMISSION	Faulty or damaged aerial, damaged coaxial cable, faulty transceiver, faulty intercom, faulty headset, faulty push to talk switch.	Check aerial and coaxial cable, replace transceiver, check intercom and headsets, check push to talk switch.
NO INTER OCCUPANT COMMUNICATION	Faulty intercom, incorrectly set squelch on intercom.	Replace intercom, reset squelch.
CONSTANT BACKGROUND NOISE THROUGH HEADSETS	Incorrectly set squelch on intercom.	Reset squelch.

CHAPTER 24
ELECTRICAL POWER

CHAPTER24 ELECTRICAL POWER**TABLE OF CONTENTS/EFFECTIVITY**

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
24-00-00	GENERAL	24-3	10 MAY 1995
24-00-01	DESCRIPTION AND OPERATION	24-3	10 MAY 1995
24-00-02	TROUBLE SHOOTING	24-3	10 MAY 1995
24-30-00	DC GENERATION	24-10	10 MAY 1995
24-30-01	ALTERNATOR SYSTEM	24-10	10 MAY 1995
24-30-02	DESCRIPTION OF ALTERNATOR	24-10	10 MAY 1995
24-30-03	CHECKING OF ALTERNATOR SYSTEM	24-10	10 MAY 1995
24-30-04	SERVICE PROCEDURES	24-10	10 MAY 1995
24-30-05	BATTERY	24-10	10 MAY 1995
24-30-06	SERVICING BATTERY	24-10	10 MAY 1995
24-30-07	REMOVAL OF BATTERY	24-10	10 MAY 1995
24-30-08	INSTALLATION OF BATTERY	24-11	10 MAY 1995
24-30-09	TESTING BATTERY	24-11	10 MAY 1995
24-30-10	CHARGING BATTERY	24-11	10 MAY 1995
24-30-14	REMOVAL OF VOLTAGE RECTIFIER/ REGULATOR	24-11	10 MAY 1995
24-30-15	INSTALLATION OF VOLTAGE RECTIFIER/ REGULATOR	24-11	10 MAY 1995
24-30-16	CHECKING VOLTAGE RECTIFIER/ REGULATOR	24-11	10 MAY 1995
24-30-17	VOLTMETER	24-11	10 MAY 1995
24-50-00	ELECTRICAL SYSTEM COMPONENT LOADS	24-10	10 AY 1995

24-00-00 GENERAL

This chapter contains instructions for correcting difficulties which may arise in the operation of the electrical charging system. Schematics for the individual systems are located in Chapter 91 of this manual. For further information concerning electronic equipment, refer to Chapter 23.

24-00-01 DESCRIPTION AND OPERATION

Electrical power is supplied by a 14-volt, direct current, negative ground electrical system. A 12-volt battery is incorporated into the system to furnish power for starting and as a reserve power source in case of an alternator failure. Access to the battery is gained by removing the turtle deck.

The electrical generating system consists of an engine driven 250-watt alternator. A solid-state voltage rectifier/regulator maintains the system bus voltage at 14 volts. The master switch must be ON before any electrical equipment will operate. The master switch controls the master solenoid. The switch is a single pole, single throw type.

NOTE: If the engine is running, then the alternator will supply electrical power to the entire electrical system, whether or not the Master Switch is OFF or ON.

24-00-02 TROUBLESHOOTING

Probable troubles peculiar to the electrical system components covered by this Chapter are listed in Chart 2401, along with their probable causes and suggested remedies. After the trouble has been corrected, check the entire system for security and operation of its components. Check the Rotax Operator's Manual for more details.

CHART 2401 TROUBLESHOOTING (ALTERNATOR)

VOLTMETER DISPLAYS LESS THAN 10 VOLTS REGARDLESS OF ENGINE RPM.

Check the following:

1 . OPEN FIELD CIRCUIT.

A. Check the continuity of circuits at the following points:

- (a) master solenoid field contact.
- (b) master solenoid output contact.
- (c) master switch.
- (d) bus bar.
- (e) voltmeter.

The voltage recorded at each point should be the same as that of the battery. If an open field is detected, determine the cause and replace the component or effect a repair.

2 . OPEN OUTPUT CIRCUIT.

A . Check the integrity of the alternator fuse. Replace if necessary.

B . With the engine running at 3000rpm, turn the master switch OFF and check the voltage at the bus bar. The voltage recorded at the bus bar should be approximately 14 volts. If a voltage is recorded which varies from approximately 14 volts, the rectifier/regulator is at fault. Replace if necessary.

3 . OPEN FUEL WINDING.

Check the continuity of the field circuits by disconnecting both wires connected to the "G" terminals on the rectifier/regulator and place a multimeter across those two wires. The circuit should be uninterrupted. If an open circuit is detected, replace the field windings.

OUTPUT ON VOLTMETER DOES NOT MEET MINIMUM VALUES REGARDLESS OF ENGINE RPM.

Check the following:

1 . OPEN FIELD CIRCUIT.

A . Check for a resistance in the following circuits:

- (a) master solenoid field contact
- (b) master solenoid output contact
- (c) master switch
- (d) bus bar
- (e) voltmeter

If a high resistance is detected, determine the cause and replace the component or effect a repair.

2 . OPEN OUTPUT CIRCUIT.

- A . Check the integrity of the alternator fuse. Replace as necessary.
- B . With the engine running at 3000RPM, turn the master switch OFF and check the voltage at the bus bar. The voltage recorded at the bus bar should be approximately 14 volts. If a voltage is recorded which varies from approximately 14 volts, the rectifier/regulator is at fault. Replace if necessary.

3 . OPEN FIELD WINDING.

Check the continuity of the field circuits by disconnecting both wires connected to the "G" terminals on the rectifier/regulator and place a multimeter across those two wires. The circuit should be uninterrupted. If an open circuit is detected, replace the field windings.

ALTERNATOR CIRCUIT FUSE BLOWS

Check the following:

- A . Check the output circuit from the voltage regulator/rectifier with the engine running at 3000RPM and all electrical equipment turned off. It should show approximately 14 volts. If voltage is recorded which varies from approximately 14 volts, the rectifier/regulator is at fault. Replace if necessary.
- B . Check for a dead short in all electrical systems. Repair or replace if necessary.
- C . Check that the correct fuse rating is being used.

EXCESSIVE VOLTMETER FLUCTUATION

Check the following:

- A. Check the continuity of circuits at the following points:
 - (a) master solenoid field contact.
 - (b) master solenoid output contact.
 - (c) master switch.
 - (d) bus bar.
 - (e) voltmeter.

If an open field is detected, determine the cause and replace the component or effect a repair.

- B. Check the output circuit from the voltage regulator/rectifier with the engine running at 3000RPM and all electrical equipment turned off. It should show approximately 14 volts. If a voltage is recorded which varies from approximately 14 volts, the rectifier/regulator is at fault. Replace as necessary.
- C. Check the integrity of the control circuit of the voltage rectifier/regulator.

EXCESSIVE VOLTS INDICATED

- A. Check the output circuit from the voltage regulator/rectifier with the engine running at 3000RPM and all electrical equipment turned off. It should show approximately 14 volts. If a voltage is recorded which varies from approximately 14 volts, the rectifier/regulator is at fault. Replace if necessary.
- B. Check the integrity of the control circuit of the voltage rectifier/regulator.

TROUBLESHOOTING (BATTERY)-----
DISCHARGED BATTERY

Check the following:

1 . CONTINUOUS CURRENT DRAIN

- A. Master switch has been left turned on.

Turn master switch OFF and recharge battery.

- B. Master solenoid has remained in the closed position with the master switch OFF.

(a) Check for voltage at the field circuit of the master switch. If voltage is present, replace master switch.

(b) Check for voltage at the bus bar with the master switch OFF. If voltage is detected, replace master solenoid.

2 . EXPIRED BATTERY

If the battery is a wet cell type

- A. Check the specific gravity of each cell. There should be little or no variation between cells.

Replace battery as required.

3 . BATTERY UNUSED FOR LONG PERIOD

- A. Recharge battery and check voltage. If voltage is less than 13.5 volts replace battery.

BATTERY LIFE IS SHORT

1 . EXCESSIVE CURRENT DRAIN

- A. Check the following circuits for excessive current usage:

(a) starter motor.

(b) master solenoid field circuit.

Determine the cause of the fault and repair or replace as necessary.

- B. Check that the starter motor solenoid is disengaging after start. Replace as necessary.

- C. Check all circuits for a dead short.

2 . BATTERY EXPIRED

- A. Replace Battery.

CRACKED BATTERY CASING

- 1 . BATTERY OVER CHARGED
Replace battery.
- 2 . FROZEN BATTERY
Replace battery.

ELECTROLYTE RUNS OUT OF VENT PLUGS - WET CELL TYPE ONLY

- 1 . OVERFULL BATTERY
Check the electrolyte level of each cell. If overfull, drain all electrolyte and replace with new fluid.
- 2 . BATTERY OVERCHARGING
Check the output of the charging circuit. If output exceeds specifications, check operation of sensing circuit of voltage rectifier/regulator. Replace as required.
- 3 . EXCESSIVE CURRENT DRAIN
 - A . Check the following circuits for excessive current usage:
 - (a) starter motor
 - (b) master solenoid field circuitDetermine the cause of the fault and repair or replace as necessary.
 - B . Check that the starter motor solenoid is disengaging after start. Replace as necessary.
 - C . Check all circuits for a dead short.

EXCESSIVE CORROSION ON BATTERY TERMINALS

- 1 . LOOSE CONNECTION
Check for a loose connection between the battery and the main power leads.

BATTERY FREEZES - WET CELL TYPE ONLY

1. WATER ADDED WITHOUT CHARGING BATTERY
If fresh water is added to the battery, the battery should be briefly charged (approximately 1 hour), to prevent the added water from freezing in cold conditions.

BATTERY POLARITY REVERSED

1. **BATTERY ALLOWED TO DRAIN COMPLETELY**
Check for cause of battery drain, refer discharged battery in this chapter. Replace battery.
2. **BATTERY CHARGED WITH POLARITY REVERSED**
Check that the battery is connected to the charger or aircrafts with the correct polarity. Replace battery.

BATTERY CONSUMES EXCESSIVE WATER

1. **BATTERY OVERHEATING**
 - A. Check the following circuits for excessive current usage:
 - (a) starter motor
 - (b) master solenoid field circuit.Determine the cause of the fault and repair or replace as necessary.
 - B. Check that the starter motor solenoid is disengaging after start. Replace as necessary.
 - C. Check all circuits for a dead short.
 - D. Check that the charge current is not excessive and that the sensor circuit in the voltage regulator/rectifier is operating correctly.

24-30-00 DC GENERATION

The alternator is located in the flywheel at the rear of the engine and is driven by the crankshaft. The AC current produced by the alternator is converted to DC by the voltage regulator/rectifier.

There is one fuse/circuit breaker switch which controls the generating system. This switch marked "ALTERNATOR," is in the output circuit from the voltage regulator/rectifier and if switched off or self-switched off will result in a complete interruption to the charging current.

The voltmeter displays the electrical system voltage. An indication of alternator output in amperes is not given by the voltmeter. The voltmeter will indicate that the alternator is charging by an increase in voltage from engine idle to 3000RPM.

24-30-01 ALTERNATOR SYSTEM**24-30-02 DESCRIPTION OF ALTERNATOR**

The integrated alternator is a permanent-excited 10 pole single phase generator with 250 Watt AC output. For further information, refer to the engine manufacturer's maintenance manual.

24-30-03 CHECKING OF ALTERNATOR SYSTEM**24-30-04 SERVICE PROCEDURES**

For maintenance and servicing procedures, refer to the engine manufacturer's maintenance manual.

24-30-05 BATTERY**24-30-06 SERVICING BATTERY**

The battery fitted at manufacture is a sealed battery. All connections must be clean and tight.

24-30-07 REMOVAL OF BATTERY

Remove the turtle deck. Ensure that the master switch is in the OFF position, then disconnect the battery cables and pull them free of the battery box. Disconnect the battery holding bar and remove from the battery box. Lift the battery up and out.

24-30-08 INSTALLATION OF BATTERY

The installation of the battery is the reverse of the removal procedure.

24-30-09 TESTING BATTERY

The specific gravity cannot be tested. If the alternator output is known to be correct, the question of battery capability can be more accurately determined with a load type tester or replace the battery.

24-30-10 CHARGING BATTERY

If the battery is not up to normal charge, remove it from the aircraft and charge, starting at 4 amperes and finishing at 2 amperes. A fast charge is not recommended.

24-30-14 REMOVAL OF VOLTAGE RECTIFIER / REGULATOR

Remove the top engine cowl from the aircraft, locate the voltage rectifier/regulator on the right side (cockpit side) of the firewall, and disconnect the electric wire connector from its base. Remove the four fixing bolts allowing the voltage rectifier/regulator to be removed from the aircraft.

24-30-15 INSTALLATION OF VOLTAGE RECTIFIER / REGULATOR

The installation of the voltage rectifier/regulator is the reverse of the removal procedures.

24-30-16 CHECKING VOLTAGE RECTIFIER / REGULATOR

For information regarding the testing of the voltage rectifier/regulator, refer to the engine manufacturer's maintenance manual.

24-30-17 VOLTMETER

The voltmeter indicates the aircraft system voltage and can easily be checked by placing a calibrated voltmeter or multimeter across the bus bar and earth. Both meters should read identically. The voltmeter is not a serviceable component and should be replaced if faulty.

24-50-00 ELECTRICAL SYSTEM COMPONENT LOADS

CHART 2401 ELECTRICAL LOAD DATA

ITEM	DESCRIPTION	AMPS
1	MASTER RELAY	0.75
2	OIL PRESSURE GAUGE	0.1
3	OIL TEMPERATURE GAUGE	0.1
4	CYLINDER HEAD TEMPERATURE GAUGE	0.1
5	TACHOMETER	0.1
6	VOLTMETER	0.1
7	HOURMETER	0.1
8	FUEL PUMP	1.0
9	VHF COM Tx	3.6
10	VHF COM Rx	0.7
11	INTERCOM	0.2
12	GYRO ARTIFICIAL HORIZON	0.6
13	DIRECTIONAL GYRO	0.6
14	GYRO TURN CO-ORDINATOR	0.5
15	STROBE LIGHTS	3.2
16	G.P.S. (Garmin)	0.45
17	LANDING LIGHT	8.5
18		
19		
	TOTAL	20.70

CHAPTER 25

EQUIPMENT FURNISHINGS

CHAPTER 25 EQUIPMENT FURNISHINGS
TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
25-00-00	GENERAL	25-3	10 MAY 1995
25-10-00	SEAT	25-3	10 MAY 1995
25-10-01	REMOVAL AND INSTALLATION OF SEAT	25-3	10 MAY 1995
25-10-02	REMOVAL AND INSTALLATION OF CENTRE CONSOLE	25-3	10 MAY 1995

25-00-00 GENERAL

In addition to the standard equipment, the aircraft may be fitted with a dry powder type fire extinguisher. This fire extinguisher is mounted to the top of the center console in the cabin.

25-10-00 SEAT

The seat is constructed in one piece from fiberglass with timber strengthening ribs. The safety harnesses are three-point aircraft harnesses and are attached directly to brackets provided on the fuselage.

25-10-01 REMOVAL AND INSTALLATION OF SEAT

To remove the fiberglass seat from the airframe, remove the seat cushion and then undo the self-tapping screws at the top of the back of the seat and at the front of the seat. The seat can now be removed from the aircraft. When installing the seat, ensure that the center seat belt buckles are fed through the center of the seat and that they are not twisted or tangled. The self-tapping screws may be re-used provided they are in good condition.

25-10-02 REMOVAL AND INSTALLATION OF CENTRE CONSOLE

Remove the fuel tap (single screw) then remove the two screws surrounding the fuel cock. Remove the two screws at each side of the center console and the two screws on the top. The center console may now be lifted away from the airframe in two pieces. When reinstalling the center console, ensure that the fuel cock placard plate is located correctly with the ON position at the most forward point. Also, check that no wires, cables, or hoses have been pinched during the installation.

CHAPTER 27

FLIGHT CONTROLS

CHAPTER 27 FLIGHT CONTROLS
TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
27-00-00	GENERAL	27-3	10 MAY 1995
27-00-01	DESCRIPTION AND OPERATION	27-3	10 MAY 1995
27-00-02	TROUBLESHOOTING	27-3	10 MAY 1995
27-00-03	STANDARD PROCEDURES	27-5	10 MAY 1995
27-05-00	CONTROL COLUMN ASSEMBLY	27-5	10 MAY 1995
27-05-01	REMOVAL OF CONTROL COLUMN	27-5	10 MAY 1995
27-05-02	INSPECTION AND ADJUSTMENT OF CONTROL COLUMN	27-6	10 MAY 1995
27-05-03	INSTALLATION OF CONTROL COLUMN	27-8	10 MAY 1995
27-10-00	AILERON CONTROLS	27-9	10 MAY 1995
27-10-01	REMOVAL OF AILERON CONTROLS	27-9	10 MAY 1995
27-10-02	INSPECTION AND ADJUSTMENT OF AILERON CONTROLS	27-9	10 MAY 1995
27-10-03	INSTALLATION OF AILERON CONTROLS	27-11	10 MAY 1995
27-10-04	RIGGING AND ADJUSTMENT	27-12	05 MAR 1997
27-20-00	RUDDER CONTROLS	27-14	10 MAY 1995
27-20-01	REMOVAL OF RUDDER PEDAL ASSEMBLY	27-14	10 MAY 1995
27-20-02	INSPECTION AND ADJUSTMENT OF RUDDER PEDAL ASSEMBLY	27-16	10 MAY 1995
27-20-03	INSTALLATION OF RUDDER PEDAL ASSEMBLY	27-16	10 MAY 1995
27-20-04	REMOVAL OF RUDDER CABLES	27-17	10 MAY 1995
27-20-05	INSPECTION OF RUDDER CABLES	27-17	10 MAY 1995
27-20-06	INSTALLATION OF RUDDER CABLES	27-17	10 MAY 1995
27-20-07	RIGGING AND ADJUSTMENT	27-19	10 MAY 1995
27-30-00	ELEVATOR CONTROLS	27-19	10 MAY 1995
27-30-01	REMOVAL OF ELEVATOR CONTROLS	27-19	05 MAR 1997
27-30-02	INSPECTION AND ADJUSTMENT OF ELEVATOR CONTROLS	27-21	10 MAY 1995
27-30-03	INSTALLATION OF ELEVATOR CONTROLS	27-21	10 MAY 1995
27-30-04	RIGGING AND ADJUSTMENT	27-22	10 MAY 1995
27-35-00	ELEVATOR TRIM SYSTEM	27-23	10 MAY 1995
27-35-01	REMOVAL OF TRIM SYSTEM	27-23	10 MAY 1995
27-35-02	INSTALLATION OF TRIM SYSTEM	27-23	10 MAY 1995
27-35-03	RIGGING AND ADJUSTMENT	27-23	10 MAY 1995
27-90-00	STALL WARNING SYSTEM	27-25	10 MAY 1995
27-90-01	REMOVAL OF STALL WARNING SYSTEM	27-25	10 MAY 1995
27-90-02	INSTALLATION OF STALL WARNING SYSTEM	27-25	10 MAY 1995
27-90-03	ADJUSTMENT OF STALL WARNING SYSTEM	27-25	10 MAY 1995

AMENDMENT 2: 05 MAR 1997

27-00-00 GENERAL

The aircraft is controlled in flight by the use of three standard primary control surfaces consisting of the ailerons, elevator, and rudder. Operation of these controls is through the movement of the dual control sticks and dual rudder pedals. The individual surfaces are connected to their control components by cables, push-pull, or torque tubes and bellcranks.

27-00-01 DESCRIPTION AND OPERATION

The aileron and elevator controls consist of two control sticks (dual control), located on the floor and between the legs of each occupant. These control sticks are linked to the control surfaces via a system of bellcranks, pushrods and rod ends. The aileron linkages are arranged in such a way as to allow the wings to fold without disconnecting the aileron controls.

The rudder is controlled by two cables which extend from the left pedal of the left side rudder pedals to the left rudder horn, and from the right pedal of the right-side rudder pedals to the right rudder horn. Both pairs of rudder pedals are able to operate the rudder left and right.

27-00-02 TROUBLESHOOTING

Troubles peculiar to the flight controls are listed in chart 2701 along with their probable causes and suggested remedies.

CHART 2701 TROUBLESHOOTING (SURFACE CONTROLS)

TROUBLE	CAUSE	REMEDY
Loss of motion between control stick and control surface	Failure of control component or incorrect assembly of control system	Inspect control system for failed component or incorrect assembly
Resistance to control input	Binding of control system bushing, control system fouling, lack of lubrication	Progressively disassemble control system to locate source of problem. Repair, replace or lubricate
Control sticks not synchronized	Failure or incorrect assembly of control column push rod assembly	Disassemble control column, replace faulty component and re-assemble

Incorrect aileron travel	Aileron limit stops worn or loosened	Re-adjust aileron limit stops and re-secure
Correct aileron travel cannot be obtained	Worn or damaged aileron control system	Adjust and/or replace aileron control components.
Control stick stops before control surface reaches full travel	Aileron and/or elevator pushrods out of adjustment or control system fouling	Re-adjust control system, inspect for control system fouling
Lost motion between rudder pedals and rudder	Component failure in rudder control system	Repair or replace failed component
Excessive resistance in rudder controls	Worn rudder cables, fairleads or bushes, lack of lubrication	Progressively disassemble rudder control system to locate fault. Repair, replace or lubricate.
Rudder pedals not at neutral when rudder is	Rudder cables not installed correctly or cable adjustment links uneven	Replace rudder cables or re-adjust rudder cable adjustment links
Incorrect rudder travel	Failure of rudder control component or binding of rudder cables	Replace faulty component, replace rudder cable fairleads.
Incorrect elevator travel	Failure of elevator control component, binding of control system, incorrect adjustment	Replace faulty component, lubricate control system, re-adjust control system.

27-05-00 CONTROL COLUMN ASSEMBLY**27-05-01 REMOVAL OF CONTROL COLUMN**

To remove the control column, the seat and center console must first be removed from the aircraft (refer to chapter 25). Disconnect the elevator push rod and aileron bellcrank at the rod ends and disconnect the push to talk switch cables at the base of the control sticks. Remove the two clamping bolts attaching the nylon control column bearing to the floor and the castellated nut and split pin on the pivot bolt at the opposite end of the control column. Refer Figure 2701. The control column assembly may now be removed from the aircraft.




Figure 2701

27-05-02 INSPECTION AND ADJUSTMENT OF CONTROL COLUMN

Begin with the base of the control sticks at the pivot point. Wear can be measured at this point by lightly moving the stick fwd and aft.




Figure 2702

Any wear will be noticeable by a degree of movement at the top of the control stick. Refer fig 2701. If this movement is more than 3mm, the pivot bolt should be tightened 1/6th of a turn and the wear measured again. This process is repeated until the movement at the top of the control stick is within limits. This check should be carried out on both control sticks. When completed, a check of aileron control friction should be carried out to ensure that an increase in friction has not developed. If an increase in friction is detected, the control stick pivot is worn beyond limits and should be replaced.

The control column pivot bolt on the right of the control column assembly and the nylon control column bearing are checked for wear by applying pressure to the control column in a fwd and aft fashion. If any movement is visible at the control column pivot bolt, this bolt should be tightened 1/6th of a turn until no visible movement exists.




Figure 2703

When completed, a check of elevator control friction should be carried out to ensure that an increase in friction has not developed. If so, the control column pivot floor mount is worn beyond its limits and should be replaced.

If movement is detected in the nylon control column bearing, this can be adjusted by sanding the mating surfaces of the top half of the bearing on a flat plate. Care must be taken to ensure that not too much material is removed causing elevator control system friction to increase. Refer fig

2703. The rod ends connected to the bottom of the control sticks are then checked for wear.

This is achieved by fixing the control surfaces to prevent movement, and then measuring the amount of free play on the top of the control stick in both a fwd and aft movement and side to side. If the free play is in excess of 5mm fwd and aft, or 10mm side to side, the control system should be disassembled for closer examination. Each rod end should be checked with a dial indicator for wear. If movement of the ball within the rod end is above 0.015 inches, the rod end must be replaced. Refer Fig 2704.




Figure 2704

27-05-03 INSTALLATION OF CONTROL COLUMN

To install the control column assembly, the removal procedures may be followed in reverse, paying particular attention to the following: -

- (1) When installing the castellated pivot bolt nut, apply only enough tension to minimize any play in the operation of the control column without creating friction.
- (2) Renew the split pin in the pivot bolt after adjustment.
- (3) Do not over tighten the two clamping bolts which pass through the nylon control column bearing.
Recommended torque = 10 inch/pounds, (1.77kg/cm).
- (4) After connecting control pushrods, check for full and free movement of elevator, ailerons and control sticks.
- (5) Check rigging of ailerons and elevator.

27-10-00 AILERON CONTROLS**27-10-01 REMOVAL OF AILERON CONTROLS**

To remove the aileron controls, the seat cushion and seat must first be removed from the aircraft (refer chapter 25). Remove the turtle deck and disconnect the forward aileron bellcrank at the control column. Remove the forward aileron bellcrank pivot belt, the mid aileron bellcrank pivot bolt, and the rear aileron bellcrank pivot bolt. Disconnect the aileron push pull rods at the ailerons and remove the aileron control assembly from the aircraft through the top of the fuselage where the turtle deck was removed. Refer Figure 2706.

27-10-02 INSPECTION AND ADJUSTMENT OF AILERON CONTROLS

The removable turtle deck is fitted with a nylon bearing which supports the inboard end of the aileron torque tube. This bearing must be examined for wear or damage frequently as it is subject to wear if the turtle deck is being removed frequently. Check the rivet on the lower bearing half for security and elongation of the rivet hole. Also check that there is no more than 1mm of play between the bearing and the aileron torque tube when the turtle deck is fitted correctly. If excessive play exists, the lower bearing should be removed and new bearing fitted. Refer Figure 2705. The aileron lower bellcrank is checked by moving each end of the bellcrank fwd and aft in a rocking motion. The movement is measured and should not exceed 6mm total. If the movement is in excess of this tolerance, the pivot bolt must be tightened 1/6th of a turn until the movement is within tolerance. When completed, a check of aileron control friction should be carried out to ensure that an increase in friction has not developed. If an increase in friction is detected, the pivot bushes or the aileron bellcrank must be replaced.




Figure 2705

27-10-03 INSTALLATION OF AILERON CONTROLS

When installing the aileron controls, the removal procedures may be followed in reverse, paying particular attention to the following:

- 1 . When installing any bolt which is subject to rotation (i.e., forward, mid and rear bellcrank pivot arms), tighten those bolts just enough to remove excessive play without creating unwanted friction.
- 2 . All bolts subject to rotation must be fitted with castellated nuts and new split pins.
- 3 Check that all push rods fitted with rod ends can be rotated through 10 degrees.
- 4 After re-installing the aileron control system, check for full and free movement of the control sticks and ailerons.
- 5 Check rigging of the aileron.




Figure 2706

27-10-04 RIGGING AND ADJUSTMENT

To check and/or adjust the rigging of the ailerons, an aileron rigging jig will be required. This is available from Skyfox Aviation or an authorized dealer, Part No ARG-010.

The aileron rigging jigs are placed on the under surface of the wings, on the fourth rib from the root which is just outboard of the jury strut attachment points. Refer Figure 2707. Set the control column so that the base of the joy sticks are vertical and check that the trailing edge of each aileron is adjacent to the neutral position on the rigging jigs. If an error exists where one aileron is high and the other is low, the mid aileron push pull rod must be adjusted in length until both ailerons are at neutral, or both ailerons are either high or low of the neutral mark on the rigging jigs, the length of the vertical aileron push/pull rods must be adjusted by adding or removing washers from the swivel link assembly until both ailerons are neutral. Refer Figure 2708.

The maximum deflection of the ailerons is then adjusted by use of the aileron stop screws on the control column at the base of the right joystick until the trailing edge of the ailerons are adjacent to the corresponding maximum deflection marks on the rigging jigs. Refer Figure 2703.

The aileron deflections are:
Up = $13^{\circ} \pm 1^{\circ}$
Down = $17^{\circ} \pm 1^{\circ}$




Figure 2707




Figure 2708




Figure 2709

27-20-00 RUDDER CONTROLS

27-20-01 REMOVAL OF REDDER PEDAL ASSEMBLY

Remove the top and bottom engine cowls and drain the braking system as described in Chapter 12 of this manual. Disconnect the brake lines from the master cylinders and the rudder cables from the rudder pedal assembly by disconnecting the "D" shackle at the end of the cable. Disconnect nose wheel steering linkages. Remove the eight retaining screws (four for each pedal assembly) and remove the rudder pedal assemblies from the aircraft. Refer Figure 2710.




Figure 2710

27-20-02 INSPECTION AND ADJUSTMENT OF RUDDER PEDAL ASSEMBLY

Ensure that full and free rudder movement is available through operation of the rudder pedals and that excessive friction is not present. The rudder pedal floor mounts are checked for security and wear. If more than 1mm wear is found between the rudder pedal bearings and the rudder pedal torque tube, the bearings must be replaced. Refer fig 2711.




Figure 2711

27-20-03 INSTALLATION OF RUDDER PEDAL ASSEMBLY

When installing the rudder pedal assembly, the removal procedures may be followed in reverse, paying particular attention to the following: -

1. When installing any bolt which is subject to rotation (i.e., "D" shackle which retains the rudder cable), tighten those bolts just enough to remove excessive play without creating unwanted friction.
2. All bolts subject to rotation must be fitted with castellated nuts and new split pins.
3. Check that both "D" shackles which retain the rudder cable can be rotated through 30 degrees.
4. After re-installing the rudder pedal assembly, check for full and free movement of the rudder control system.
5. Check rigging of the rudder.
6. The cable tension is "taut", i.e., no sag in cable, when rudder and nosewheel are straight.

27-20-04 REMOVAL OF RUDDER CABLES

- CAUTION -

THE REMOVAL OF THE RUDDER CABLES REQUIRES THAT THE CABLES MUST BE CUT AND ARE THEN NO LONGER USABLE. IT IS THEREFORE IMPORTANT THAT RUDDER CABLE REPLACEMENT IS ANTICIPATED BEFORE REMOVAL OF EXISTING CABLES IS ATTEMPTED.

Remove the top and bottom engine cowls, seat and turtle deck cover. Disconnect the rudder cables from the rudder pedal assembly and rudder control horn at the "D" shackles. Refer Figure 2706. Cut the rudder cables near the cable swage at either end of the cable and pull the cable from the aircraft.

27-20-05 INSPECTION OF RUDDER CABLES

The rudder control cables are checked for wear, damage, and security of the swages. If the fairleads in the fuselage, through which the rudder cables run, are found to be worn, they must be replaced. The shackles at each end of both rudder cables are checked for wear by removing the retaining bolt and checking for elongation in both the bolt and corresponding mounting hole. If any elongation is found, the worn parts must be replaced.

27-20-06 INSTALLATION OF RUDDER CABLES

Replacement rudder cables will be fitted with a thimble and swaged at one end when supplied. Pass the un-swaged end through the four fairleads along the inside of the fuselage so that the pre-swaged end is toward the rudder pedals and the cable is free of kinks, loops, or binding against the airframe. The un-swaged end is passed through the fabric covering at the rudder cable fairing located at station 2650mm. Connect the swaged end to the rudder pedal with the D-Shackle. Set both rudder pedals so that the toe brake pivot tubes are 558mm forward of the front seat cross member. This dimension is from the centerline of each tube. Set the rudder at neutral by aligning the top of the rudder with the overhanging vertical stabilizer. Pull the rudder cable around the thimble held by the D-Shackle until all slack is removed and the cable is "tight-by-hand" (do not let the rudder move). Mark the position on the cable to enable swaging after removal from the D-shackle. Swage the cable then assemble to the "D"-shackle link at the rudder control horn. The Cable tension is then controlled by the rudder return springs. Refer Fig 2712.

NOTE: Reference to CAO 108.41 and AC 43 is required to replace rudder cables.




Fig 2712

27-20-07 RIGGING AND ADJUSTMENT

To check the rigging of the rudder, place a protractor between the top of the rudder and the overhanging vertical stabilizer with the index in line with the centerline of the rudder hinges and the 90° mark in line with the axis of the overhanging vertical stabilizer. Operate the rudder pedals in both directions and check that there is 30° (+/-1°) of travel in both directions. Also check that the rudder control horn is contacting the rudder control stop when full rudder pedal deflection is applied.

If adjustment is required, metal must be added or removed from the rudder stop which operates against the rudder control horn. Metal is removed by grinding the mating surface of the rudder control stop and added by applying a bead of weld to the same surface and then dressing the weld until the correct deflection is obtained.

27-30-00 ELEVATOR CONTROLS**27-30-01 REMOVAL OF ELEVATOR CONTROLS**

To remove the elevator controls, the tailplane, rear inspection panels, seat cushion and seat must first be removed from the aircraft (refer Chapter 25). Remove the turtle deck and disconnect the forward elevator pushrod at the control column. Remove the elevator idler arm pivot bolt and disconnect the rear elevator push rod from the idler arm. Disconnect the rear elevator push rod from the elevator control horn and remove the elevator from the aircraft. Remove the forward elevator control assembly from the aircraft. The rear elevator push rod may only be removed after the push rod guide bush is dislodged to the rear from its locating sleeve. Once this is achieved the rear elevator push rod may be removed through the cavity left by the removal of the tailplane. Refer Figure 2713.





Figure 2713

27-30-02 INSPECTION AND ADJUSTMENT OF ELEVATOR CONTROLS**Figure 2714**

The yoke on the rear end of the elevator push rod is visible through the rear access panel and should be checked for wear in the same manner as the rod ends. Refer fig 2714.

The elevator idler arm is checked for wear by moving the bottom of the arm side to side. If movement is visible, the pivot bolt should be tightened 1/16 of a turn until no visible movement exists. When completed, a check of elevator control friction should be carried out to ensure that an increase in friction has not developed. If an increase in friction is evident, then the idler arm should be replaced.

27-30-03 INSTALLATION OF ELEVATOR CONTROLS

When installing the elevator controls, the removal procedures be followed in reverse, paying particular attention to the following:

1. When installing any bolt which is subject to rotation (i.e. elevator idler arm pivot bolt), tighten those bolts just enough to remove excessive play without creating unwanted friction.
2. All bolts subject to rotation must be fitted with castellated nuts and new split pins.
3. Check that the forward elevator push rod can be rotated through 10 degrees.
4. After re-installing the elevator control system, check for full and free movement of the control sticks and control column.
5. Check rigging of the elevator.

27-30-04 RIGGING AND ADJUSTMENT

To check the rigging of the elevator, use an inclinometer to measure the amount of deflection of the elevator in relation to the horizontal stabilizer. All control surface movements should be measured when the control surface is operated from the cockpit.

The elevator control limits are: UP = $39^{\circ} \pm 1^{\circ}$
DOWN = $21^{\circ} \pm 1^{\circ}$

If adjustment becomes necessary, the UP travel can be adjusted by adding or removing metal from the base of the elevator control horn where it contacts the fin post, and DOWN travel can be adjusted by adding or removing metal from the down elevator stop where it meets the elevator control horn. To remove metal, grind the elevator control horn or the elevator down stop until the required travel is obtained. To add metal, apply a bead of weld to the elevator control horn or elevator down stop and then dress those welds until the required travel is achieved. In both cases, the elevator must be removed to carry out the adjustment.

27-35-00 ELEVATOR TRIM SYSTEM

27-35-01 REMOVAL OF TRIM SYSTEM

To remove the elevator trim system, it is necessary to remove the seat, centre console and turtle deck first. Disconnect the forward elevator trim spring from the control column and disconnect the rear elevator idler arm. Remove the rod end from the rear elevator push rod and then remove the swaged trim cable fitting from the push rod. Remove the pivot bolt from the elevator trim handle, then the pivot bolt from the trim cable pulley located under the rear elevator push rod. The elevator trim system can now be removed from the aircraft. Refer Figure 2715.

27-35-02 INSTALLATION OF TRIM SYSTEM

When installing the elevator trim system, the removal procedures may be followed in reverse, paying particular attention to the following:

1. All bolts subject to rotation must be fitted with castellated nuts and new split pins.
2. After installing the elevator trim system, check for full and free movement of the control sticks, control column and trim lever.
3. Check rigging of the trim system.

27-35-03 RIGGING AND ADJUSTMENT

To check the adjustment of the forward trim spring, place the trim lever and control column in the full forward position. Loosen the Adel clamps securing the forward trim spring mounting plate and slide the plate aft until no tension is applied to the spring. Re-tighten the Adel clamps.

To check the adjustment of the trim, place the trim lever in the full aft position and control stick in full aft position, loosen the turnbuckle to its maximum and allow the control column to fall forward as far as it will go. Tighten the turnbuckle until the elevator attains an angle of 27° UP $\pm 1^{\circ}$ in relation to the horizontal stabilizer. Lock and safety wire the turnbuckle in this position.

The friction applied to the trim lever should be enough to hold in the full aft position while the control column is moved to full forward. Adjustment is achieved by tightening or loosening the trim lever pivot bolt and nut.

27-35-04 ELEVATOR TRIM INSPECTION

The inspection of the trim system is simply checking that all parts are functional and the operation is applicable to the correct rigging of the system.




Figure 2715

27-90-00 STALL WARNING SYSTEM

27-90-01 REMOVAL OF STALL WARNING SYSTEM

The stall warning pressure head is located on the left front jury strut and can be removed by disassembling the jury struts. The pressure tube which runs between the pressure head and the stall warning transducer is routed from the pressure head through the wing ribs, to the tip of the wing and then back down the rear wing spar to the cabin, and then across the head rack and down the left windscreen pillar to the stall warning transducer. The pitot tube is also connected to the stall warning transducer and follows the same route as the tube from the pressure head, except that it is connected at the outer end to the pitot head. These tubes should not be removed from the wing unless it is positively established that a leak or blockage has occurred in a section of the tube which is inaccessible. To remove the stall warning transducer, the top tube and pitot tube are then disconnected and the bolts retaining the stall warning transducer can be removed.

27-90-02 INSTALLATION OF STALL WARNING SYSTEM

When installing the stall warning system, the removal procedures may be followed in reverse, paying particular attention to the following:

1. Ensure that the pressure and pitot tubes are a firm fit over the connection nipples on the pressure transducer.
2. Check the pressure and pitot system for leaks after installation.
3. Check calibration of the stall warning system.

27-90-03 ADJUSTMENT OF STALL WARNING SYSTEM

The tube on the jury strut has been factory set e.g., the lower end of the tube is forward by one degree off 90° using the bottom of the leading edge and the bottom of the trailing edge as a datum.

As the wing gets to a particular angle of attack, air will start to flow through the tube, and the buzzer is activated through a transducer and solid-state circuitry.

The circuit is switched on by an air switch in the pitot line which is set to 35 knots. This is to stop the system from activating on the ground from wind gusts and propeller wash deflecting off the ground.

27-90-04 SETTING STALL WARNING POTENTIOMETER

- 1 . Using a flat screwdriver, turn the sensitivity on the air switch, located on the bottom of the stall warning control box, full clockwise. This will increase sensitivity.
- 2 . Using a Phillips head screwdriver, wind the pressure switch, located on the top of the stall warning control box, to the halfway position.
- 3 . Turn the stall warning test switch on the instrument panel to the ARM position.
- 4 . Connect a 60ml syringe to the pitot pressure head and depress the plunger until the airspeed indicator shows 35 knots. If the stall warning sounds, wind the pressure switch out until the alarm stops. Then wind the pressure switch in until the alarm sounds.
- 5 . Wind the air switch out until the alarm stops sounding and then wind it a further 1/8 of a turn out. The stall warning should now not sound with an indicated airspeed of less than 35 knots.
- 6 . Remove the syringe from the pitot pressure head.
- 7 . Move the stall warning test switch to the ON position and blow LIGHTLY into the stall warning pressure head. The alarm should NOT sound.
- 8 . If the stall warning alarm is constantly sounding in flight, wind the sensitivity on the air switch anti-clockwise by 1/8 of a turn.

NOTE: A flight test is recommended to check that the stall warning sounds between 5 Kts and 10 Kts above the indicated stall speed and as close to the lower limit of 5 Kts as possible to avoid gusts causing warnings on climb.

CHAPTER 28

AIRCRAFT FUEL SYSTEM

CHAPTER 28 AIRCRAFT FUEL SYSTEM

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
28-00-00			
28-00-01			
28-00-02	GENERAL	28-3	10 MAY 1995
28-10-00	DESCRIPTION	28-3	10 MAY 1995
28-10-01	TROUBLE SHOOTING	28-3	10 MAY 1995
28-10-02	STORAGE	28-4	10 MAY 1995
28-10-03	INSPECTION OF FUEL TANKS	28-4	10 MAY 1995
28-20-00	REPAIR OF FUEL TANKS	28-4/5	05 MAR 1997
28-20-01	INSPECTION OF COLLECTOR TANK	28-6	10 MAY 1995
28-20-02	DISTRIBUTION	28-6	10 MAY 1995
28-20-03	REMOVAL OF FUEL COCK	28-6	10 MAY 1995
28-20-04	INSPECTION OF FUEL COCK	28-6	10 MAY 1995
28-20-05	INSTALLATION OF FUEL COCK	28-6	10 MAY 1995
28-20-06	FUEL. FILTER BOWL AND SCREEN	28-6	10 MAY 1995
28-20-07	REMOVAL OF FUEL FILTER BOWL AND SCREEN	28-6	10 MAY 1995
28-20-08	INSTALLATION OF FUEL FILTER BOWL AND SCREEN	28-6	10 MAY 1995
28-20-09	CLEANING AND INSPECTION OF		
28-40-00	FILTER BOWL AND SCREEN	28-7	10 MAY 1995
28-40-01	REMOVAL OF ELECTRIC FUEL PUMP	28-7	10 MAY 1995
28-40-02	INSTALLATION OF ELECTRIC FUEL PUMP	28-7	10 MAY 1995
28-40-03	INDICATING	28-7	10 MAY 1995
28-40-04	FUEL QUANTITY INDICATORS	28-7	10 MAY 1995
28-40-05	REMOVAL OF FUEL QUANTITY INDICATORS	28-8	10 MAY 1995
	INSTALLATION OF FUEL QUANTITY INDICATORS	28-8	10 MAY 1995
	FUEL PRESSURE CHECK	28-8	10 MAY 1995
	FUEL SYSTEM - SCHEMATIC	28-10	10 MAY 1995

28-00-00 GENERAL**28-00-01 DESCRIPTION**

The fuel system components covered in this section consist of the fuel tanks, non-return valves, collector tank, fuel cock, fuel filter bowl and screen, electric fuel pump, fuel quantity indicators, and low fuel pressure warning light.

28-00-02 TROUBLESHOOTING

Troubles peculiar to the fuel system are listed in Chart 2801 along with their probable causes and suggested remedies.

CHART 2801 TROUBLESHOOTING (FUEL)

TROUBLE	CAUSE	REMEDY
FAILURE OF FUEL TO FLOW	Blocked fuel filters or faulty fuel pump or valves, vents blocked, fuel tap off. No fuel in aircraft.	Clean fuel filters, replace fuel pump or clean valves, Clean vents. Turn on tap. Refuel aircraft
FUEL PRESSURE LIGHT ILLUMINATES	Faulty fuel pump(s) or pressure switch	Repair or replace as necessary.
UNIDENTIFIED LEAKS	Perished fuel lines	Pressure test and/or replace as necessary Refer AC 43.
FUEL COCK LEAKS	Faulty "O" ring seals	Replace "O" rings

28-10-00 STORAGE

When storage for extended periods is anticipated, the fuel system should be drained completely at the following drain points:

- (1) Both drain valves located under the wing fuel tanks
- (2) Collector tank drain valve located under right side of the fuselage at the wing strut attachment point
- (3) At the gascolator drain valve located on the bottom right side of the firewall

When returning the aircraft to service, the fuel filters should be removed and cleaned before refueling the aircraft.

- NOTE -


ALWAYS CHECK FOR WATER CONTAMINATION OF THE FUEL SYSTEM AFTER EXTENDED STORAGE.

28-10-01 INSPECTION OF FUEL TANKS

Each main wing fuel tank can be inspected for obvious defects, foreign particles, and damage by inserting a mirror through the fuel tank filler and with the aid of a small light. An inspection hole is provided in the baffle within the fuel tank to facilitate inspection of the area beyond the baffle. Fuel leaks will be detected by fuel stains occurring along the bottom inboard section of the trailing edge of the wing. Fuel stains occurring around and behind the fuel filler neck indicate a faulty fuel cap gasket.

28-10-02 REPAIR OF FUEL TANKS

If the fuel tank is found to be leaking, the tank must be drained of fuel, the fuel lines and fittings removed, and the fuel tank removed from the wing by cutting the fabric around the top of the tank. The fabric is cut between the ribs and the tank on both sides of the tank, between the front of the tank and the leading-edge spar and along the front of the trailing edge of the wing. This need only be done on the top surface. Cut through the silicon adhesive around the tank using a sharp knife, taking care not to damage the wing spars. Drill the rivets from the rear fuel tank retaining bracket with a 3.3mm drill and remove the bracket. Lift the rear of the fuel tank away from the front spar. Refer fig 2801. Plug the fitting holes with blank threaded plugs, fill the tank with fuel and pressurize the tank to 2.5Psi (4 Kpa). Any leaks will soon become apparent and then marked for repair.



Drain the fuel from the tank and thoroughly wash the exterior surface with acetone. If the fuel leak is due to damage, identified by white strands of fiberglass matting, the affected area should be ground away and exterior surface sanded around the damaged area for a radius of 50mm, with 150 grit sandpaper to remove the gloss from the surface. If the fuel leak emanates from a pin hole type flaw in the tank wall, then the exterior surface need only be sanded for a radius of 25mm with the 150-grit sandpaper. Mix an appropriate amount of vinylester resin and catalyst and patch the hole with 10oz woven fiberglass matting.

If the fuel leak is emanating from around one of the fuel line fittings, the fiberglass material must be dug out from around the fitting using a 2-3mm rotary file with a die grinder or dremel tool, and the cavity refilled with a mixture of epoxy resin, hardener, and cotton flox mixed to a sloppy consistency. Allow to cure and then repeat the pressure test as above. Once satisfied that no more leaks exist, the fuel tank can be reinstalled into the wing. Clean off all remaining silicon and sikaflex with a scraper and coat the front and rear of the tank with petroleum jelly. Apply a bead of sikaflex to the front and rear of the tank where it contacts the spars and lay the tank into position ensuring that the tank is separated from the spar by approximately 2mm of sikaflex. Also, fill the spaces between the wing ribs and the fuel tank with sikaflex and allow to set overnight. Apply a small bead of sikaflex to the rear fuel tank retaining bracket where it contacts the fuel tank and refit using 4-4 aluminium pop rivets, then replace the fabric covering, and reconnect the fuel lines and fittings.

28-10-03 INSPECTION OF COLLECTOR TANK

The aluminum collector tank is sheathed in a fiberglass wrap which allows any leaked fuel to drain overboard via a drain tube from the bottom of the collector tank through the bottom of the fuselage. A visual inspection for fuel draining from the drain tube and the integrity of the collector tank is all that is required.

28-20-00 DISTRIBUTION**28-20-01 REMOVAL OF FUEL COCK**

To remove the fuel cock, drain both main fuel tanks and the collector tank and then remove the center console. Refer Chapter 25. The disconnection of the fuel lines from the fuel cock will allow the fuel cock to be removed from the aircraft.

28-20-02 INSPECTION OF FUEL COCK

By removing the screw from the center of the rotating shaft, the fuel cock handle may be pulled off the body, then the gland nut can be removed from the top of the cock to expose the inside.

28-20-03 INSTALLATION OF FUEL COCK

The installation procedures are the reverse of the removal procedures. After installation of the fuel cock, but before the installation of the center console, fill the fuel tanks with fuel and check for leaks. Ensure the fuel cock "ON-OFF" placard is facing with "OFF" at the aft (up) position.

28-20-04 FUEL FILTER BOWL AND SCREEN**28-20-05 REMOVAL OF FUEL FILTER BOWL AND SCREEN**

The fuel filter bowl and screen is located on the bottom right of the firewall in the gascolator. To remove the bowl, turn the fuel cock to "OFF" and cut the safety wire securing the knurled retaining nut and loosen until the wire clamp can be rotated clear of the bowl. The bowl can now be removed along with the filter screen.

28-20-06 INSTALLATION OF FUEL FILTER BOWL AND SCREEN

The installation procedures are the reverse of the removal procedures. After installation, turn the fuel cock "ON" and check for fuel leaks.

28-20-07 CLEANING AND INSPECTION OF FILTER BOWL AND SCREEN

Check the fuel filter bowl for cracks or deformity, clean with solvent such as fuel, and wipe with a clean rag. Check the filter screen for foreign particles entangled in the screen, wash with solvent such as fuel, and allow to dry.

28-20-08 REMOVAL OF ELECTRIC FUEL PUMP

The electric fuel pump is located to the right of the collector tank, behind the seat which must be removed. Refer Chapter 25. Drain both main fuel tanks and collector tank, then disconnect the two wires and fuel lines from the electric fuel pump. Remove the two bolts retaining the fuel pump. The pump is now able to be removed from the aircraft.

28-20-09 INSTALLATION OF ELECTRIC FUEL PUMP

The installation procedures are the reverse of the removal procedures but with the following extra requirements:

- (1) After installation, fill the fuel tanks and check for leaks.
- (2) Carry out an operational check of the electric fuel pump.
- (3) Carry out a fuel flow check at the carburetor with the electric fuel pump operating. Fuel flow should be a minimum of 30 liters per hour. See Para. 73-10-02 FUEL FLOW CHECKS

28-40-00 INDICATING**28-40-01 FUEL QUANTITY INDICATORS**

The fuel quantity indicators in the aircraft are transfers which are applied directly to the fuel tank. The fuel tank is transparent so that the fuel quantity can be determined by reading the fuel level in the tank directly against the fuel quantity transfer.

28-40-02 REMOVAL OF FUEL QUANTITY INDICATORS

Drain both fuel tanks at the drain valves under each tank but leave the collector tank full. Fold the wings on the aircraft back and secure them to the fin using the tow struts supplied. Disconnect the fuel and vent lines from the fuel tanks, then remove the clear cover from the root rib using a sharp knife to cut the silicon sealer around the cover. The fuel quantity indicators can now be peeled from the fuel tank.

28-40-03 INSTALLATION OF FUEL QUANTITY INDICATORS

Place the aircraft in the level position. Refer Chapter 8. Clamp the fuel lines and pour a measured 10 liters of fuel into the fuel tank. Mark the 10 ltr level mark on the tank. Fold the wings, then place the new fuel quantity indicator onto the tank with the 10-liter mark aligned with the previously marked position on the tank. To avoid air bubbles under the transfer, start applying the transfer from the center of the tank and work out using a wiping action. Drain the fuel tanks through the drain valves under each tank and then disconnect the fuel lines. Replace the clear cover over the root rib using silicon sealant, then replace the fuel lines, fill both fuel tanks and check for leaks. If no leaks are detected, the wings can be unfolded.

28-40-04 FUEL PRESSURE CHECK

The fuel pressure indicator consists of a low fuel pressure warning light on the instrument panel which is activated by an adjustable pressure switch in the fuel system between the two carburetors. If the engine has not been started for some time, an initial check can be made by simply turning the master switch "ON," at which time the low fuel pressure light should illuminate. If not, remove and empty the float bowl from one of the carburetors, which will relieve any stored pressure in the fuel system. Replace the carburetor fuel bowl, then by turning the electric fuel pump switch "ON", the low fuel pressure warning light should go out.

If these checks are not successful, carry out the following checks:

- (1) Check the electric fuel pump and instrument fuses.
- (2) Remove the bulb from the warning light and check its

integrity with a separate 12-volt power source.


Replace if necessary.

- (3) Place a calibrated pressure gauge in the fuel system at the "T" piece between the two carburetors. Turn "ON" the master switch and electric fuel pump and check for an increase in pressure to 27Kpa (4Psi). If this does not occur, the fuel pump is at fault.

cont...

- (4) Remove and empty the float bowl from one of the carburetors, which will relieve any stored pressure in the fuel system. Replace the carburetor fuel bowl, turn the master switch "ON," then turn the adjustment screw in the fuel pressure switch clockwise until the low fuel pressure light illuminates. Now turn the electric fuel pump "ON" and check that the low fuel pressure warning light goes out.
The pressure switch is now set.

28-40-05 FUEL SYSTEM – SCHEMATIC



CHAPTER 32

LANDING GEAR

CHAPTER 32 LANDING GEAR

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
32-00-00	GENERAL	32-3	10 MAY 1995
32-00-01	DESCRIPTION & OPERATION	32-3	10 MAY 1995
32-00-02	TROUBLE SHOOTING	32-3/4	05 MAR 1997
32-10-00	MAIN LANDING GEAR	32-5	10 MAY 1995
32-10-01	REMOVAL OF MAIN GEAR	32-5	10 MAY 1995
32-10-02	INSTALLATION OF MAIN GEAR	32-5	10 MAY 1995
32-10-03	INSPECTION OF MAIN GEAR	32-5	10 MAY 1995
32-40-00	WHEELS AND BRAKES	32-6	10 MAY 1995
32-40-01	REMOVAL OF WHEELS	32-6	10 MAY 1995
32-40-02	INSPECTION OF WHEELS	32-6	10 MAY 1995
32-40-03	INSTALLATION OF WHEELS	32-6	10 MAY 1995
32-40-04	REMOVAL OF TIRES & TUBES	32-6	05 MAR 1997
32-40-05	INSTALLATION OF TIRES & TUBES	32-7	10 MAY 1995
32-40-06	REMOVAL OF WHEEL BEARINGS	32-7	10 MAY 1995
32-40-07	INSTALLATION OF WHEEL BEARINGS	32-7	10 MAY 1995
32-40-08	REMOVAL OF BRAKE DISC & CALIPER	32-7	10 MAY 1995
32-40-09	REPLACING BRAKE PADS	32-8	10 MAY 1995
32-40-10	INSTALLATION OF BRAKE DISC & CALIPER	32-8	10 MAY 1995
32-40-11	REMOVAL OF BRAKE MASTER CYLINDERS	32-8	10 MAY 1995
32-40-12	INSTALLATION OF BRAKE MASTER CYLINDERS	32-8	10 MAY 1995
32-40-13	BRAKE BLEEDING PROCEDURE		10 MAY 1995
32-40-14	LEAK CHECK		10 MAY 1995
32-50-00	STEERING	32-8	10 MAY 1995
32-50-01	REMOVAL OF STEERING CONTROL	32-8	10 MAY 1995
32-50-02	INSTALLATION OF STEERING CONTROL	32-9	10 MAY 1995
32-70-00	NOSEWHEEL ASSEMBLY	32-9	10 MAY 1995
32-70-01	REMOVAL OF NOSEWHEEL ASSEMBLY	32-9	10 MAY 1995
32-70-02	CLEANING & INSPECTION OF NOSEWHEEL ASSEMBLY	32-9	05 MAR 1997
32-70-03	INSTALLATION OF NOSEWHEEL ASSEMBLY	32-9	10 MAY 1995

32-00-00 GENERAL

32-00-01 DESCRIPTION & OPERATION

The main landing gear is a tubular steel structure which is pivoted on the fuselage to allow both vertical and horizontal travel of the wheel. Suspension is provided by bonded rubber cross members between the top of one leg to the bottom of the other.

The brakes are dual, independent, disc brakes operated by toe pedals on both rudder pedal assemblies. The brakes can be activated by either occupant. The master cylinders have self-contained reservoirs and are mounted to the left side rudder pedals. High pressure PVC brake lines carry the brake fluid to the calipers which are mounted to the undercarriage leg at the axle. The brake discs are bolted to the wheel in a manner which allows the caliper to operate on the inside circumference of the disc.

The nose wheel assembly includes a steerable, nose wheel via a scissor link attached to a movable outer leg. The suspension is a column of 10×16 mm rubber discs. The outer leg is connected to the rudder pedals via steering springs through the firewall.

32-00-02 TROUBLE SHOOTING

Troubles peculiar to the landing gear are listed in Chart 3201 along with their probable causes and suggested remedies.

CHART 3201 TROUBLE SHOOTING (LANDING GEAR)

TROUBLE	CAUSE	REMEDY
AIRCRAFT SITS TO ONE SIDE ON FLAT GROUND.	Incorrect pressure in main tires. Bonded rubber may have delaminated or stretched.	Check tire pressure Replace bonded struts as required
BRAKES INEFFICIENT	Insufficient brake fluid, brake pads worn, leak in hydraulic system	Locate fault & rectify.
BRAKES LOCKED ON	Foreign object between brake disc & brake pad brake caliper jammed on backing plate.	Remove disc and caliper, clean & reassemble.
NO BRAKE PRESSURE AT PEDAL	Insufficient brake fluid, leak in hydraulic system, faulty master cylinder.	Check for brake fluid quantity, leaks and master cylinder operation.
BRAKES NOISY DURING OPERATION	Foreign object between brake disc & brake pad, worn brake pads, moisture in pad.	Remove disc and caliper, clean and re-assemble. check brake pads for wear.

32-10-00 MAIN LANDING GEAR

32-10-01 REMOVAL OF MAIN GEAR

Jack the aeroplane as described in Section 7 of this manual, drain the braking system and remove the wheel and brake assemblies. The olive on the wheel cylinder end of the brake line must be cut off at the olive to allow enough line to refit a new olive without replacing the brake line. Remove the seat from the aeroplane and pull the brake line up through the landing gear leg. Remove the shock strut pivot bolt at the axle of the gear in question. The landing gear can now be removed from the aeroplane.

32-10-02 INSTALLATION OF MAIN GEAR

Apply MIL-G-81322A General Purpose Grease to the pivot bushes on the main landing gear, and fit to the aeroplane making sure that the shock strut with the "pass through" structure is connected to the left hand gear and the rubber bonding is on the lower end of both shock struts. Route the brake line through the landing gear leg and refit the wheel and brake assembly. Fit a new olive to the brake line and attach to the wheel cylinder. Re-install the seat, refill the braking system with brake fluid (MIL-H-5606E) and test the brakes.

32-10-03 INSPECTION OF MAIN GEAR

The landing gear is checked for damage, corrosion and distortion at each service. Remove the fairings on the shock struts and check for delamination. Up to 15% delamination is acceptable. Corrosion will be identifiable by blistering paint and brown stains emanating from cracks in the paint. This may also indicate a fracture in the steel. If mild corrosion is found, the affected surface must be stripped of paint, cleaned and repainted.

If corrosion is severe, replace component.

To check for distortion, place a straight edge along each tube of the landing gear. If more than 1/8" gap between the straight edge and the tube is found, the landing gear should be repaired or replaced. Refer to Figure 3201.




Figure 3201

32-40-00 WHEELS AND BRAKES

32-40-01 REMOVAL OF WHEELS

Jack the aeroplane in accordance with the instructions given in Chapter 7 of this manual. Remove wheel pants if fitted. Remove the safety wire and alien head cap screws from the brake disc. Remove the dust cap from the wheel hub, remove the split pin from the axle and remove the 3/4" UNF wheel nut. The wheel can now be removed from the axle.

32-40-03 INSPECTION OF WHEELS

Check the wheels for dents and buckles by jacking the aeroplane in accordance with Chapter 7, spinning the wheel by hand and sighting the bead of the wheel. If a dent or buckle is visible, a dial indicator must be set to the wheel to measure the extent of the deformation. If the deformation exceeds 1/8" the wheel must be replaced. Replace the bearings if signs of skidding or pitting are visible. Pack bearings with MIL-G-81322A General Purpose Grease and reassemble.

32-40-03 INSTALLATION OF MAIN WHEELS

To install the main wheels, the installation procedures may be followed in reverse, paying particular attention to the following:

- (1) Grease main wheel bearings with grease specified in Chapter 12 of this manual.
- (2) Adjust the 3/4" UNF axle nut until no play exists and there is no unnecessary friction when rotating the wheel.
- (3) Fit a new split pin through the castellations on the wheel nut and the wheel axle.
- (4) Ensure that the three socket head cap screws which hold the disc to the wheel are securely safety wired.

32-40-04 REMOVAL OF TIRES AND TUBES

The wheel assembly used on the aircraft is a Matco, part No. W600 assembly, which is of the split rim type.

TIRE MAIN CHENG SHIN or DELI 15×6.00 – 6

TIRE NOSE CHENG SHIN or DELI 15×5.00 – 6

To change the tire, remove the wheel assembly from the aeroplane and remove the valve from the tube. Undo the three bolts holding the two wheel halves together which allows the wheel halves to be removed from the tire.

32-40-05 INSTALLATION OF TIRES & TUBES

Fit the tube into the replacement tire and inflate the tube until it fills the shape of the tire. Fit the two wheel halves to the replacement tire, ensuring that the valve stem is located in- the notch in the wheel and that the tube is not pinched between, the wheel halves. Replace the three bolts and tighten to 50 In/Lbs.

Inflate the tire to the correct pressure as stated in Chapter 12 and check for leaks. The wheel may now be refitted to the aeroplane.

32-40-06 REMOVAL OF WHEEL BEARINGS

Place the wheel down on a flat surface and prize the seal from the wheel hub using a screwdriver or similar. The tapered roller bearing can now be removed from the wheel hub. Repeat this procedure with the other side of the wheel. To remove the outer shell of the bearing use a large pin punch and a small hammer to tap the bottom bearing shell from the hub. Ensure that the bearing remains true in the hub during this procedure by tapping one side of the bearing and then the other.

32-40-07 INSTALLATION OF WHEEL BEARINGS

To install the bearings, the removal procedures may be followed in reverse, paying particular attention to the following:

- (1) Ensure that the outer shell of the bearing is fully seated in the wheel hub.
- (2) Apply grease to the tapered roller bearing before installation. Refer Chapter 12 of this manual.

32-40-08 REMOVAL OF BRAKE DISC & CALIPER

Remove the wheel from the aircraft as described in this chapter. Drain the brake fluid and disconnect the brake line from the caliper and remove the four bolts and nuts which secure the caliper backing plate to the landing gear. The caliper and disc may now be removed from the landing gear.

32-40-09 REPLACING BRAKE PADS

Remove the brake pads from the calipers. Drill out the rivets which hold the brake pads to the aluminum brake pad mounting plate with a 1/8" drill and discard the old brake pad. Attach the replacement brake pad, #RA66-56, using 105-2 rivets. Reassemble the caliper assembly and refit the brake disc and wheel. Bleed the brake system as described in this chapter and replace the tie wire on the brake calipers.

32-40-10 INSTALLATION OF BRAKE DISC & CALIPER

To install the brake disc and calipers, the removal procedures may be followed in reverse. Refill the braking system after installation and check for leaks.

32-40-11 REMOVAL OF BRAKE MASTER CYLINDERS

Remove the top engine cowling, drain the brake fluid and disconnect the brake lines from the brake master cylinders. Remove the two split pins, nuts and bolts which allow the master cylinders to be removed from the aircraft.

32-40-12 INSTALLATION OF BRAKE MASTER CYLINDERS

The installation procedures are the reverse of the removal procedures. Refill the braking system after installation and check for leaks.

32-40-14 LEAK CHECK

Apply maximum braking pressure to the toe brakes and check for leaking fluid. If a leak is detected, trace the leak and repair or replace as necessary.

32-50-00 STEERING

The steering is achieved by linking the steerable nose wheel to the rudder pedals via springs through the firewall to the steering arm on the nose leg.

32-50-01 REMOVAL OF STEERING CONTROL

Remove the fire protection boots from the steering springs. Disconnect the springs from the rudder pedals and steering arm. The nose wheel is free to caster as required.

32-50-02 INSTALLATION OF STEERING CONTROL

The installation procedures are the reverse of the removal procedures. Carry out a functional check after installation.

32-70-00 NOSEWHEEL ASSEMBLY

32-70-01 REMOVAL OF NOSEWHEEL ASSEMBLY

Lower the tail of the aircraft down to the ground on the tail skid. Attach a weight to the tail lift handle so as to prevent the nose falling. Complete access is now available to the nose wheel assembly.

Remove the split pin at the top of the outer leg to enable the removal of the "inner leg safety pin". Remove the center bolt in the steering scissor link. With the "inner safety pin" removed and the scissor bolt removed, the inner leg can be taken out downwards. The inner leg comprises of a fork, scissor links, wheel and tire, rubber suspension discs and spat if fitted.

The rest of the nose leg assembly is attached to the aircraft by three bolts. Two bolts at the end of each stay at the fuselage connection points, and one center bolt inside the leg at the top. The center bolt can be accessed by inserting an extension socket spanner, 1/2" NF, up inside the tube to hold the bolt head whilst removing the 1/2" metal lock nut on the top of the leg. The complete nose wheel assembly can now be removed from the aircraft.

32-70-02 CLEANING AND INSPECTION OF NOSEWHEEL ASSEMBLY

A check of the rubber suspension discs may be required if the nose leg extension is less than 50mm. (Aircraft should be level and empty) If the discs are worn or broken then they all must be replaced.

The correct number of discs to be inserted is 10.

32-70-03 INSTALLATION OF NOSEWHEEL ASSEMBLY

The installation procedures are the reverse of the removal procedures. Carry out a functional check after installation.

NOTE: The bush at the top of the leg is a "stepped bush" for alignment purposes. The large part of the bush must be facing downwards.

Skyfox
Aviation

MAINTENANCE MANUAL

CA-25N
GAZELLE

CHAPTER 33

LIGHTS

CHAPTER 33 LIGHTSTABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
33-00-00	GENERAL	33-3	10 MAY 1995
33-00-01	DESCRIPTION AND OPERATION	33-3	05 MAR 1997
33-00-02	TROUBLE SHOOTING	33-4	10 MAY 1995
33-40-00	STROBE LIGHTS	33-5	05 MAR 1997
33-40-01	REMOVAL OF STROBE LIGHTS	33-5	05 MAR 1997
33-40-02	INSTALLATION OF STROBE LIGHTS	33-5	10 MAY 1995
33-40-03	REMOVAL OF POWER SUPPLY	33-5	05 MAR 1997
33-40-04	INSTALLATION OF POWER SUPPLY	33-5	10 MAY 1995
33-40-05	RECOGNITION LIGHT	33-6	05 MAR 1997
33-40-06	REMOVAL OF RECOGNITION LIGHT BULB	33-6	05 MAR 1997
33-40-07	INSTALLATION OF RECOGNITION LIGHT BULB	33-6	10 MAY 1995

33-00-00 GENERAL

The lighting system components covered in this section consist of strobe lights and a recognition light. These lights are optional equipment and, as such, they may not be fitted to all aircraft.

33-00-01 DESCRIPTION AND OPERATION

The strobe lights used are manufactured by Whelan and are installed in accordance with the manufacturer's recommendations. Aircraft may be fitted with two strobe lights, one on each wing tip. The power supplies are located inside each wing tip. The strobe lights are activated by a toggle switch mounted on the instrument panel.

The recognition light is mounted on the nose leg (in the front of the lower engine cowling in earlier models) and is activated by a toggle switch mounted on the instrument panel.

33-00-02 TROUBLE SHOOTING

Troubles peculiar to the lighting system are listed in Chart 3301 along with their probable causes and suggested remedies.

CHART 3301 TROUBLE SHOOTING (LIGHTING SYSTEM)

TROUBLE	CAUSE	REMEDY
STROBE(S) DO NOT ILLUMINATE	Interruption of power to power supply or strobe lights, faulty power supply or strobe lights.	Check strobe fuse connections, output of power supply, integrity of strobe lights.
IRREGULAR FLASHING STROBE(S)	Low supply current to power supply, faulty power supply.	Check current to power supply.
RECOGNITION LIGHT DOES NOT ILLUMINATE	Interruption of power to switch or light, faulty globe.	Check current to light, integrity of globe.
DIM RECOGNITION LIGHT	Low current supply to switch or globe, resistance in earth line.	Check current to light, resistance in earth line.
GLOBE BLOWS OFTEN	Excessive current to light.	Check output of voltage regulator.

33-40-00 STROBE LIGHTS

All strobe lights fitted to the Gazelle are of the same type, so. removal and installation instructions are identical.

33-40-01 REMOVAL OF STROBE LIGHTS

Ensure that the strobe toggle switch and master switch are in the "OFF" position. Remove the two screws at the base of the strobe light and withdraw the light assembly from the wing tip until the connector plug and socket are through the mounting hole. Disconnect the power lead and remove strobe light.

33-40-02 INSTALLATION-OF STROBE LIGHTS

The installation procedures are the reverse of the removal procedures. Carry out a functional check after installation.

33-40-03 REMOVAL OF POWER SUPPLY

Ensure that the strobe toggle switch and the master switch are in the "OFF" position. Remove the wing tips and disconnect the power and output leads from the strobe light power supply located on the outboard wing rib. Remove the mounting screws which attach the power supply to the wing rib and remove the power supply from the aircraft.

33-40-04 INSTALLATION OF POWER SUPPLY

The installation procedures are the reverse of the removal procedures. Carry out a functional check after installation.

33-40-05 RECOGNITION LIGHT**33-40-06 REMOVAL OF RECOGNITION LIGHT GLOBE**

Ensure that the recognition light toggle switch and master switch are in the "OFF" position.

On nose leg installations, remove screw from housing clamp then separate assembly. Remove globe retaining screw and disconnect wire. Remove globe.

On engine cowling installations remove the top and bottom engine, cowlings, remove the three clamping screws which hold the light in place. Remove the light globe from the cowling.

33-40-07 INSTALLATION OF RECOGNITION LIGHT GLOBE

The installation procedures are the reverse of the removal procedures. Carry out a functional check after installation.

Skyfox

MAINTENANCE MANUAL

CA-25N

Aviation

GAZELLE

CHAPTER 34

NAVIGATION AND PITOT STATIC

CHAPTER 34 NAVIGATION AND PITOT STATIC

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
34-00-00	GENERAL	34-3	10 MAY 1995
34-00-01	REMOVAL AND INSTALLATION OF FACE MOUNTED INSTRUMENTS	34-3	10 MAY 1995
34-10-00	FLIGHT	34-4	10 MAY 1995
34-10-01	PITOT STATIC SYSTEM	34-4	05 MAR 1997
34-10-02	TESTING OF PITOT STATIC SYSTEM	34-4	10 MAY 1995
34-10-06	ALTIMETER	34-6	10 MAY 1995
34-10-07	ALTIMETER CALIBRATION CHECK	34-7	05 MAR 1997
34-10-08	AIRSPEED INDICATOR	34-8	10 MAY 1995
34-10-09	AIRSPEED INDICATOR CALIBRATION CHECK	34-8	10 MAY 1995
34-10-10	VERTICAL SPEED INDICATOR	34-9	10 MAY 1995
34-20-00	GYRO HORIZON	34-10	10 MAY 1995
34-20-02	DIRECTIONAL GYRO	34-11	10 MAY 1995
34-20-04	GYRO TURN CO-ORDINATOR	34-12	10 MAY 1995
34-20-06	MAGNETIC COMPASS	34-13	01 MAR 1996
34-20-07	CALIBRATION OF MAGNETIC COMPASS	34-13	01 MAR 1996

34-00-00 GENERAL**34-00-01 REMOVAL AND INSTALLATION OF FACE MOUNTED INSTRUMENTS**

Removal of the top engine cowl allows access to the rear of the instrument panel where any static or pitot lines or electrical cables should be disconnected from the instrument to be removed. All instruments are fixed to the instrument panel via three or four screws which are accessible from the cockpit side of the panel. Remove these screws which are accessible from the cockpit side of the panel. Remove these screws and the instrument may be taken out of the aircraft.

When replacing instruments, take particular care not to cross thread the mounting screws, and be sure to use brass or aluminum screws or those provided by the instrument manufacturer. Carry out a functional check of the instruments. Refer Figure 3401.




Figure 3401

34-10-00 FLIGHT**34-10-01 PITOT STATIC SYSTEM**

The pitot system consists of a pressure head located under the left wing, just outboard of the wing strut attachment point. Air pressure is transferred from here to the pressure sensitive instruments via a clear plastic tube which is routed from the pressure head, through the wing ribs to the wing tip and then through the rear wing spar to the cabin. The airspeed indicator and stall warning device are both fed by the pitot line. There is a drain fitted into the pitot line behind the instrument panel for draining accumulated condensation. Refer Figure 3402.

The static system consists of two static vents, one located on each side of the fuselage at station 2170mm. A clear plastic tube is routed from the two static vents to the "T" piece and the up to the top of the head rack and then down to behind the instrument panel. The airspeed indicator, altimeter and vertical speed indicator are all fed by the static line. There is a drain fitted into the static line behind the instrument panel for draining accumulated condensation. Refer Figure 3402.

34-10-02 TESTING OF PITOT STATIC SYSTEM

The pitot system shall be tested for leaks by applying a pressure at the pitot head sufficient to cause the airspeed indicator to read 100 knots. There should be no sign of restrictions in the piping during application of the pressure and no decrease in the reading when the system is sealed for at least 10 seconds.

- CAUTION -

Do not allow a negative pressure to occur, as this may damage the airspeed indicator.

- END -

The static system shall be tested for leaks by applying sufficient suction to the system to cause the airspeed indicator to read 85 knots. The system shall then be sealed. The reading of the airspeed should not decrease by more than 4 knots within 10 seconds.




Figure 3402

34-10-06 ALTIMETER

The altimeter indicates pressure altitude in feet above sea level. The indicator has three pointers and a dial scale, the long pointer is read in hundreds of feet, the middle pointer in thousands of feet, and the short pointer in ten thousands of feet. A barometric pressure window is located on the right side of the indicator dial and is set by the knob located on the lower left corner of the instrument. The altimeter consists of a sealed diaphragm that "is connected to the pointer through a mechanical linkage. The instrument case is vented to the static air system and as static air pressure decreases, the diaphragm expands, causing the pointers to move through the mechanical linkage.

Troubles peculiar to the altimeter are listed in Chart 3401 along with their probable causes and suggested remedies.

CHART 3401 TROUBLE SHOOTING (ALTIMETER)

TROUBLE	CAUSE	REMEDY
EXCESSIVE SCALE ERROR	Improper calibration adjustment.	Recalibrate instrument.
EXCESSIVE POINTER OSCILLATION	Defective mechanism.	Replace altimeter.
ALTIMETER STICKS ON ONE ALTITUDE	Water or restriction in static air line.	Clear the static air line of water or obstructions.
ALTIMETER READING' CHANGES DURING BANKING	Water in static air line.	Clear the static air line of water, or obstructions.
ALTIMETER REQUIRES RESETTING FREQUENTLY	Temperature compensator inoperative.	Replace altimeter.
ALTIMETER READS HIGH OR LOW	Improper venting.	Check static air system for leaks, instrument case for cracks.

Cont...

ALTIMETER REQUIRES RESETTING FREQUENTLY	Temperature compensator inoperative.	Replace altimeter.
ALTIMETER READS HIGH OR LOW	Improper venting.	Check static air system for leaks, instrument case for cracks.
SETTING KNOB IS HARD TO TURN	Wrong lubricant used in altimeter.	Have instrument serviced.
INNER REFERENCE FAILS TO MOVE	Out of engagement.	Replace altimeter.

34-10-07 ALTIMETER CALIBRATION CHECK

The altimeter shall be tested for diaphragm errors against an appropriate test instrument from sea level to maximum operating height of altimeter or to 21,000 feet. Errors shall not exceed +/- 100 feet.

34-10-08 AIRSPEED INDICATOR

The airspeed indicator provides a means of indicating the speed of the aircraft passing through the air. The airspeed indication is the differential pressure reading between the pitot air pressure and the static air pressure. This instrument has a diaphragm vented to the pitot air source and the case is vented to the static air system. As the aircraft increases speed, the pitot air pressure increases causing the diaphragm to expand. A mechanical linkage picks up the motion and moves the instrument pointer to the indicated speed. The instrument dial is calibrated in knots and also has the necessary operating range markings for safe operation of the aircraft.

Troubles peculiar to the airspeed indicator are listed in Chart 3402 along with their probable causes and suggested remedies.

CHART 3402 TROUBLE SHOOTING (AIRSPEED INDICATOR)

TROUBLE	CAUSE	REMEDY
POINTERS OF STATIC INSTRUMENTS DO NOT INDICATE PROPERLY	Leak in instrument case or line.	Trace leak and repair or replace.
POINTER OSCILLATES	Defective mechanism.	Replace instrument.
ASI READS HIGH	Pointer not on 0, leaking static.	Reset to 0, repair leak.
AS I READS LOW	Pointer not on 0, leaking static, pitot head not aligned.	Reset to 0, repair leak, align pitot.
AIRSPEED CHANGES DURING BANKING	Water in pitot or static line.	Drain water.

34-10-09 AIRSPEED INDICATOR CALIBRATION CHECK

Airspeed indicators shall be tested against an appropriate test instrument. The scale errors at the major graduations of the scale shall not exceed +/- 4 knots up to 95 knots, when tested first with the pressure increasing and then with the pressure decreasing. Operation shall be smooth and continuous.

The calibration error in Skyfox aircraft is approx 2.5 knots throughout the entire range. CAS is 2.5 knots higher than IAS.

34-10-10 VERTICAL SPEED INDICATOR

The vertical speed indicator measures the rate of change in static pressure when the aircraft is climbing or descending. By means of a pointer and dial, this instrument will indicate the rate of ascent or descent of the aircraft in feet per minute. But due to the lag of the instrument, the aircraft will be climbing--or descending before the instrument starts to read and the instrument will continue to read after the aircraft has assumed level flight. In rough air this should not be considered a malfunction.

Troubles peculiar to the vertical speed indicator are listed in Chart 3403 along with their probable causes and suggested remedies.

CHART 3403 TROUBLE SHOOTING (VERTICAL SPEED INDICATOR)

TROUBLE	CAUSE	REMEDY
POINTER DOES NOT SET ON 0	Ageing of diaphragm.	Reset pointer.
POINTER FAILS TO RESPOND	Blocked static system.	Remove blockage.
POINTER OSCILLATES	Leak in static system.	Repair leak.
RATE OF CLIMB INDICATES WHEN AIRCRAFT IS BANKED	Water in static line.	Drain water.
POINTER CANNOT BE RESET TO 0	Diaphragm distorted.	Replace instrument.
READS VERY LOW DURING CLIMB OR DESCENT	Broken case.	Replace instrument.

34-20-00 GYRO HORIZON

The gyro horizon is essentially an electrically driven gyroscope rotating in a horizontal plane and is operated by the same principal as the directional gyro. Due to the gyroscopic inertia, the spin axis continues to point in a vertical direction, providing a constant visual reference to the attitude of the aircraft relative to the pitch and roll axis. A bar across the face of the indicator represents the horizon and aligning the miniature aircraft to the horizon bar simulates the alignment of the aircraft to the actual horizon. Any deviation simulates the deviation of the aircraft from the true horizon. The gyro horizon is marked for different degrees of bank.

For trouble shooting, refer to Chart 3404.

CHART 3404 TROUBLE SHOOTING (GYRO HORIZON)

TROUBLE	CAUSE	REMEDY
BAR FAILS TO RESPOND	Insufficient power.	Check instrument fuses, system voltage.
BAR OSCILLATES OR SHIMMIES	Instrument loose in panel or defective.	Check security of instrument, replace instrument.
INSTRUMENT DOES NOT INDICATE LEVEL FLIGHT	Instrument not level in panel, aircraft out of trim.	Check level of instrument, trim of aircraft.
BAR HIGH AFTER 180 DEG TURN	Normal if within 1/16".	Replace instrument if error is greater than 1/16".
INSTRUMENT TUMBLES IN FLIGHT	Insufficient power.	Check instrument fuses, system voltage.
BAR DOES NOT SETTLE	Insufficient power, defective instrument.	Check instrument fuses, system voltage.

34-20-02 DIRECTIONAL GYRO

The directional gyro is a flight instrument incorporating an electrically driven gyro stabilized in the vertical plane, due to gyroscopic inertia, the spin axis continues to point in the same direction even though the aircraft yaws to the right or left. This relative motion between the gyro and the instrument case is shown on the instrument dial which is similar to a compass card. The dial, when set to agree with the aircraft magnetic compass, provides a positive indication free swing and turning error. However, the directional gyro has no sense of direction and must be set to the magnetic compass. Since the magnetic compass is subject to errors due to magnetic fields, electrical instruments, etc, the directional gyro is only accurate for the heading it has been set for. If the gyro is set on 270 deg, for instance, and the aircraft is turned to some other heading, there can be a large error between the directional gyro and the magnetic compass due to the error in compass compensation, this will appear as gyro precession. The gyro should only be checked in the heading it was first set, also due to internal friction, spin axis error. For trouble shooting, refer to Chart 3405.

CHART 3405 TROUBLE SHOOTING (DIRECTIONAL GYRO)

TROUBLE	CAUSE	REMEDY
EXCESSIVE DRIFT	Setting error, defective instrument, insufficient power.	Reset instrument, replace instrument, check instrument fuses and system voltage.
DIAL SPINS DURING TURNS	Limits of 55 deg of gimbal exceeded.	Replace instrument.
DIAL SPINS CONTINUOUSLY	Defective instrument.	Replace instrument.

34-20-04 GYRO TURN CO-ORDINATOR

The turn co-ordinator is an electric instrument. The turn portion of the indicator is driven by a permanent magnet, DC governor controlled gyro motor. Dampening action is provided by a precision air dashpot. The indicator is designed to indicate the rate, of turn and roll, which means if the aircraft is turned right and left rapidly, the indicator will move, indicating a turn, but if the aircraft is held in a bank by applying rudder, the indicator will come back to zero indicating no turn. The slip/skid portion of the indicator is a ball sealed in a curved glass tube filled with dampening fluid. In an improperly coordinated turn the ball is forced from the center of the tube, thus indicating attitude error. For trouble shooting, refer to Chart 3406.

CHART 3406 TROUBLE SHOOTING (TURN CO-ORDINATOR)

TROUBLE	CAUSE	REMEDY
POINTER FAILS TO RESPOND	Foreign matter in mechanism	Replace instrument.
INCORRECT SENSITIVITY	Out of calibration	Recalibrate instrument.
INCORRECT TURN RATE	Out of calibration, aircraft not coordinated	Recalibrate instrument, check aircraft attitude.
INSTRUMENT WILL NOT RUN	No power, malfunction in instrument	Check instrument fuses, system voltage, replace instrument.

34-20-06 MAGNETIC COMPASS

The magnetic compass is a self contained instrument. The compass correction card is located in the correction card holder mounted on the instrument. The compass should be swung whenever instruments or radios are changed and at once every 3 years.

34-20-07 CALIBRATION OF MAGNETIC COMPASS

NOTE: Refer AC 43.13 and CAO 108.6 for details.

When a magnetic direction indicator does not provide satisfactory directional indications, it can be adjusted by the "ground swinging" technique to compensate for errors.

The ground swinging technique is as follows:

- (a) Move the aircraft to a location free from influence of steel structures, underground pipes and cables, reinforced concrete, or other aircraft.
- (b) Place the aircraft in a level flying position.
- (c) Check indicator for fluid level and cleanliness. If fluid is required, the compass is defective.
- (d) Reset the fixed compensating magnets to neutral positions.
- (e) Check the pivot friction of the indicator by deflecting the card with a small magnet. The card should rotate freely in a horizontal plane.
- (f) Align the aircraft with the north magnet heading and compensate with compensating magnets. Repeat for the east magnet heading. Then place on south and west magnetic headings and remove half of the indicated error by adjusting the compensators. The engine should be running and all normal flight electrical services on.
- (g) Turn the aircraft on successive 30 deg headings through 360 deg. Prepare a correct card to show the correction to be applied at each of these headings. When significant errors are introduced by operation of electrical equipment or systems, the correction card should also be marked at each 30 deg heading showing the correction to be applied when such equipment or systems are turned on or energized.

Skyfox

MAINTENANCE MANUAL

CA-25N

Aviation

GAZELLE

CHAPTER 39

ELECTRICAL

AMENDMENT 0: 10 MAY 1995

Page 39-1

CHAPTER 39 ELECTRICAL**TABLE OF CONTENTS/EFFECTIVITY**

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
39-00-00	GENERAL	39-3	05 MAR 1997
39-40-00	ELECTRICAL SWITCHES, FUSES AND CIRCUIT BREAKERS	39-3	10 MAY 1995
39-40-01	REMOVAL OF ELECTRICAL SWITCHES	39-3	10 MAY 1995
39-40-02	INSTALLATION OF ELECTRICAL SWITCHES	39-3	10 MAY 1995
39-40-03	REMOVAL OF CIRCUIT BREAKERS	39-3	10 MAY 1995
39-40-04	INSTALLATION OF CIRCUIT BREAKERS	39-3	10 MAY 1995
39-40-05	REMOVAL OF FUSES	39-4	10 MAY 1995
39-40-06	INSTALLATION OF FUSES	39-4	10 MAY 1995
39-40-07	REMOVAL OF OIL PRESSURE SENSOR	39-4	10 MAY 1995
39-40-08	INSTALLATION OF OIL PRESSURE SENSOR	39-4	10 MAY 1995
39-40-09	REMOVAL OF FUEL PRESSURE SWITCH	39-5	10 MAY 1995
39-40-10	INSTALLATION OF FUEL PRESSURE SWITCH	39-5	10 MAY 1995

39-00-00 GENERAL

All Skyfox, CA20 series aircraft, first registered in Australia are fitted with fuses except where customers have specifically requested circuit breakers.

The switches are of the toggle type and are mounted on the lower part of the instrument panel. The circuit breakers (if fitted) are single hole mounting, push button type with manual reset. They must be reset by the pilot whenever tripped. They are located on the lower right part of the instrument panel. The fuses are square hole mounted, twin spade connector type and must be replaced by the pilot when blown. The fuses are mounted in the same location as the circuit breakers.

NOTE: Ensure that the battery is disconnected before working on the electrical system if it is likely that live wires may be grounded.

39-40-00 ELECTRICAL SWITCHES, FUSES AND CIRCUIT BREAKERS

39-40-01 REMOVAL OF ELECTRICAL SWITCHES

Remove the top engine cowl. Disconnect the two wires from the back of the switch, undo the mounting nut from the front of the switch and remove the switch from the aircraft. Locate disconnected wires to facilitate installation.

39-40-02 INSTALLATION OF ELECTRICAL SWITCHES

Locate switch in panel and install mounting nut, ensuring that the orientation of the ON OFF positions is correct. (Closed circuit is when the toggle switch is pointing to the same end as the terminals). Reconnect the wire cables to the switch and check operation. UP is usually ON in Skyfox, CA20 series aircraft.

39-40-03 REMOVAL OF CIRCUIT BREAKERS

Remove the top engine cowl. Disconnect the two wires from the back of the circuit breaker, undo the mounting nut from the front of the circuit breaker and remove the circuit breaker from the aircraft. Locate disconnected wires to facilitate installation.

39-40-04 INSTALLATION OF CIRCUIT BREAKERS

Locate circuit breaker in panel and install mounting nut, ensuring that the operating current is correct. Reconnect the wire cables to the circuit breaker and check operation.

39-40-05 REMOVAL OF FUSES

Simply pull on the coloured portion of the fuse until it dislodges from the fuse holder.

39-40-06 INSTALLATION OF FUSES

Check that the fuse rating of the replacement fuse is of the correct rating and type. Locate the fuse in the fuse holder and push until the fuse is firmly held by the fuse holder. Check the operation of the circuit for which the replaced fuse controls.

- NOTE -

Replacement fuses are located in the map pocket located over the shoulder of the pilot. Ensure that there are sufficient spare fuses of all ratings used to replace each and every fuse.

39-40-07 REMOVAL OF OIL PRESSURE SENSOR

The oil pressure sensor is located at the front, right hand side of the engine. Disconnect the wire cable from the sensor and, using a 17mm open ended spanner, remove the sensor from the "T" adapter.

39-40-08 INSTALLATION OF OIL PRESSURE SENSOR

Check that the replacement sensor is of the correct rating (supplied by Rotax). Use a small amount of PVC thread sealing tape on the sensor before installation. Reconnect the wire cable and test the pressure gauge.

39-40-09 REMOVAL OF FUEL PRESSURE SWITCH

Ensure that the master and fuel pump switches are turned OFF. Remove the top engine cowling and disconnect the fuel pressure switch wire cables. Remove the pressure switch using a 24mm open ended spanner.

39-40-10 INSTALLATION OF FUEL PRESSURE SWITCH

Ensure that the replacement switch is of the correct rating and type (ie. normally closed). Clean the threaded end of the switch and apply a small amount of PVC thread tape before installation. Reconnect the wire cables and carry out a fuel pressure warning light calibration in accordance with Chapter 28.

Skyfox

MAINTENANCE MANUAL

CA-25N

Aviation

GAZELLE

CHAPTER 51

STRUCTURES GENERAL

AMENDMENT 0: 10 MAY 1995

Page 51-1

CHAPTER 51 STRUCTURES GENERAL
TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	DATE	EFFECTIVITY
51-00-00	GENERAL	51-3	10 MAY 1995
51-00-01	DESCRIPTION	51-3	10 MAY 1995
51-10-00	STRUCTURAL REPAIRS	51-3	10 MAY 1995
51-10-01	RE-OILING FUSELAGE TUBES	51-3	10 MAY 1995
51-10-02	FABRIC REPAIRS	51-5	05 MAR 1997
51-10-03	MATERIALS FOR SMALL REPAIRS	51-6	05 MAR 1997

51-00-00 GENERAL

51-00-01 DESCRIPTION

The fuselage is constructed of 4130 steel tube of various diameters and wall thicknesses. The whole assembly is welded together using the MIG and TIG process. Each wing contains two aluminium spars of tubular extrusion with internal vertical web. The front spar forms the leading edge of the wing. The wing ribs are constructed from aircraft grade plywood. The trailing edge is aluminium angle section and is bonded to each rib. Both wings are fitted with fibreglass 26 litre fuel tanks which are located between the first and second rib at the wing root. The elevator, tail plane and rudder are all constructed from 4130 steel tube. The aircraft frame is covered with synthetic polyfibre fabric, then primed and painted. The engine cowls are two piece and of fibreglass construction with a fire retardant additive added to the resin.

51-10-00 STRUCTURAL REPAIRS

The fuselage, being a steel tubular structure, is relatively easily repaired providing the damage is not too extensive. Skyfox Aviation should be consulted for repair of damage to the fuselage structure itself, and for all repairs, reference must be made to FAA publications, "Acceptable Methods A/C 43.13-1A".

51-10-01 RE-OILING FUSELAGE TUBES

Use a 3/32" drill to remove the 10 rivets for oiling the fuselage tubes. Using a syringe, and a mixture of 50% fisholene and 50% linseed oil or Ensis Fluid, inject 100ml of mixture into each of the 10 tubes. Using a compressed air spray gun, spray sufficient mixture through both of the head rack tubes to give an even and full coverage to the inside of the tubes. Reseal the 10 oiling points with 3-4, aluminium pop rivets sealed with non-corrosive, oil resistant sealant. Change the attitude of the aircraft to sufficiently distribute the oil. Refer Figure 5101.




Figure 5101

51-10-03 FABRIC REPAIRS

Very small holes (up to 5mm Diameter) in fabric surfaces may be repaired, when the backside is accessible, by installing a small patch on the backside of the fabric with Poly-Tak.

A soldering iron, or other hot tool, may be used to trim and smooth any jagged edges of the hole before the patch is applied.... The coating buildup is then carefully applied only inside the hole with a small brush, sanded smooth and the finish coat applied.

Holes up to 8" in diameter may be patched by first trimming the hole to a uniform round, elliptical, square, or rectangular shape and crease 1/4" of the edge to the inside to avoid a sharp interface line showing around the edge. Mask-the repair area to prevent damage to the adjacent surface, then sand with 280 grit wet or dry sandpaper. Clean off the sanding residue then wipe with M.E.K.

The fabric patch is sized to allow a minimum 2" overlap around the edge and bonded in place with Poly-Tak Fabric Cement.

A patch cut to a square or rectangular shape will look more finished than a round patch cut to fit exactly to the contour of a round or elliptical hole, and will be easier to trim with finishing tape.

After the Poly-Tak cement has dried a minimum of 15 minutes, smooth the patch edges with an iron at 225 degrees C., then use the iron at a 350 degrees final temperature to heat taut the patch. Radiant heat from the iron surface held close over the edge will thermosoften and release the Poly-Tak bond, therefore a patch overlap area must be protected with a cardboard ring heat barrier taped in place during the heat shrinking operation.

Installing a finishing tape centered on the edge of a small patch is optional, except on wing top surfaces.

Patches to cover damage over 8" diameter will overlap the old fabric surface a minimum 2" on all sides. A 2" finishing tape will be installed with Poly-brush centering on the edge of the patch on all sides.

Seal the repair area with Poly-brush fabric sealant. At least two coats are to be brushed or sprayed on to the repair area.

Spray or brush two coats of Poly-spray on to the repair area. Allow to dry for approx, six hours, lightly sand, then paint.

51-10-03 MATERIALS FOR SMALL REPAIRS

The following materials may be needed for small repairs to the fabric, fibreglass, windows or structure. All these materials are available from Skyfox Aviation.

Fabric	Stits
	<div style="border: 1px solid black; padding: 5px; text-align: center;"> POLY-FIBER ACFT. P-106 F.A.A. P.M.A. 94 x 94 Threads 1.7 oz./sq.yd. Over 70 lbs./in. </div>
Fibre glass	Mat (woven) Resin / Fire retardant
Lexan	1.5 mm clear sheet 3.0 mm tinted sheet
Acrylic	2.0 mm clear moulded
Steel	Chrome / Molybdenum steel tubing (various sizes)

CHAPTER 52

DOORS

CHAPTER 52 DOORS**TABLE OF CONTENTS/EFFECTIVITY**

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
52-00-00	GENERAL	52-3	10 MAY 1995
52-10-00	PASSENGER CREW	52-3	10 MAY 1995
52-10-01	REMOVAL OF DOORS	52-3	10 MAY 1995
52-10-02	INSTALLATION OF DOORS	52-3	10 MAY 1995
52-10-03	REMOVAL OF DOOR LATCH	52-3	10 MAY 1995
52-10-04	INSTALLATION OF DOOR LATCH	52-3	10 MAY 1995
52-10-05	ADJUSTMENT OF DOORS	52-4	10 MAY 1995

52-00-00 GENERAL

This aircraft has two doors. One on each side of the cockpit. Each door has an individual main latching mechanism and holder device to hold the door full open.

52-10-00 PASSENGER CREW

52-10-01 REMOVAL OF DOORS

Unlatch the doors and remove the piano hinge pin from the top of the door by pulling the pin forward. Ensure that the door is supported during this operation to prevent it from falling from the aircraft when the hinge pin is removed.

52-10-02 INSTALLATION OF DOORS

Ensure the doors are unlatched, align the piano hinge at the top of the door with the piano hinge at the top of the door opening of the fuselage. Insert the hinge pin into the piano hinge from the front. Check that the doors operate freely.

52-10-03 REMOVAL OF DOOR LATCH

Remove the door from the aircraft as described in this chapter. Using a 3mm pin punch, remove the roll pin from the external door handle and remove the handle. Using a 1/2" open ended spanner, remove the retaining nut from between the internal door handle mounting plate and the door skin. The internal door handle and the two locking pins can now be removed.

52-10-04 INSTALLATION OF DOOR LATCH

Locate the four spacers and lexan rub washer on the internal door handle shaft and fit to the door and using a 1/2" open ended spanner, fit the retaining nut onto the door handle shaft between the internal door handle mounting plate and the door skin. Before tightening the retaining nut, locate the locking pins into the door pin guides and internal door handle, then tighten the retaining nut until a small amount of friction is present when turning the door handle. Locate the external door handle onto the internal door handle shaft and fit the roll pin. Ensure that the internal handle operates in a downward arc and the external handle operates in an upward swinging arc.

52-10-05 ADJUSTMENT OF DOORS

To rectify small gaps which may be present between the doors and the fuselage, the doors may be bent slightly where required. The recommended procedure is to re-shape the door starting from the top and working down the door. Only small adjustments can be made in this way, (3/16" or 5mm), and always check the door locking mechanism for operation after any adjustment. Where it is not possible to achieve a good fit, the gap may be filled by applying an extra layer of foam sealing tape.

CHAPTER 55

STABILIZERS

CHAPTER 55 STABILIZERS

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
55-00-00	GENERAL	55-3	10 MAY 1995
55-00-01	ELEVATOR AND RUDDER HINGE BUSH REPLACEMENT	55-3	10 MAY 1995
55-10-00	HORIZONTAL STABILIZER	55-4	10 MAY 1995
55-10-01	REMOVAL OF HORIZONTAL STABILIZER	55-4	10 MAY 1995
55-10-02	INSTALLATION OF HORIZONTAL STABILIZER	55-4	10 MAY 1995
55-20-00	ELEVATOR	55-5	10 MAY 1995
55-20-01	REMOVAL OF ELEVATOR	55-5	10 MAY 1995
55-20-02	INSTALLATION OF ELEVATOR	55-6	10 MAY 1995
55-30-00	FIN	55-6	10 MAY 1995
55-40-00	RUDDER	55-6	10 MAY 1995
55-40-01	REMOVAL OF RUDDER	55-6	10 MAY 1995
55-40-02	INSTALLATION OF RUDDER	55-6	10 MAY 1995

55-00-00 GENERAL

The elevator, horizontal stabilizer, fin and rudder are all constructed from 4130 steel tube and welded using the MIG process. The elevator and tail plane contain four plywood intercostal ribs each which are bonded to the steel tube. The hinges are formed by 4130 steel tube welded to the structure and sleeved with Teflon tube.

55-00-01 ELEVATOR AND RUDDER HINGE BUSH REPLACEMENT

The elevator and rudder hinges are checked for excessive wear by applying fwd and aft pressure to the elevator/rudder and watching closely for displacement between the elevator/rudder hinge tubes and the tail plane/fin hinge tubes. If any displacement is detected, the teflon bushes in the hinge tubes must be replaced. Remove the old bushes with a 7mm pin punch. Cut the replacement bush material into 20mm lengths with a sharp knife and remove sharp edges from both ends. Insert the replacement bush until the bush protrudes from both ends of the hinge tube. Trim the bush flush with the hinge tube. A 3/16" bolt (slightly longer than the bush) inserted into the bush, enables the bush to be inserted into the hinge, using a hammer. Refer Figure 5501.




Figure 5501

55-10-00 HORIZONTAL STABILIZER

55-10-01 REMOVAL OF HORIZONTAL STABILIZER

Remove the inspection panels from beneath the horizontal stabilizer and drill the 3/32" rivets from the fin fairing above the horizontal stabilizer. Refer fig 5502. Remove the hinge pins, from the elevator and stabilizer and disconnect the stabilizer struts at the outboard end. Remove the two stabilizer locating bolts at the center, top and remove the stabilizer from the aircraft. Take note of the number and location of washers used on the stabilizer locating bolts as they vary between aircraft.




Figure 5502

55-10-02 INSTALLATION OF HORIZONTAL STABILIZER

The removal procedures may be followed in reverse paying particular attention to the following:

- (a) When installing the stabilizer locating bolts, ensure that the washers are fitted in the same position from which they were removed. There should be no strain placed on the stabilizer when the bolts are tightened.
- (b) Use new split pins in the elevator hinge pins.
- (c) After installation, check elevator rigging. Refer chapter 27.

55-20-00 ELEVATOR**55-20-01 REMOVAL OF ELEVATOR**

FIRST remove the horizontal stabilizer as shown in this chapter. Disconnect the elevator control horn from the elevator push rod and remove the elevator from the aircraft. Refer fig 5503.




Figure 5503

55-20-02 INSTALLATION OF ELEVATOR

The removal procedures may be followed in reverse paying particular attention to the following:

- (a) When installing the stabilizer locating bolts, ensure that the washers are fitted in the same position from which they were removed. There should be no strain placed on the stabilizer when the bolts are tightened.
- (b) Use new split pins in the elevator hinge pins.
- (c) After installation, check elevator rigging. Refer Chapter 27.

55-30-00 FIN

The fin is a steel tube structure and is an integral part of the fuselage. Removal of the fin is not possible and no other servicing procedures apply.

55-40-00 RUDDER**55-40-01 REMOVAL OF RUDDER**

Disconnect the rudder cables from the rudder as described in Chapter 27. Remove the rudder hinge pins starting at the bottom first. The rudder can now be removed from the aircraft.

55-40-02 INSTALLATION OF RUDDER

The removal procedures may be followed in reverse paying particular attention to the following:

- (a) Use new split pins in the rudder hinge pins.
- (b) After installation, check rudder rigging. Refer Chapter 27.

CHAPTER 56

WINDOWS

CHAPTER 56 WINDOWS**TABLE OF CONTENTS/EFFECTIVITY**

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
56-00-00	GENERAL	56-3	10 MAY 1995
56-10-00	FLIGHT COMPARTMENT	56-3	10 MAY 1995
56-10-01	REMOVAL AND INSTALLATION OF WINDSCREEN	56-3	10 MAY 1995
56-10-02	REMOVAL AND INSTALLATION OF SKYLIGHT	56-3	10 MAY 1995
56-10-03	REMOVAL AND INSTALLATION OF DOOR WINDOWS	56-3	10 MAY 1995
56-10-04	REMOVAL AND INSTALLATION OF QUARTER WINDOWS	56-4	10 MAY 1995
56-10-05	REMOVAL AND INSTALLATION OF TURTLE DECK WINDOWS	56-4	10 MAY 1995

56-00-00 GENERAL

All windows are made from lexan sheet which is cold formed when it is fitted to the aircraft. Care must be taken to minimize stresses in the lexan during installation.

56-10-00 FLIGHT COMPARTMENT**56-10-01 REMOVAL AND INSTALLATION OF WINDSCREEN**

The windscreen in the CA-25N is molded acrylic plastic.

To remove the windscreen, remove the top engine cowling, and remove screws from upper retaining strip and vertical windscreen trims. Remove windscreen.

Place new windscreen in position, with upper cowling fitted, lightly clamping with upper retaining strip and small spring clamps on vertical tubes. Fit windscreen in place installing vertical windscreen trims and upper retaining strips.

For aircraft S/N CA25N019 and below, when a new windscreen is required and ordered from Skyfox Aviation, side retaining fittings will be sent with the windscreen. This new system enables the molded windscreen to be installed without drilling holes through the plastic.

56-10-02 REMOVAL AND INSTALLATION OF SKYLIGHT

Remove screws from upper retaining strip, drill out rivets from butt ribs and trailing edge of skylight. Remove skylight and use as a template on a piece of 3mm tinted lexan for shape and rivet layout. Rivet skylight in position using CHERRY 73 ASL 4-6 rivets with fibre washers. Trim excess from butt ribs with an angle grinder fitted with a sanding disc. Refit retaining strip.

56-10-03 REMOVAL AND INSTALLATION OF DOOR WINDOWS

Remove the door and door handles as described in chapter 52 of this manual. Drill the rivets along the door trim strips to allow removal of the lexan.

Lay the old window over the new and mark and drill the holes.

Refit the window to the door using CHERRY 73AS4-3 rivets.

Refit the door to the aircraft.

56-10-04 REMOVAL AND INSTALLATION OF QUARTER WINDOWS

Drill out all the rivets holding the lexan quarter window with a 3.3mm drill. Replace the lexan window and drill rivet holes into the new window using the window frame as a template.

Two different types of rivets are used.

Rivet the window into place with CHERRY 72AS4-2 rivets (Flush Rivets) along the top edge where the turtle deck overlaps the window frame and CHERRY 73AS4-2 rivets for all others.

56-10-05 REMOVAL AND INSTALLATION OF TURTLE DECK WINDOWS

Drill out all the rivets holding the lexan windows with a 3.3mm drill. Remove the lexan window and drill rivet holes into the new window using the old window as a template. Rivet the window into place with CHERRY 73AS4-2 rivets.

NOTE: All holes drilled in lexan for riveting purposes, must be enlarged to at least 1 1/2 times the diameter of the rivet to allow for thermal expansion.

Skyfox
Aviation

MAINTENANCE MANUAL

CA-25N
GAZELLE

CHAPTER 57

WINGS

CHAPTER 57 WINGS**TABLE OF CONTENTS/EFFECTIVITY**

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
57-10-00	MAIN FRAME	57-3	10 MAY 1995
57-10-01	REMOVAL AND INSTALLATION OF WINGS	57-3	10 MAY 1995
57-10-02	REPAIR OF WING STRUT ATTACHMENT	57-4	10 MAY 1995
57-10-03	REMOVAL AND INSTALLATION OF WING TIPS	57-4	10 MAY 1995
57-10-04	REMOVAL AND INSTALLATION OF AILERONS	57-5	10 MAY 1995
57-10-05	AILERON BALANCING	57-5	10 MAY 1995
57-10-06	BALANCING PROCEDURE	57-5	10 MAY 1995

57-10-00 MAIN FRAME

Each wing contains two spars of tubular extrusion with internal vertical web. The front spar forms the leading edge of the wing and is attached to the fuselage head rack at the root end by a clevis pin. The rear spar is stationed approximately 60% of the chord and is attached to the fuselage at the root end by a 5/16" bolt and also acts as a pivot when the wings are folded. Wing strut attachment brackets of 4130 steel are riveted and glued to both spars.

The wing ribs are constructed from, aircraft grade plywood and have a plywood cap strip stapled and glued to the top and bottom of the rib. Each wing has five ribs which have aileron hinge mounts extending from the trailing edge. The other five ribs in each wing have lightening holes and do not extend past the trailing edge. The wing ribs are attached to the front spar using a hand formed aluminium angle (Shear Clips) which is riveted and bonded to both spar and rib. The wing ribs are bonded to the rear spar, however a shear clip is used on the root rib only. The trailing edge is aluminium angle section and is bonded to each rib.

Four aluminium diagonal braces are riveted and bonded to both front and rear spars and form a "zigzag" between both spars. Where a diagonal brace passes through a rib, the two parts are bonded together. The first and second diagonal braces are attached via a steel doubler plate to the spar.

The left wing contains an aluminium pitot tube and a stall warning tube which is extended through to the fuselage via two separate plastic tubes. Both wings are fitted with fibreglass 26 litre fuel tanks which are located between the first and second rib at the wing root.

57-10-01 REMOVAL AND INSTALLATION OF WINGS

Drain all fuel from the aircraft as per chapter 28 and disconnect the fuel feed and vent lines from the wing to be removed. Disconnect the pitot and stall warning pressure tubes at the headrack. Disconnect strobe light cables (if fitted) at the wing entry point cut any nylon ties which locate the cables and tubes. Place the aircraft in a level attitude and place supports under the wing tips. Remove the turtle deck and disconnect the ailerons. Remove the bottom wing strut attachment bolt, front spar wing pin, and then the rear spar bolt allowing the wing and strut assembly to be removed.

NOTE: - THE WING AND FUSELAGE MAY BECOME UNSTABLE DURING THIS PROCEDURE SO ASSISTANCE IS RECOMMENDED. USE ONE OTHER PERSON TO HOLD THE OTHER WING TIP TO SUPPORT THE AIRCRAFT.


(Cont..)

Place the wing on the ground in a vertical position with the leading edge down. Remove the two jury strut attachment bolts and the two wing strut attachment bolts from the wing and remove the wing strut assembly.

When installing the wings, fit the main strut to each wing. 2×6.5mm bushes on the leading edge and one 6.5mm bush and one black bush at rear spar. Fit wings to fuselage with 1/4" pins or screwdrivers to locate everything temporarily, ensuring that the wing tip is well supported. Fit strut bolts then rear spar bolt then front spar pins. Fit jury struts and pitot plumbing. Connect ailerons. Fold wings back checking for possible interference to fuel lines. Connect fuel lines and strobe wiring. Place the plug for strobe wire inside black foam tube (handitube). Connect the ailerons as described in this chapter. Check that ailerons work freely and correct travel. Refer chapter 27. Carry out a dual inspection on all safety and split pins. Fuel up tanks and check for leak at wing connection. Carry out pitot leak check and check calibration of stall warning system. Refer chapter 27.

57-10-02 REPAIR OF WING STRUT ATTACHMENT

If excessive wear is detected in the bottom wing strut attachment fitting, a repair may be carried out as follows. Support the wing tip while the bottom wing strut attachment bolt is removed. Drill and ream the fuselage wing strut attachment point and the bottom wing strut attachment to 1/2" and fit replacement bush, part no WI-10 into hole. Refit the bottom wing strut attachment bolt. Refer fig 5701.



57-10-03 REMOVAL AND INSTALLATION OF WING TIPS

Drill out rivets, using 1/8" drill bit. Drive out rivet tails if necessary and then remove wing tip.

Re-install using 1/8" rivets.

NOTE: If rivet holes become enlarged through miss-use, then use larger size rivet.

57-10-04 REMOVAL AND INSTALLATION OF AILERONS

Remove the turtle deck and disconnect the aileron control horns from the vertical aileron push/pull rods as shown in figure 5702. Remove the two hinge retaining bolts from each of the five hinges leaving the center hinge until last, then remove the aileron from the aircraft.




Figure 5702

The installation procedures are the reverse of the removal procedures. Check rigging of ailerons and use new split pins or bolts subject to rotation.

57-10-05 AILERON BALANCING

The static balance of the ailerons is vitally important as unbalanced ailerons may cause control surface flutter which may have catastrophic results. The ailerons should be balanced each time a repair or modification is carried out, or when paint is added or removed.

57-10-06 BALANCING PROCEDURE

With the ailerons removed from the aircraft, place a straight edge under the second and fourth hinge points so that the aileron may pivot on the hinges. The bottom surface of the ailerons should be level, ($\pm 2^\circ$). If not, hollow out either end of the aileron profile and insert lead shot (or small pieces of lead) until balance is achieved.

The total weight of the lead being applied should not exceed 200 grams, (7 ounces).

CHAPTER 61

PROPELLER

CHAPTER 61 PROPELLER

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
61-00-00	GENERAL	61-3	05 MAR 1997
61-00-01	REMOVAL OF PROPELLER	61-3	10 MAY 1995
61-00-02	CLEANING, INSPECTION AND REPAIR	61-3	10 MAY 1995
61-00-03	INSTALLATION OF PROPELLER	61-3	10 MAY 1995
61-00-04	CHECKING AND ADJUSTING BLADE TRACKING	61-3	05 MAR 1997

61-00-00 GENERAL

The propeller fitted, by Skyfox Aviation is a fixed pitch wooden propeller. Reference should be made to the propeller manufacturers instruction manual when removing, installing or repairing the propeller. Also refer AD107/PFP/1 (Wooden Propellers – Inspection).

61-00-01 REMOVAL OF PROPELLER

Remove the ten screws which hold the spinner cone to the back plate. Take note of which way the spinner was removed so that it will can be installed in the same position. Cut the safety wires from the propeller bolts and remove the bolts and propeller in accordance with the propeller owner instruction manual.

61-00-02 CLEANING, INSPECTION AND REPAIR

Refer to propeller owners instruction manual for cleaning, inspection and repair of the propeller. FAA publication AC43.13- 1A may be used as a reference for acceptable repair methods.

61-00-03 INSTALLATION OF PROPELLER

Install the propeller in accordance with the propeller owners instruction manual. Ensure that the propeller bolts are safety wired correctly. Replace the spinner in the same position that it was removed, (ie. not rotated 180°), and tighten the ten screws which hold the spinner in place. The Skyfox Aviation factory recommended torque for the propeller bolts is 60 inch pounds.

61-00-04 CHECKING AND ADJUSTING BLADE TRACKING

Place a straight edge from the left main landing gear strut and clamp it into position so that the end of the straight edge is near the tip of the propeller. (Approximately 3mm, 1/8" clearance). Turn the propeller by hand, to check that both blades pass the straight edge with the same clearance. (Max. 3mm difference).

If adjustment of tracking is required further torque appropriate bolts to maximum of 70 inch pounds.

CAUTION: Check that the Ignition Switches are OFF before turning the propeller.

Skyfox
Aviation

MAINTENANCE MANUAL

CA-25N
GAZELLE

CHAPTER 71

POWERPLANT

Skyfox

MAINTENANCE MANUAL

CA-25N

Aviation

GAZELLE

CHAPTER 71 POWERPLANT

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
71-00-00	GENERAL DESCRIPTION	71-3	10 MAY 1995
71-00-01	TROUBLE SHOOTING	71-3	10 MAY 1995
71-00-02	REMOVAL OF ENGINE	71-4	10 MAY 1995
71-00-03	INSTALLATION OF ENGINE	71-5	10 MAY 1995
71-10-00	ENGINE COWLS	71-6	05 MAR 1997
71-10-01	REMOVAL OF ENGINE COWLS	71-6	05 MAR 1997
71-10-02	CLEANING AND INSPECTION	71-6	10 MAY 1995
71-10-03	INSTALLATION OF ENGINE COWLS	71-6	10 MAY 1995

71-00-00 GENERAL DESCRIPTION

The Rotax 912A engine is manufactured in Austria and certificated to the Joint Aviation Requirements – 22H standard. A brief description of the engine is as follows:

4-stroke, 4-cylinder horizontally opposed, spark ignition engine, one central camshaft – pushrods – OHV.

Liquid cooled cylinder heads – ram air cooled cylinders.

Dry tank forced lubrication.

Dual breakerless, capacitor discharge ignition.

Prop drive via reduction gear with integrated shock absorber and overload protection.

Integrated AC generator.

Electric starter.

Mechanical fuel pump.

71-00-01 TROUBLE SHOOTING

For trouble shooting of the engine and its accessories, refer to the engine manufacturers operators manual. See list of vendor publications in this manual.

71-00-02 REMOVAL OF ENGINE

- (1) Remove the engine cowls, (refer this chapter), and propeller, (refer chapter 61).
- (2) Disconnect battery – negative terminal and turn off fuel at fuel cock.
- (3) Disconnect the muffler supporting strap from muffler. Disconnect retaining springs, (exhaust pipes to mufflers) and remove muffler. Remove both rear exhaust pipes from the engine.
- (4) Drain coolant, (refer chapter 12), and disconnect the lower radiator hose at the water pump.
- (5) Disconnect the top radiator hose and coolant overflow hose from expansion tank.
- (6) Disconnect fuel line from gascolator at the engine driven fuel pump.
- (7) Disconnect sensor wires from sensors. (Oil temperature sensor, oil pressure sensor, oil pressure switch, fuel pressure switch, cylinder head temperature sensor).
- (8) Disconnect ignition switch wires from ignition coils if the coils are to be removed.

- CAUTION -

THE IGNITION IS NOW LIVE. IT IS RECOMMENDED TO DISCONNECT THE COILS BY USING THE QUICK RELEASE CONNECTORS IN THE LEAD TO THE ENGINE.

- (9) Disconnect the plugs to the ignition coils at the firewall.
- (10) Disconnect generator wires at the voltage rectifier /regulator. These are marked with the symbol "G" on the voltage rectifier/regulator.
- (11) Disconnect the tachometer sensor wires from the engine. The connector is located on the right hand side of the engine near the coolant radiator. Remove any nylon ties which hold the wires to the engine mount.
- (12) Carburettors are best removed from the engine at the manifold and left attached to the aircraft with the throttle and starting carburettor cables still intact.
- (13) Disconnect the carburettor air induction hoses at the airfilter box. The tubes can remain attached to the engine mount.
- (14) Disconnect the cabin heat scat hose from the heat exchanger on the right, front exhaust.
- (15) Disconnect the carburettor heat control cable from the air filter box and remove the cable clamp to free the control cable.
- (16) Disconnect the power cable from the starter motor. Disconnect the earth lead from number three cylinder head.
- (17) Disconnect the oil line from the oil pump at the front of the engine, and the oil return line at the banjo fitting on the bottom of the crankcase.
- (18) Support the engine with a suitable crane or jack at the propeller flange and the engine mount cross tube located above the flywheel. Remove the four mounting bolts at the rubber dynafocal mounts and slowly move the engine forward, check that all hoses, wires and cables are clear and free. The ignition coils must be removed with the engine.

71-00-03 INSTALLATION OF ENGINE

The removal procedures may be followed in reverse paying particular attention to the following:

- (1) Check the condition of the rubber inserts in the dynafocal mounts and replace if necessary.
- (2) Pre-fill the oil lines and oil cooler with engine oil before connecting to engine.
- (3) Ensure that the carburettor air induction hoses are well sealed to the filter box.
- (4) When refilling the coolant system, air locks may occur in the top radiator and cylinder head hoses. To remove the air locks, fill the coolant system as full as possible, then rock the aircraft from side to side. Check the coolant level in the expansion tank before fitting the pressure cap.
- (5) Check the adjustment of the carburettor heat control. Refer chapter 76.
- (6) All bolts requiring steel lock nuts should be fitted with new nuts.
- (7) Check the adjustment of the throttle and starting carburettor controls. Refer chapter 76.
- (8) Check for correct safety wiring of engine mounting bolts and coolant system drain.
- (9) Ground run the engine and check for leaks in the oil system, coolant system, exhaust system, and fuel system and check for normal operating parameters of engine.

71-10-00 ENGINE COWLS

The engine cowls are two piece and of fibreglass construction with a fire retardant additive added to the resin. The bottom cowl is attached to the fuselage by four screws on each side. The top cowl is then fitted to the bottom cowl with five camloc fasteners on each side and then attached to the fuselage by two camloc fasteners on each side and one camloc fastener at the top and centre of the cowl.

71-10-01 REMOVAL OF ENGINE COWLS

Open both cabin doors and undo the five camloc fasteners along the cowl join each side of the cowls, and the two camloc fasteners on each side of the top cowl, then undo the camloc fastener at the top and centre of the cowl. The top cowl can now be removed. Undo the four screws on each side and remove the bottom cowl.

71-10-02 CLEANING AND INSPECTION

Use a solvent such as kerosene or fuel to clean any dirt, oil or coolant from inside the engine cowls. Rinse with fresh water and dry off with a clean dry cloth. Inspect the cowls for cracks, deformity or heat degradation and repair as necessary. Refer FAA publication AC 43.13-1A. Check the condition of the rubber seal which contacts the windscreen and replace as necessary.

71-10-03 INSTALLATION OF ENGINE COWLS

The removal procedures may be followed in reverse ensuring that after installation, the engine cowl clears all engine components such as exhaust system and airfilter box.

Skyfox

MAINTENANCE MANUAL

CA-25N

Aviation

GAZELLE

CHAPTER 73

ENGINE FUEL SYSTEM

Skyfox
Aviation

MAINTENANCE MANUAL

CA-25N

GAZELLE

CHAPTER 73 ENGINE FUEL SYSTEM

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
73-00-00	GENERAL	73-3	10 MAY 1995
73-10-00	DISTRIBUTION	73-3	10 MAY 1995
73-10-01	REMOVAL AND INSTALLATION OF FUEL LINES	73-3	10 MAY 1995
73-10-02	FUEL FLOW CHECK	73-3	10 MAY 1995

73-00-00 GENERAL

This chapter describes removal, installation and servicing procedures for those components not covered by the data in the engine manufacturers operations and maintenance manuals. Refer to list of vendor publications in this manual.

73-10-00 DISTRIBUTION

73-10-01 REMOVAL AND INSTALLATION OF FUEL LINES

The fuel line from the gascolator to the engine driven fuel pump has a swivel fitting on the gascolator end. Turn the fuel cock OFF and undo the swivel fitting. The end attached to the engine driven fuel pump is a "push on" fitting. Loosen the hose clamp and remove the fuel line.

The fuel line from the engine driven fuel pump to the carburetors has a "T" piece fitted where the single fuel line is divided into two, and also another "T" piece provides a mount for the fuel pressure switch. The fuel lines between the "T" piece and the carburetors are covered with fire sleeve. The fitting to the engine driven fuel pump is a "push on" fitting as are the two fuel lines attached to the carburetors. Disconnect the two wire cables from the fuel pressure switch. Loosen the hose clamp on the fuel pump; and pull the fuel line free, then loosen the hose clamps at the carburetors and pull free.

When installing the fuel lines, pay particular attention when pushing the fuel line onto the "push on" fittings so that the fuel line is not damaged and foreign particles do not enter the fuel line. Turn ON the fuel cock.

73-10-02 FUEL FLOW CHECKS

Drain both main fuel tanks (fuel remains in the collector tank). Remove both carburetor bowls, and place under them a calibrated measuring container of approximately 500ml capacity. Turn the fuel cock OFF, then turn the master and electric fuel pump switches ON. Using a wristwatch or other time piece with second indications, turn the fuel cock ON for 30 seconds. Turn the master and electric fuel pump switches OFF, then measure the quantity of fuel in the containers. Multiply the quantity of fuel by two. The minimum quantity of fuel over a thirty second period must not be less than 250ml (total of both bowls), i.e. fuel flow 30 lt/hour. Expect 300 ml in test.

If the minimum is not met, check all fuel filters, fuel cock and lines for blockages. Replace the fuel line onto the carburetor.

CHAPTER 74
IGNITION

CHAPTER 74 IGNITION

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
74-00-00	GENERAL	74-3	10 MAY 1995
74-30-00	SWITCHING	74-3	10 MAY 1995

74-00-00 GENERAL

This chapter describes removal, installation and servicing procedures for those components not covered by the data in the engine manufacturers operations and maintenance manuals. Refer to list of vendor publications in this manual.

74-30-00 SWITCHING

The dual ignition circuits are controlled by two toggle switches fitted at the lower left section of the instrument panel. These switches, when in the OFF position, ground the ignition circuit to earth and disable that ignition system. Removal and installation of those switches is described in chapter 39 of this manual.

CHAPTER 76
ENGINE CONTROLS

CHAPTER 76 ENGINE CONTROLS

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER	SECTION	SUBJECT	PAGE EFFECTIVITY		
76-00-00		GENERAL	76-3	10 MAY	1995
76-00-01		DESCRIPTION	76-3	10 MAY	1995
76-10-00		SERVICING	76-3	10 MAY	1995

76-00-00 GENERAL

For information regarding the adjustment of the engine controls, refer to the engine manufacturers operations and maintenance manual. Refer to the list of vendor publications in this manual. The engine controls are described below.

76-00-01 DESCRIPTION

The engine throttle is controlled by a push pull control located at the bottom and centre of the instrument panel. This single control divides into two pushrod cables via a splitter box behind the instrument panel before routing to each of the two carburetors on the engine.

The choke control, (starting carburetor), is located on the left of the instrument panel next to the RIGHT CDI switch. This single control divides into two Bowden cables behind the instrument panel before routing to each of the two carburetors on the engine.

The carburetor heat control is located above the throttle control on the instrument panel. This control is a pushrod cable which routes to the carburetor heat selector box located under the engine. When carburetor heat is selected, fresh air is heated by the engine exhaust before being drawn into the engine.

76-10-00 SERVICING

All engine controls are "Bowden Cables" and must have free movement at all times. If the movement is restricted, the inner cable can be removed from the outer cable and lubricated with "Anti-Seize".

If the Throttle Friction nut cannot be adjusted to achieve the appropriate friction for the pilot, then it must be replaced.

Diagrams are provided in Chapter 91.

CHAPTER 7 7
ENGINE INDICATING

CHAPTER 77 ENGINE INDICATING

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION SUBJECT	PAGE EFFECTIVITY
77-00-00 GENERAL	77-3 10 MAY 1995
77-00-01 REPLACEMENT OF ENGINE INSTRUMENTS	77-3 10 MAY 1995
77-00-02 TROUBLE SHOOTING	77-4 10 MAY 1995
77-10-00 POWER	77-5 10 MAY 1995
77-10-01 TACHOMETER	77-5 10 MAY 1995
77-20-00 TEMPERATURE	77-5 10 MAY 1995
77-20-01 OIL TEMPERATURE	77-5 10 MAY 1995
77-20-02 CYLINDER HEAD TEMPERATURE	77-5 10 MAY 1995
77-40-00 PRESSURE	77-5 10 MAY 1995
77-40-01 OIL PRESSURE	77-5 10 MAY 1995
77-50-00 INSTRUMENT FACE MARKINGS	77-6 10 MAY 1995

77-00-00 GENERAL

All engine instruments in the CA25N are sealed and cannot be serviced. If incorrect readings are evident and it is found to be instrument error, then the instrument must be replaced.

77-00-01 REPLACEMENT OF ENGINE INSTRUMENTS

Remove the top engine cowl. Disconnect wire cables from the back of the instrument and arrange in such a way so as to facilitate installation. Undo the two retaining nuts from the back of the instrument and remove the retaining clamp. Pull the instrument out of the instrument panel from the cockpit side.

When installing a replacement instrument, ensure that the instrument face operating range markings are correct. Place the instrument in the panel and rotate the instrument until it is level. Replace the retaining clamp and nuts and reconnect the wire cables. Carry out a functional check of the instruments.

77-00-02 TROUBLE SHOOTING

Troubles peculiar to the engine indicating system are listed in chart 7701 along with their probable causes and suggested remedies.

CHART 7701 TROUBLE SHOOTING (ENGINE INDICATING)

TROUBLE	PROBABLE CAUSE	REMEDY
POINTER DOES NOT MOVE	Instrument fuse blown, low system voltage, sensor disconnected, faulty instrument, faulty engine.	Check fuse, system voltage at instrument, replace sensor, instrument, repair engine.
INACCURATE READINGS	Incorrect system voltage, faulty sensor, faulty instrument, out of calibration, engine faulty.	Check system voltage at instrument, replace sensor or instrument, repair engine.
POINTER FLUCTUATES RAPIDLY	Faulty voltage rect/regulator, loose connection faulty sensor or instrument.	Replace rect/regulator, check connections, replace sensor or instrument.
INSTRUMENT INDICATE EXTREME READINGS	Faulty rect/regulator, sensor disconnected, faulty sensor, instrument or engine.	Replace rect/regulator, check sensor connection, replace sensor or instrument, repair engine.

77-10-00 POWER

77-10-01 TACHOMETER

The tachometer is an electric instrument which reads the frequency of pulses from a dedicated sensor mounted near the flywheel of the engine. The frequency of these pulses is converted into RPM and displayed to the pilot via a pointer over a circular face which is marked with yellow and green arcs and a radial red line as well as numerical figures indicating the safe operating range. The tachometer has DIP switches on the back of the instrument which must be switched as follows:

1. CLOSED — DOWN
2. OPEN — UP
3. OPEN — UP
4. OPEN -- UP
5. OPEN — UP

77-20-00 TEMPERATURE

77-20-01 OIL TEMPERATURE

The oil temperature is indicated via an electric instrument and sensor. The sensor changes resistance with changes in temperature which causes the instrument pointer to move. The instrument face is marked in degrees Celsius and has yellow, green and red arcs indicating the safe operating range.

77-20-02 CYLINDER HEAD TEMPERATURE

The method used for indicating the cylinder head temperature is identical to that of the oil temperature. The CHT probe is located in Cylinder No 3 head (underneath).

77-40-00 PRESSURE

77-40-01 OIL PRESSURE

The oil pressure indicating system operates in the same manner as the oil temperature and cylinder head temperature except that the sensor changes resistance with variation in pressure.

77-50-00 INSTRUMENT FACE MARKINGS

TACHOMETER RPM

0	-	1600	No Colour
1600	-	5500	Green Band
5500	-	5800	Yellow Band
5800			Red Radial

OIL PRESSURE kPa

0	-	125	
125	-	500	Red Band Green Band
500	-	1000	Red Band

OIL TEMPERATURE °C

50	-	140	Green Band Red Band
140	-	150	

C.H.T. °C

50	-	150	Green Band
150			Red Radial

VOLTMETER Volts

10	-	12	
12	-	14	Red Band Green Band
14	-	16	Red Band

CHAPTER 79
OIL SYSTEM

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
79-00-00	GENERAL	79-3	10 MAY 1995-
79-00-01	DESCRIPTION	79-3	10 MAY 1995
79-00-02	OIL FILTER REPLACEMENT	79-3	10 MAY 1993~
79-00-03	OIL COOLER REMOVAL	79-3	10 MAY 1995
79-00-04	OIL COOLER INSTALLATION	79-3	10 MAY 1995
79-00-05	DRAINING OIL TANK	79-4	05 MAR 1997
79-00-06	OIL SCREENS	79-4	10 MAY 1995
79-00-07	OIL TANK REMOVAL	79-4	10 MAY 1995
79-00-08	OIL TANK INSTALLATION	79-4	10 MAY 1995

79-00-00 GENERAL

79-00-01 DESCRIPTION

The oil is drawn from the oil tank, through the oil cooler to the oil pump where it is forced through a full flow oil filter and then to the engine components. The engine has a dry sump, forced lubrication oil system which consists of an oil tank, which has oil returned to it, using crankcase pressure. While the engine is not operating, the oil is stored in the tank which is fitted with a drain plug.

79-00-02 OIL FILTER REPLACEMENT

Remove both engine cowls. Loosen the oil filter clamp, (hose clamp), while leaving the lock wire intact, then remove the oil filter from the engine. Before installing the replacement filter, cut the oil filter apart and examine for foreign particle and metal filings. If found, the source of the particles should be investigated further before allowing the engine back into service. When installing the new filter, tighten the filter to the engine and then rotate the oil filter clamp in an anti-clockwise direction and tighten the clamp. The oil filter should now be prevented from unscrewing.

79-00-03 OIL COOLER REMOVAL

Remove both engine cowls. Refer chapter 71. Disconnect both oil lines from the cooler by removing the centre bolts from the "banjo" fittings on the oil cooler. Undo the two 20mm securing nuts from the oil cooler and remove the cooler from the engine mount brackets.

79-00-04 OIL COOLER INSTALLATION

The removal procedures may be followed in reverse paying particular attention to the following:

- (1) Renew the copper gaskets on the "banjo" fittings.
- (2) Maximum torque to be applied to the 20mm securing nuts is 30 inch/pounds, (3.4Nm).
- (3) Fill oil lines and cooler with engine oil before reconnection.
- (4) Ground run engine and check for correct oil pressure and oil leaks.

79-00-05 DRAINING OIL TANK

To drain the oil tank, provide a suitable container with a minimum capacity of that required to fill the tank, (at least 2.5Lt) Remove the engine cowls and centre console then remove the oil tank box base plate. Open the oil drain valve or drain plug located at the base of the oil tank on the inside of the tank box. It is recommended that the engine be warmed to operating temperatures to ensure complete draining of the old oil.

NOTE: On aircraft fitted with oil "Quick Drain", this procedure is simplified. Locate quick drain plug, located on lower surface of aircraft, behind firewall. Remove lockwire. Use TWO spanners, one to hold the mounting nut and the other to undo the oil plug. Drain contents into a suitable container, then re-fit oil plug. Relock wire plug.

79-00-06 OIL SCREENS

The oil screen is located in the base of the oil tank and can only be serviced by removing the oil tank from the oil box. Once the oil tank has been removed from the oil box, the tank is disassembled, and the oil strainer removed. Cleaning of the oil strainer should be carried out at engine overhaul. When cleaning the strainer, take notice of any foreign particles or metal filings which may indicate damage occurring in the engine. After reassembling the oil tank, pressurize to 14Kpa, (2psi), and check for leaks around the lid seal. Reinstall the oil tank into the oil box and attach to firewall then reconnect all hoses.

NOTE: The Rotax Parts Manual refers to the screen as a baffle.

79-00-07 OIL TANK REMOVAL

Remove both engine cowls. Refer chapter 71. Drain oil from oil tank. Remove lid from oil box. Disconnect oil lines. Disconnect quick drain system if fitted. Remove nylon retaining blocks from inside oil box. Disconnect oil tank housing clamp from oil box. Remove oil tank from box.

79-00-08 OIL TANK INSTALLATION

The removal procedures may be followed in reverse paying particular attention to the following:

- (1) Fill oil lines and cooler with engine oil before reconnection.
- (2) Ground run engine and check for correct oil pressure and oil leaks.

CHAPTER 80
STARTING

CHAPTER 80 STARTING

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	PAGE	EFFECTIVITY
80-00-00	GENERAL	80-3	10 MAY 1995
80-00-01	DESCRIPTION AND OPERATION	80-3	10 MAY 1995
80-00-02	TROUBLE SHOOTING	80-3	10 MAY 1995

80-00-00 GENERAL

80-00-01 DESCRIPTION AND OPERATION

The engine is fitted with an electric starter which is operated by a push button switch located under the master switch on the instrument panel. This switch activates a solenoid located on the firewall (cockpit side) which connects the starting battery directly to the starter via a heavy-duty electric cable. The starter can only be activated when the master switch is ON.

80-00-02 TROUBLE SHOOTING

Troubles peculiar to the starting system are listed in chart 8001 along with their probable causes and suggested remedies.

CHART 8001 TROUBLE SHOOTING (STARTING SYSTEM)

TROUBLE	CAUSE	REMEDY
NOTHING HAPPENS WHEN START BUTTON IS PUSHED	Flat battery, loose connection, master switch not ON, faulty starter switch, solenoid or starter.	Turn master ON, check battery charge, loose connections, replace starter, solenoid or switch.
A CLICKING SOUND IS HEARD BUT ENGINE DOES NOT CRANK	Flat battery, loose connection, faulty solenoid or starter.	Check for loose connections, battery charge, replace solenoid or starter.
ENGINE CRANKS SLOWLY	Flat battery, loose connection, faulty starter.	Check battery charge, loose connections, replace starter.
ENGINE CRANKS NORMALLY BUT WON'T START	Ignition switches not ON, refer to engine operators manual.	Turn ignition ON, refer to engine operators manual for trouble shooting.

Check the Rotax Operator's Manual for further starting problems.

CHAPTER 91
CHARTS AND WIRING DIAGRAMS

CHAPTER 91 CHARTS AND WIRING DIAGRAMS

TABLE OF CONTENTS/EFFECTIVITY

CHAPTER SECTION	SUBJECT	EFFECTIVITY
	CHARTS AND WIRING DIAGRAMS	10 MAY 1995..
91-00-01	CONTROL SYSTEM ASSEMBLY	10 MAY 1995
91-00-02	AILERON CENTERING DEVICE ASSEMBLY	10 MAY 1995 -
91-00-03	TAIL WHEEL ASSEMBLY	10 MAY 1995
91-00-04	ENGINE MOUNT ASSEMBLY	10 MAY 1995
91-00-05	COOLING SYSTEM ASSEMBLY	10 MAY 1995
91-00-06	OIL SYSTEM ASSEMBLY	10 MAY 1995
91-00-07	INDUCTION SYSTEM ASSEMBLY	10 MAY 1995
91-00-08	FIREWALL ASSEMBLY	10 MAY 1995
91-00-09	FUEL SYSTEM SCHEMATIC	10 MAY 1995
91-00-10	ELECTRICAL CIRCUIT DIAGRAM	10 MAY 1995
91-00-11	PROPELLER ASSEMBLY	10 MAY 1995
91-00-12	WING ASSEMBLY	10 MAY 1995
91-00-13	WASHOUT DETAIL	10 MAY 1995
91-00-14	LEADING EDGE DETAIL	10 MAY 1995
91-00-15	DIHEDRAL DETAIL	10 MAY 1995
91-00-16	UHF RADIO WIRING DIAGRAM	10 MAY 1995
91-00-17	INTERCOM WIRING DIAGRAM	10 MAY 1995
91-00-18	TERRA TRT250 WITH AT3000 INTERWIRING	10 MAY 1995
91-00-19	KING KY97A VHF INTERWIRING	10 MAY 1995
91-00-20	KING KR86 ADF INTERWIRING	10 MAY 1995
91-00-21	CA-25N ELECTRIC WIRING	05 MAR 1997
91-00-22	VHF ICOM IC-A200/DACOM ICS41 INTERWIRING	10 MAY 1995
91-00-23	WING ASSEMBLY	10 MAY 1995
91-00-24	RUDDER PEDAL ASSEMBLY	10 MAY 1995
91-00-25	SEAT BELT HARDWARE	10 MAY 1995
91-00-26	INSTRUMENT PANEL HARDWARE	10 MAY 1995
91-00-27	BRAKE ASSEMBLY	10 MAY 1995
91-00-28	WHEEL ASSEMBLY	10 MAY 1995
91-00-29	MASTER CYLINDER ASSEMBLY	10 MAY 1995
91-00-30	BATTERY INSTALLATION	10 MAY 1995
91-00-31	FILLER NECK VALVE ASSEMBLY	10 MAY 1995
91-00-32	MAIN UNDERCARRIAGE ASSEMBLY 1 of 2	10 MAY 1995
91-00-33	MAIN UNDERCARRIAGE ASSEMBLY 2 of 2	10 MAY 1995
91-00-34	MAIN UNDERCARRIAGE LEG	10 MAY 1995
91-00-35	MAIN UNDERCARRIAGE SHOCK STRUT	10 MAY 1995
91-00-36	TAIL SKID ASSEMBLY	10 MAY 1995
91-00-37	STEERING ASSEMBLY LEFT HAND	10 MAY 1995
91-00-37	STEERING ASSEMBLY RIGHT HAND	10 MAY 1995
91-00-38	RUDDER RETURN LEFT HAND	10 MAY 1995

AMENDMENT 0: 10 MAY 1995



Page 91-2

TABLE OF CONTENTS/EFFECTIVITY (cont.)

CHAPTER SECTION	SUBJECT	EFFECTIVITY
91-00-40	NOSE GEAR - PARTS LISTS 1 of 2	10 MAY 1995
91-00-41	NOSE GEAR - PARTS LISTS 2 of 2	10 MAY 1995-
91-00-42	NOSE GEAR ASSEMBLY 1 of 2	10 MAY 1995
91-00-43	NOSE GEAR ASSEMBLY 2 of 2	10 MAY 1995
91-00-44	MAIN WHEEL SPAT	10 MAY 1995
91-00-45	NOSE WHEEL SPAT	10 MAY 1995
91-00-46	SEAT ASSEMBLY	10 MAY 1995
91-00-47	JURY STRUT ASSEMBLY	10 MAY 1995
91-00-48	WASHOUT DETAIL	10 MAY 1995
91-00-49	DIHEDRAL DETAIL	10 MAY 1995 05
91-00-50	KT76A/SSD120 INTERWIRING 100 HOUR	MAR 1997
CH-100-N	INSPECTION SCHEDULE	10 MAY 1995

SKYFOX CA-25N Gazelle

THREE VIEW DIAGRAMS



THREE VIEW DRAWING (MAIN PARTS LIST)

No.	DESCRIPTION	PART No.
1.	FUSELAGE	FU-1
2.	WING R/H	WI-I-R
3.	WING L/H	WI-I-L
4.	AILERON R/H	57-1-R
5.	AILERON L/H	57-1-L
6.	RUDDER	VLA-FRI
7.	ELEVATOR	TPI-E
8.	HORIZONTAL STABILISER	TPI-S
9.	WING LIFT STRUT R/H	WI-28-10-R
10.	WING LIFT STRUT L/H	WI-28-10-L
11.	UPPER ENGINE COWLING	CD-033-U
12.	LOWER ENGINE COWLING	CD-033-L
13.	WINDSCREEN	PT-CA22
14.	SKYLIGHT	SL-3
15.	WING TIP R/H	WING-T-R
16.	WING TIP L/H	WING-T-L
17.	FUEL CAP	91-034
18.	DOOR R/H	MISS-6-3-R
19.	DOOR L/H	MISS-6-3-L
20.	BAGGAGE COMPARTMENT DOOR	FBH-1
21.	TURTLE DECK COVER	FTD-1
22.	SPINNER CONE	AEP-5-C
23.	TYRE MAIN	15 x 6.00 x 6
24.	TYRE NOSE	13 x 5.00 x 6
25.	WHEEL	AA60
26.	ASSEM. U/C MAIN R/H	10813210-01-R
27.	ASSEM. U/C MAIN L/H	10813210-01-L
28.	TAIL SKID	10813250-01
29.	MUFFLER R/H	MA-2
30.	MUFFLER L/H	MA-3

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DO NOT SCALE


DIMENSIONS IN MILLIMETRES

PROJECTION

ITEM	PART NO	DESCRIPTION	QTY
1	AA42B10	EYE BOLT	2
2	RF 481	3/32" S/S THIMBLE	4
3	7	1/16" S/S MARINE CABLE GRADE 304	2
4	2170	SWAGE	4
5	C-191	CENTURY SPRING	1
6	CD-929-2	SPRING MOUNTING PLATE	1
7	CS-22	AILERON BELLCRANK REAR	1
8	RH-2	TUBE REFER DWG NO FU-8	1
9	CT37347.6	NYLON TIE	1

SUPPLEMENTAL DRAWING

REFER DWG NO CS-1 FOR REMAINING CONTROL ASSY APPLICABLE CA2201 INWARDS



NOTE: THIMBLES TO BE FITTED TO SPRING AND EYEBOLTS BEFORE SWAGING CABLES

TO LOCATE HOLE IN SPRING MOUNTING PLATE ASSEMBLY MUST FIRST BE MOUNTED IN AIRFRAME. THEN SPRING PRE-TENSIONED TO 14KG +/- 1 AND THEN LOCATION OF HOLE MARKED AND DRILLED 5mm.

PLASTIC INSULATION TAPE TO BE APPLIED TO FUSelage TUBE RH-2 BEFORE FITTING SPRING MOUNTING PLATE

AND-18 BOLT SHOWN ON DWG NO CS-1 IS REPLACED WITH AN 42B10 EYEBOLT SHOWN ON THIS DRAWING.

CABLE LENGTH AFTER SWAGING IS 415 mm MEASURED BETWEEN THIMBLES AT I.D. UNSWAGED CABLE LENGTH IS 515 mm.

NYLON TIE IS LOOPED OVER FUSelage TUBE RH-2 AND THROUGH TOP THIMBLES OF BOTH CABLES. NYLON TIE MUST BE LEFT LOOSE ENOUGH TO ALLOW SPRING TO EXTEND FREELY.

APPROVED PURSUANT TO
REGULATION 35
OF THE CIVIL AVIATION REGULATIONS
SIGNED *Alan P Kerr* (ALAN P KERR)
DATE 26/3/93
JOB NUMBER REFERENCE

SCALE 1:2
ISS DATE 25/06/92
DRAWING NO CD-029-1
SHEET 1 OF 1

LIMITS: AS DETAILED
DRAWN BY: C. DALBY
APPROVED: [Signature]
TITLE: AILERON CENTRING BVC ASSY
SKYFOX AVIATION
DATE: 25/06/92
DRAWING NO: CD-029-1
SHEET: 1 OF 1

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKIFOR AVIATION

DIMENSIONS IN MILLIMETRES


DO NOT SCALE

PROJECTION



SUPPLEMENTAL DRAWING

REFER TO CD-024 FOR REMAINING ASSX.
 APPLICABLE CA 25 SERIES




D. J. LUEWELLYN

Approved pursuant to C.A.R. 35
 at production issue No. 1
 as conforming with the following
 Airworthiness Design Standard:
 AS 1558
 Date: 7/1/73
 As authorized under 6/1/73

UNITS	ISSUED	SCALE	DATE
METRIC	7/1/73	1:1	17-5-73
	REVISED		ISS
	DATE		DATE
			20-20-73
			3
			SECT

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYDEX AVIATION
 DIMENSIONS IN MILLIMETRES DO NOT SCALE PROJECTION

APPROVED PURSUANT TO
 REGULATION 33/
 OF THE CIVIL AVIATION REGULATIONS
 SIGNED (SALANTERRI)
 DATE 26/2/97
 JOB NUMBER REFERENCE




9	71032 MOUNTING RUBBER	9	18		
8	AN363-6E4 NUT	4	17	MS35333-10 LOCK WASHER	1
7	AN960-6 WASHER	12	16	M6 x 16mm SET SCREW	1
5	AN6-40A BOLT	4	15	EARTH STRAP	1
5	MS35333-42 LOCK WASHER	9	14	CD-024-2	1
4	M10 x 40mm BOLT	7	13	AN365-42B NUT	6
3		1	12	AN960-416 WASHER	15
2		1	11	AN4-15A BOLT	6
1	DC-005-1 MOUNTING	1	10	CD-005-3 INNER MOUNT	4
	ITEM	QTY	No	ITEM	QTY
	LIMITS	1/1-1-0		ITEM	
	MATERIAL			SKYDEX AVIATION	

SCALE 1:1
 DATE 18.11.93
 DRAWING NO. CD-005


TITLE ENGINE MOUNT ASSEMBLY

APPROVED PURSUANT TO
 REGULATION 25
 OF THE FEDERAL AVIATION
 ADMINISTRATION
 SIGNED: [Signature]
 DATE: 2/2/93
 (BALANTY RSI)



NO.	SYMBOL	DESCRIPTION	QUANTITY	REMARKS
1	1	CONTROL PANEL	1	
2	2	CONTROL PANEL	1	
3	3	CONTROL PANEL	1	
4	4	CONTROL PANEL	1	
5	5	CONTROL PANEL	1	
6	6	CONTROL PANEL	1	
7	7	CONTROL PANEL	1	
8	8	CONTROL PANEL	1	
9	9	CONTROL PANEL	1	
10	10	CONTROL PANEL	1	
11	11	CONTROL PANEL	1	
12	12	CONTROL PANEL	1	
13	13	CONTROL PANEL	1	
14	14	CONTROL PANEL	1	
15	15	CONTROL PANEL	1	
16	16	CONTROL PANEL	1	
17	17	CONTROL PANEL	1	
18	18	CONTROL PANEL	1	
19	19	CONTROL PANEL	1	
20	20	CONTROL PANEL	1	
21	21	CONTROL PANEL	1	
22	22	CONTROL PANEL	1	
23	23	CONTROL PANEL	1	
24	24	CONTROL PANEL	1	
25	25	CONTROL PANEL	1	
26	26	CONTROL PANEL	1	
27	27	CONTROL PANEL	1	
28	28	CONTROL PANEL	1	
29	29	CONTROL PANEL	1	
30	30	CONTROL PANEL	1	
31	31	CONTROL PANEL	1	
32	32	CONTROL PANEL	1	
33	33	CONTROL PANEL	1	
34	34	CONTROL PANEL	1	
35	35	CONTROL PANEL	1	
36	36	CONTROL PANEL	1	
37	37	CONTROL PANEL	1	
38	38	CONTROL PANEL	1	
39	39	CONTROL PANEL	1	
40	40	CONTROL PANEL	1	
41	41	CONTROL PANEL	1	
42	42	CONTROL PANEL	1	
43	43	CONTROL PANEL	1	
44	44	CONTROL PANEL	1	
45	45	CONTROL PANEL	1	
46	46	CONTROL PANEL	1	
47	47	CONTROL PANEL	1	
48	48	CONTROL PANEL	1	
49	49	CONTROL PANEL	1	
50	50	CONTROL PANEL	1	

CONTROL SYSTEM ASSEMBLY
 AVIATION
 CONTROL SYSTEM ASSEMBLY



THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DIMENSIONS IN MILLIMETRES DO NOT SCALE PROJECTION

ITEM	PART NO	DESCRIPTION	QTY
1	CP-016-21	HOSE SWATH	1
2	CP-016-22	CLAMP SUPPORT	1
3		T. CONNECTOR	1
4		VENT LINE	1
5		FUEL FILLER NECK ASSY.	2
6		NON RETURN VALVE	2
7		FUEL TANK - WING	2
8		VENTED FUEL CAP	2
9		FISHER STRAINER	2
10	CCA-1550	DRAIN VALVE	4
11		TANK BATHING MAT	4
12		STATIC BATH	2
13		COLLECTOR TANK ASSY	1
14		FUEL COCK	1
15	ACS-10580	GASCOLATOR	1
16	1LM12	EMERGENCY FUEL PUMP	1
17	860-204	FUEL PRESSURE WARNING SWITCH	1
18	22097155	MAIN FUEL PUMP	1
19	28-5	FUEL TANK CROSS VENT	2
20		TANK FLEXIBLE HOSE	2
21		ENGINE FUEL HOSE	5
22		CROSS VENT HOSE	1
23		RESTRICTOR	1

SKYFOX AVIATION TITLE FUEL SYSTEM SCHEMATIC

DATE 10-5-43


SCALE 1:5

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DIMENSIONS IN MILLIMETRES

DO NOT SCALE

PROJECTION



APPROVED PURSUANT TO
REGULATION 35
OF THE CIVIL AVIATION REGULATIONS
SIGNED
DATE 26/2/93
JOB NUMBER REFERENCE

NO	ITEM	QTY
13	TAIL PIPES	2
12	FUEL PUMP	1
11	MS0300N HOSE CLAMP	2
10	MS0200N HOSE CLAMP	8
9	AF1027624 FIRE SLEEVE x 575mm	1
8	AF1027624 FIRE SLEEVE x 380mm	1
7	TFP14 TEE PICE	1
6	PRESSURE SWITCH 560204	1
5	TIE	1
4	ENZED 100R-4-1/4"MP HOSE 660mm	1
3	ENZED 100R-4-1/4"MP HOSE 365mm	1
2	MIL-H-8794-5 x 110mm HOSE	1
1	MIL-H-8794-5 x 170mm HOSE	1

SCALE 1:1 21.11.93
N.T.S. ISS DATE

SKYFOX AVIATION MILITARY ENGINE FUEL SYSTEM ASSEMBLY


DATE 26/2/93
JOB NUMBER REFERENCE

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DIMENSIONS IN MILLIMETRES

DO NOT SCALE

PROJECTION



APPROVED PURSUANT TO
REGULATION 35
OF THE CIVIL AVIATION REGULATIONS
SIGNED *[Signature]*
DATE 26/2/93
JOB NUMBER 26/93

FS 3	
QTY	ITEM
2	MS0300N HOSE CLAMP
1	A063A058 SWIVEL TAIL
1	MIL-H-8794-6 HOSE 84.0mm

FS 1	
QTY	ITEM
2	MS 0300N HOSE CLAMP
2	AN 970-816 WASHER
1	P7N A50510808 BULKHEAD
1	C50530808 45° ELBOW
2	A063A058 SWIVEL TAIL
1	MIL-H-8794-6 HOSE 310mm

FS 2	
QTY	ITEM
1	2 AN960-10 WASHER
1	AN364-3 NUT
1	10 AN3-26 BOLT
1	9 FFA GAS BRACKET
2	SF-GASC-1 RING RETAIN
2	B37500408 90° ELBOW
1	K1023 GASCOLATOR

SCALE 1:20
DATE 26/2/93
DRAWING No CD-035
SHEET 1 OF 1

FUEL SYSTEM


SKYFOX AVIATION

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DIMENSIONS IN MILLIMETRES

DO NOT SCALE

PROJECTION



SCALE 1:1

ISS DATE 28.11.93

DRAWING NO CD-005-3B

SHEET 1 OF 1

APPROVED PURSUANT TO
 REGULATION OF THE CIVIL AVIATION REGULATIONS
 SIGNED *[Signature]*
 (ALAN P. KERR)
 DATE 26/12/93
 JOB NUMBER REFERENCE

31	300-100 BOTTLE	1
32	WATER TANK	1
33	WATER TANK	1
34	WATER TANK	1
35	WATER TANK	1
36	WATER TANK	1
37	WATER TANK	1
38	WATER TANK	1
39	WATER TANK	1
40	WATER TANK	1
41	WATER TANK	1
42	WATER TANK	1
43	WATER TANK	1
44	WATER TANK	1
45	WATER TANK	1
46	WATER TANK	1
47	WATER TANK	1
48	WATER TANK	1
49	WATER TANK	1
50	WATER TANK	1
51	WATER TANK	1
52	WATER TANK	1
53	WATER TANK	1
54	WATER TANK	1
55	WATER TANK	1
56	WATER TANK	1
57	WATER TANK	1
58	WATER TANK	1
59	WATER TANK	1
60	WATER TANK	1
61	WATER TANK	1
62	WATER TANK	1
63	WATER TANK	1
64	WATER TANK	1
65	WATER TANK	1
66	WATER TANK	1
67	WATER TANK	1
68	WATER TANK	1
69	WATER TANK	1
70	WATER TANK	1
71	WATER TANK	1
72	WATER TANK	1
73	WATER TANK	1
74	WATER TANK	1
75	WATER TANK	1
76	WATER TANK	1
77	WATER TANK	1
78	WATER TANK	1
79	WATER TANK	1
80	WATER TANK	1
81	WATER TANK	1
82	WATER TANK	1
83	WATER TANK	1
84	WATER TANK	1
85	WATER TANK	1
86	WATER TANK	1
87	WATER TANK	1
88	WATER TANK	1
89	WATER TANK	1
90	WATER TANK	1
91	WATER TANK	1
92	WATER TANK	1
93	WATER TANK	1
94	WATER TANK	1
95	WATER TANK	1
96	WATER TANK	1
97	WATER TANK	1
98	WATER TANK	1
99	WATER TANK	1
100	WATER TANK	1

SKYFOX AVIATION

THE COOLING SYSTEM ASSEMBLY

K-CAB DESIGN K.G.HILLS.


DRAWN BY

APPROVED

1/2-1.0

MATERIAL

WITHOUT CONSENT OF SKYFOX AVIATION DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED



APPROVED PURSUANT TO
 REGULATION 35 OF THE CIVIL AVIATION REGULATIONS
 SIGNED Alan P Kerr
 DATE 26/2/97
 JOB NUMBER REFERENCE

13 BIKE BRAKE CABLE	2
12 SPLITTER BOX	1
11a 4500 x 650mm CABLE	1
11 4500 x 900mm CABLE	1
4 1/8" WHITWORTH SET SCREWS	3
3 2818 SPLITTER CLAMP	1
NO ITEM	QTY


SCALE N.T.S. 21.1.93
 ISS DATE

TITLE SKYFOX AVIATION
 CHOKO CABLE ASSEMBLY

DESIGN K.G. MILLS
 DRAWN APPROVED

DRWING NO CD-012-6
 SECRET

THIS DRAWING IS COPYRIGHTED AND MUST NOT BE COPIED OR REPRODUCED WITHOUT CONSENT OF SKYFOX AVIATION. DIMENSIONS IN MILLIMETRES. DO NOT SCALE. PROJECTION.



5	FLANG	2
4	CLAMP	2
3	SHROUD	1
2	HEAT SPRINGS	2
1	EXHAUST PIPE	1
QC	ITEM	QTY

SCALE: N.T.S.
 ISS: 23-11-93
 DATE: []
 DRAWING NO: CD-010
 SHEET: [] OF []

SKYFOX AVIATION
 CARB/CAB EXCHANGE ASSEMBLY

DESIGNER: K-CAD DESIGN & G-MILLS
 APPROVED: []


DATE: 7-1-0
 MATERIAL: []

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DIMENSIONS IN MILLIMETRES

DO NOT SCALE

PROJECTION



NOTE: SAFETY WIRE PROP BOLTS ARE ASSEMBLY.

TOGUE BOLTS TO MAIN PARTS ARE RECOMMENDED.

LOCK WIRE PROP BOLTS 1/4" AC. 4313-114.

ITEM	PART NO	DESCRIPTION	QTY
1	APP-5/AL-1	SPINNER CONE	1
2	APP-5/AL-2	SPINNER CONE SCREW	10
3	BY100X125	BOLT	6
4	WVA14	WASHER BELLEVILLE	24
5	APP-6	SPACER	1
6	APP-7	PROPELLER	1
7	APP-8	SPINNER BACK PLATE	1
8	APP-9	ENGINE PROPELLER FLANGE	1
9	APP-10	WASHER	5
10	APP-11	WASHER	5

SKYFOX AVIATION

SCALE 1:6.2


ISS 30/9/98

DATE

DRAWING NO RPA-2

SHEET 1 OF 1

APPROVED PURSUANT TO
 REGULATION 35
 OF THE CIVIL AVIATION REGULATIONS
 SIGNED [Signature]
 (ALAN P KERR)
 DATE 26/2/93
 JOB NUMBER REFERENCE



THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DIMENSIONS IN MILLIMETRES

DO NOT SCALE

PROJECTION

APPROVED PURSUANT TO
REGULATION 35
OF THE CIVIL AVIATION REGULATIONS
SIGNED AV (ALAN FARRAR)
DATE 26/2/93
JOB NUMBER REFERENCE

NO	ITEM	QTY	ITEM	QTY
1	MS 21042-3 NUT	4	20 T/CABLE SWIVEL	1
2	MS 21042-3 WASHER	4	19 1/4 1300 GALI	1
3	MS 35207-263 SCREW	2	18 BA-8103-1 FILTER ELEMENT	1
4	MS 24665-151 SPL 1/2 PIN	2	17 BIP 9040 SPRING	1
5	MS 24665-151 SPL 1/2 PIN	2	16 MS21919 WDG 3 AVREL CLAMP	1
6	MS 24665-151 SPL 1/2 PIN	2	15 ANQ-7A BOLT	2
7	MS 24665-151 SPL 1/2 PIN	2	14 1/2 1300 GALI	1
8	MS 24665-151 SPL 1/2 PIN	2	13 1/2 1300 GALI	1
9	MS 24665-151 SPL 1/2 PIN	2	12 1/2 1300 GALI	1
10	MS 24665-151 SPL 1/2 PIN	2	11 1/2 1300 GALI	1
11	MS 24665-151 SPL 1/2 PIN	2	10 1/2 1300 GALI	1
12	MS 24665-151 SPL 1/2 PIN	2	9 1/2 1300 GALI	1
13	MS 24665-151 SPL 1/2 PIN	2	8 1/2 1300 GALI	1
14	MS 24665-151 SPL 1/2 PIN	2	7 1/2 1300 GALI	1
15	MS 24665-151 SPL 1/2 PIN	2	6 1/2 1300 GALI	1
16	MS 24665-151 SPL 1/2 PIN	2	5 1/2 1300 GALI	1
17	MS 24665-151 SPL 1/2 PIN	2	4 1/2 1300 GALI	1
18	MS 24665-151 SPL 1/2 PIN	2	3 1/2 1300 GALI	1
19	MS 24665-151 SPL 1/2 PIN	2	2 1/2 1300 GALI	1
20	MS 24665-151 SPL 1/2 PIN	2	1 1/2 1300 GALI	1

SCALE 1:1
N.T.S. ISS DATE 27.11.93
DRAWING NO CD-007
SHEET 1 OF 1

TITLE SKYFOX AVIATION INDUCTION SYSTEM ASSEMBLY


LIMITS MATERIAL APPROVED DRAWN BY X-CAP DESIGN K.G.HALL

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYDEX AVIATION

DIMENSIONS IN MILLIMETRES

DO NOT SCALE

PROJECTION



APPROVED PURSUANT TO
 REGULATION R.S.
 OF THE CIVIL AVIATION REGULATIONS
 SIGNED K.G.M.
 (VALANT KERR)
 DATE 26/2/93
 JOB NUMBER REFERENCE

SCALE	1	25:1	93
N.T.S.	ISS	DATE	


SKYDEX	AVIATION	TITLE	SOLENOID ASSEMBLY
--------	----------	-------	-------------------

21	MS2517-15	NIPPLE	5
20	MS2517-45	NIPPLE	3
NO	ITEM	QTY	
LIMITS	+/ - 0	DRAWN	APPROVED
MATERIAL			

K-CAD DESIGN K.G. MILLS

DRAWING NO. CD-015-2-1

NOT DRAWING TO DIMENSIONS AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION | DIMENSIONS IN MILLIMETRES | DO NOT SCALE | PROJECTION




NO.	ITEM	QTY	NO.	ITEM	QTY
5	MS35207-263 SCREWS	3	10	1/2" UNF LOCK NUT	1
4	1/8" WHITWORTH SET SCREWS	3	9	BRACKET	1
3	2818 SPLITTER CLAMP	1	8	1100mm INNER CABLE	2
2	CD-012-1 SPLITTER BOX	1	7	AN960-10L WASHER	6
1	AB20-72 6' CABLE	1	6	AN365-3 NUTS	3

LIMITS	MATERIAL	APPROVED	SCALE	ISS	DATE
+/-1.0	BRASS	K-CAD DESIGN K.G. MILLS	N.I.S.	1	21.1.93

AVIATION | THRUSTLE CABLE ASSEMBLY

APPROVED PURSUANT TO
 REGULATION 35
 OF THE CIVIL AVIATION REGULATIONS
 SIGNED *Alan P Kerr*
 (ALAN P KERR)
 DATE 26/2/93
 JOB NUMBER REFERENCE

ISSUE	REVISION	DRN	CAD	STR.	APP'D	DATE




NOTES
 1. UNLESS OTHERWISE NOTED ALL 28 AWG WIRING IS TO BE DONE IN ACCORDANCE WITH THE DRAWING.
 2. PTT SWITCHES S1 AND S2 TO BE CKK B631 OR EQUIVALENT.
 3. JACKS TO BE 6/16 J1095 OR EQUIVALENT.
 4. PHONES JACKS TO BE 6/16 J1034 OR EQUIVALENT.

ITEM	PART No	QTY	DESCRIPTION	MATERIAL	SIZE	MATERIAL SPEC	PROT.TREAT	FINISH	SHY	ZONE
DEPARTMENT OF TRANSPORT										
DCCOM ICS41 INTERCOM INTERWIRING										
CHAPMAN AVIONICS										
MATERIAL TREATMENT										
UNSCRAMBLERS/SUBSCRIBERS										
Part No										
SCALE: A 3										
DRAWING No: CA 315										
THIRD ANGLE PROJECTION										
SHEET 1 OF 1										

UNSCRAMBLERS/SUBSCRIBERS
 APPROVED PERSON
 CAR 35/CAR 35 OF THE CIVIL
 AVIATION REGULATIONS
 28-7-97
 APPROVED PERSON

ISSUE	REVISION	DRN	CAD	STR	APP'D	DATE

NOTE 3) AT 3000
ENCLOSURE
ENCLOSURE




- NOTES:
- 5 AMPS MAX.
 - SELECT EACH TYPE CABLE AND CONNECTOR FROM THOSE LISTED
 - CABLE LENGTHS:
 - RG-59/U 9 FT. MAX
 - RG-8/U 17 FT. MAX
 - CONNECTORS:
 - RG-59/U: UG-88C, UG-89D, UG-88E, AMPHENOL 31-320, 31-357, 3677E
 - RG-8/U: UG-88C, UG-89D, UG-88E, AMPHENOL 6775
 - CONNECTOR - 25 PIN "D" TYPE (ITT CANNON TYPE 38-25S OR EQUIVALENT)
 - PINS 7, 19 MUST BOTH BE CONNECTED THROUGH A COMMON 2 AMP CIRCUIT BREAKER
 - PINS 11, 12 MUST BOTH BE GROUNDED
 - WIRE SIZE: 24 AWG FOR POWER INPUT AND POWER GROUND
24 AWG FOR ALL OTHERS MIL SPEC W5086A
 - MUST BE CONNECTED TO APPROPRIATE SHUN ON DME IF USED.
 - USE ONLY CONVENTIONAL SWITCH TO BE FOUND TO ENABLE DME FUNCTION

DRAWING NO. CA 333		SHEET 1 OF 1	
AIRCRAFT / ENGINE TYPE VARIOUS		DEPARTMENT OF TRANSPORT	
APPROVAL STAMP		TERRA TR1250 WITH AT3000 INTERWIRING	
ORGANISATION CHAPMAN AVIONICS		SCALE A 3	
MATERIAL TREATMENT Interchangeable / Supersession Part No		SIZE DRAWING NO. CA 333	
DIMENSIONS IN Tolerance Unless Noted. Angles Bases All Shere Edges Dimensions To Be Met After Plating Hole Radius Chamfer & Fillet Max Part No Where Shown		PROJECTED PURSUANT TO REGULATIONS CAP 65/CAR 38 OF THE CIVIL AVIATION REGULATIONS AUTHORIZED PERSON 1-2-93	
AIRCRAFT / ENGINE TYPE APPROVAL STAMP APPROVED PURSUANT TO REGULATIONS CAP 65/CAR 38 OF THE CIVIL AVIATION REGULATIONS AUTHORIZED PERSON 1-2-93		MATERIAL SIZE MATERIAL SPEC. / PROTECTIVE FINISH SRT / ZONE	

DEPARTMENT OF CIVIL AVIATION


STANDARD DRAWING SHEET FOR AIRCRAFT PART

APPROVAL STAMP		HEAT TREATMENT		PROTECTIVE TREATMENT		MATERIAL SPEC. when one part only		ORGANISATION		TITLE		DRAWING NUMBER	
COMMONWEALTH OF AUSTRALIA DEPARTMENT OF TRANSPORT APPROVED pursuant to regulation 4C of the Air Navigation Regulations <i>[Signature]</i> deputy Secretary to the Department of Transport Date: 2 NOV 1979								CHAPMAN AVIONICS		KING KR86 ADF		CA 32	
LIMITS WHERE NOT STATED		SURFACE FINISH		REPLACING PART No.		AIRCRAFT OR ENGINE TYPE		No. REQ'D PER A/C		NEXT ASSEMBLY No.		Sheet 1 of 1	
Fractional		±				VARIOUS							
Decimal		±											
Angular		±											
BREAK SHARP EDGES .010 to .015		BEND RADII		BEND RELIEF		SCALE		WEIGHT CHANGE		DIST. FROM A/C DATUM			
STAMP PART No. WHERE SHOWN													
SCHEDULE OF ISSUES		SCHEDULE OF PARTS		SCHEDULE OF OFF		SCHEDULE OF MATERIAL							
Drawn		CHK'D		AP'D		DATE		Description of Part		Material		Part No. or Spec.	
1		RC		RC		11.10.79							




- NOTES**
1. ANTENNA INSTALLATION SHOWN FOR BOTTOM MOUNTED ANTENNA
 2. LOOP CABLE LENGTHS MUST NOT BE ALTERED
 3. AUDIO CABLE MUST BE SHIELDED PAIR WITH INSULATION JACKET OVER ALL
 4. WIRE SIZE - ALL WIRE MUST BE #22 AWG MIL SPEC. W5086A OR EQUIVALENT
 5. +27.5VDC OPERATION
A. RECEIVER REQUIRES +27.5VDC. INSTALLATION KIT KRN 050-1308-17/19
B. PANEL LIGHTS - CONNECT TERMINAL #5 OF P101 TO +27.5VDC DIMMER CONTROL AND NO CONNECTION MADE TO TERMINAL #4
 6. FOR SENSE CABLE USE RG58/U OR OTHER EQUIVALENT 50 OHM COAXIAL CABLE. SENSE CABLE LENGTH NOT CRITICAL
 7. MATCHING ASSEMBLY IS TO BE MOUNTED ON RACK CABLE ASSEMBLY.

ISSUE: _____ REV. _____ DATE: _____



DRAWING No. CA 214		SHEET OF	
DEPARTMENT OF TRANSPORT		KING KY 97A VHF INTERWIRING	
ORGANISATION CHAPMAN AVIONICS PTY LTD.		SCALE SIZE A3	
DESCRIPTION MATERIAL TREATMENT		THIRD ANGLE PROJECTION CMT OF	
ITEM PART No. QTY		DRAWING No. CA 214	
Tolerance Unless Noted. ± .005 ± .010 ± .015 ± .020 ± .030 ± .040 ± .050 ± .060 ± .070 ± .080 ± .090 ± .100 ± .125 ± .150 ± .175 ± .200 ± .250 ± .300 ± .375 ± .450 ± .560 ± .700 ± .875 ± 1.000 ± 1.250 ± 1.500 ± 1.875 ± 2.000 ± 2.500 ± 3.000 ± 3.750 ± 4.500 ± 5.600 ± 7.000 ± 8.750 ± 10.000 ± 12.500 ± 15.000 ± 17.500 ± 20.000 ± 25.000 ± 30.000 ± 37.500 ± 45.000 ± 56.000 ± 70.000 ± 87.500 ± 100.000 ± 125.000 ± 150.000 ± 175.000 ± 200.000 ± 250.000 ± 300.000 ± 375.000 ± 450.000 ± 560.000 ± 700.000 ± 875.000 ± 1000.000		Interchangeable/Superseded Part No.	
APPROVAL STAMP		15 MAR '89	




NOTES:

1. All wiring shall be in accordance with the applicable code.
2. All wiring shall be in accordance with the applicable code.
3. All wiring shall be in accordance with the applicable code.
4. All wiring shall be in accordance with the applicable code.
5. All wiring shall be in accordance with the applicable code.
6. All wiring shall be in accordance with the applicable code.

IAN MURRAY
 CASA Authorized Person
 L.A. No. P008190
 APPROVED PURSUANT TO CAR... 35
 SIGNATURE: *Ian Murray*
 DATE: 29/12/96 FOR No. 18129C

9508 TCAD	15013 IM
29 December 1996	
Sheet 1 of 1	
PLATE NUMBER	CD-015-2-4
SKYFOX AVIATION	
CA-25 N Electrical wiring	

11/11/96



IC - A200 V.H.F

APPROVED
PURSUANT TO CAR 96 / CAR 138

[Signature]
AUTHORISED PERSON
DATE 30 JULY 95
I.A. NO. P088130
JOB No. 07/7/95

ICS 41

NOTES

- 1 All wiring 24 Guage minimum to meet or exceed Mil Spec W5086A.
- 2 All wiring to be in accordance with Mil W5088, EA - AC 43.13 1A & 2A and C.A.O. 108.32.
- 3 Connector s as supplied with manufacturers installation kit.
- 4 Circuit breaker type as per aircraft manufacturers parts list.
- 5 Antenna location and mounting data as per aircraft manufacturers airframe structures drawings.
- 6 Antenna part No as per aircraft manufacture parts list.
- 7 Phone & Microphone jacks part No as per aircraft manufacturers parts list.
- 8 P.T.T. switch part No as per aircraft manufacturers parts list

DATE 27 July 1995
Issue One
Drawn (Merry)

V.H.F. ICOM, IC - A200. & DACOM ICS - 41 INTERCOM



INSTALLATION FOR SKYFOX AIRCRAFT.

SKYFOX DRAWING SKY 200



APPROVED PURSUANT TO
 REGULATION 23
 OF THE CIVIL AVIATION REGULATIONS
 SIGNED *[Signature]*
 (ALAN P. KERR)
 DATE 26/1/57
 JOB NUMBER REFERENCE

NOTE: THIS SET OF DRAWINGS IS TO BE USED IN CONNECTION WITH THE CIVIL AVIATION REGULATIONS, PART 23, SUBPART G, CHAPTER 1, SECTION 23.101, WHICH IS INCORPORATED BY REFERENCE.

1	GENERAL	1	GENERAL
2	SECTION 1	2	SECTION 2
3	SECTION 3	3	SECTION 4
4	SECTION 5	4	SECTION 6
5	SECTION 7	5	SECTION 8
6	SECTION 9	6	SECTION 10
7	SECTION 11	7	SECTION 12
8	SECTION 13	8	SECTION 14
9	SECTION 15	9	SECTION 16
10	SECTION 17	10	SECTION 18
11	SECTION 19	11	SECTION 20
12	SECTION 21	12	SECTION 22
13	SECTION 23	13	SECTION 24
14	SECTION 25	14	SECTION 26
15	SECTION 27	15	SECTION 28
16	SECTION 29	16	SECTION 30
17	SECTION 31	17	SECTION 32
18	SECTION 33	18	SECTION 34
19	SECTION 35	19	SECTION 36
20	SECTION 37	20	SECTION 38
21	SECTION 39	21	SECTION 40
22	SECTION 41	22	SECTION 42
23	SECTION 43	23	SECTION 44
24	SECTION 45	24	SECTION 46
25	SECTION 47	25	SECTION 48
26	SECTION 49	26	SECTION 50
27	SECTION 51	27	SECTION 52
28	SECTION 53	28	SECTION 54
29	SECTION 55	29	SECTION 56
30	SECTION 57	30	SECTION 58
31	SECTION 59	31	SECTION 60
32	SECTION 61	32	SECTION 62
33	SECTION 63	33	SECTION 64
34	SECTION 65	34	SECTION 66
35	SECTION 67	35	SECTION 68
36	SECTION 69	36	SECTION 70
37	SECTION 71	37	SECTION 72
38	SECTION 73	38	SECTION 74
39	SECTION 75	39	SECTION 76
40	SECTION 77	40	SECTION 78
41	SECTION 79	41	SECTION 80
42	SECTION 81	42	SECTION 82
43	SECTION 83	43	SECTION 84
44	SECTION 85	44	SECTION 86
45	SECTION 87	45	SECTION 88
46	SECTION 89	46	SECTION 90
47	SECTION 91	47	SECTION 92
48	SECTION 93	48	SECTION 94
49	SECTION 95	49	SECTION 96
50	SECTION 97	50	SECTION 98
51	SECTION 99	51	SECTION 100



NOTE:
 1. ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED.
 2. ALL DIMENSIONS ARE TO BE TAKEN TO THE CENTERLINE UNLESS OTHERWISE SPECIFIED.
 3. ALL DIMENSIONS ARE TO BE TAKEN TO THE SURFACE UNLESS OTHERWISE SPECIFIED.
 4. ALL DIMENSIONS ARE TO BE TAKEN TO THE CENTERLINE UNLESS OTHERWISE SPECIFIED.
 5. ALL DIMENSIONS ARE TO BE TAKEN TO THE SURFACE UNLESS OTHERWISE SPECIFIED.




1	GENERAL	1	GENERAL
2	SECTION 1	2	SECTION 2
3	SECTION 3	3	SECTION 4
4	SECTION 5	4	SECTION 6
5	SECTION 7	5	SECTION 8
6	SECTION 9	6	SECTION 10
7	SECTION 11	7	SECTION 12
8	SECTION 13	8	SECTION 14
9	SECTION 15	9	SECTION 16
10	SECTION 17	10	SECTION 18
11	SECTION 19	11	SECTION 20
12	SECTION 21	12	SECTION 22
13	SECTION 23	13	SECTION 24
14	SECTION 25	14	SECTION 26
15	SECTION 27	15	SECTION 28
16	SECTION 29	16	SECTION 30
17	SECTION 31	17	SECTION 32
18	SECTION 33	18	SECTION 34
19	SECTION 35	19	SECTION 36
20	SECTION 37	20	SECTION 38
21	SECTION 39	21	SECTION 40
22	SECTION 41	22	SECTION 42
23	SECTION 43	23	SECTION 44
24	SECTION 45	24	SECTION 46
25	SECTION 47	25	SECTION 48
26	SECTION 49	26	SECTION 50
27	SECTION 51	27	SECTION 52
28	SECTION 53	28	SECTION 54
29	SECTION 55	29	SECTION 56
30	SECTION 57	30	SECTION 58
31	SECTION 59	31	SECTION 60
32	SECTION 61	32	SECTION 62
33	SECTION 63	33	SECTION 64
34	SECTION 65	34	SECTION 66
35	SECTION 67	35	SECTION 68
36	SECTION 69	36	SECTION 70
37	SECTION 71	37	SECTION 72
38	SECTION 73	38	SECTION 74
39	SECTION 75	39	SECTION 76
40	SECTION 77	40	SECTION 78
41	SECTION 79	41	SECTION 80
42	SECTION 81	42	SECTION 82
43	SECTION 83	43	SECTION 84
44	SECTION 85	44	SECTION 86
45	SECTION 87	45	SECTION 88
46	SECTION 89	46	SECTION 90
47	SECTION 91	47	SECTION 92
48	SECTION 93	48	SECTION 94
49	SECTION 95	49	SECTION 96
50	SECTION 97	50	SECTION 98
51	SECTION 99	51	SECTION 100

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DIMENSIONS IN MILLIMETRES

DID NOT SCALE

PROJECTION



HARNESSES: 1x N 202-A-L-1 Downward Ax
 1x N 202-A-R-1 Downward Ax

APPROVED PURSUANT TO
 REGULATION 3.1
 OF THE CIVIL AVIATION REGULATIONS
 SIGNED *Alan P Kerr*
 (ALAN P KERR)
 DATE 3 Dec 97
 JOB NUMBER REFERENCE 706


UNITS	ISS	DATE
METRIC	1	8-3-97
DRAWN	ISS	DATE
APPROVED	ISS	DATE
SALE	ISS	DATE
AVIATION	ISS	DATE
TITLE	ISS	DATE
HARNESSES HARDWARE	ISS	DATE
SCALE	ISS	DATE
1	ISS	DATE
2	ISS	DATE

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYFOX AVIATION

DIMENSIONS IN MILLIMETRES

DO NOT SCALE

PROJECTION



APPROVED PURSUANT TO
 REGULATION 25
 OF THE CIVIL AVIATION REGULATIONS
 SIGNED *[Signature]*
 ALAN P KERR
 DATE 26/2/93
 JOB NUMBER REFERENCE

P/N	DESCR.	QTY
7	PANEL	1
6	AN970-3 WASHER	4
5	95mm x 9/16 BUSH 1/2" x 4	4
4	CW6-9 GRAPHMET	4
3	AN960-1W WASHER	4
2	AN365-3 NUT	4
1	AN3-7A BOLT	4

ISSUED BY: [Signature] DATE: [Date]


SCALE: 1:1

BRANCH: [Blank] APPROVED BY: [Blank]

TITLE: SKYFOX AVIATION INSTRUMENT PANEL HARDB.

REV: 2

CD: 018



ALL DRILLED BOLTS WERE
TO BE SAFETY WIPED

17	BOLT	AM-17A	2
16	BRAKE PLATE	BA1-3/8 (VARIES)	1
15	BRAKE SPACER	BH	4
14	BOLT (TORQUE TO 50 IN LBS.)	1/4-20X DRILLED	2
13	STATIONARY BRAKE PLATE	SNS	1
12	RIVET	4-6	6
11	BRAKE LINING	64-106	2
10	MOVABLE BRAKE SHOE	MSS	1
9	DUST PLUG	P-18	1
8	PISTON	P1-1	1
7	BRAKE BLEEDER VALVE	F6446-007	1
6	BUNA-N 'O' RING	2-222	1
5	BRAKE BLEEDER SEAT	BNS	1
4	BRAKE HOUSING	PS	1
3	CAP PLUG	2X	1
2	WASHER	AW368-01SL	6
1	NUT (TORQUE TO 50 IN LBS.)	1/4-20 NYLOCK	2


NO. PART NAME INVENTORY REL. REV'D
 3DSBRAKE HAITO Mfg 25 East Kensington Ave SALT LAKE CITY, UT 84115 (801) 466-7574

3D FIVE / SIX INCH BRAKE ASSEMBLY
 DRAWN BY: GARY P. LANFORD
 CHECKED BY:

SCALE: NONE
 DATE: DEC. 3, 1990

1 OF 1


ALL DRILLED BOLTS ARE
TO BE SAFETY WIRED



QTY	DESCRIPTION	PART NO.	REMARKS
3	NUT (TILEX LOCK 1/4-20) (TORQUE 50 IN. LBS.)	AWK3-428	
3	WASHER	AWK6-46L	
1	WHEEL (HUB HALF)	VARIES	
1	WHEEL (BRAKE HALF)	VARIES	
2	BEARING RACE	VARIES	
2	BEARING	VARIES	
2	AXLE SPACER	VARIES	
1	BRAKE DISC	DS	
3	SHCS (TORQUE 40 IN. LBS.)	1/4-20-5/8	
3	BOLT	AWA-20A (5" WHEEL) AWA-16A (6" WHEEL)	
		INVENTORY NO.	REWORK

30-WHEEL
 MATCHED TO
 65 East Kensington Ave
 SALT LAKE CITY, UT 84115 (801) 486-7574

WHEEL ASSEMBLY
 DRAWN BY: GARY P. LAWFERD
 CHECKED BY:
 SCALE: NONE
 DATE: NOV. 29, 1990
 1 OF 1



19	CAP PLUG	2X	1
18	1/4" RING BRANA N	2-012	1
17	PLUG RING BRANA N	MC-15	1
16	SNAP RING	3000-X37	1
15	CYLINDER	MC-17	1
14	WASHER	ANN60-116L	1
13	ROLL PIN	1/16 X 1 1/16	1
12	1/4" RING BRANA N	2-024	1
11	SNAP RING	3000-X125	1
10	SPRING (BOTTOM)	LC-0301C-7	1
9	PISTON	MCIP	1
8	PASSAGE BUTTON	MC-13	1
7	SPRING (SHAFT)	LC-042E-9	1
6	SHIMS	10-24X5/16	1
5	RESERVOIR COVER	MC-4	1
4	SHIM	1/4-20X1/2 SHCS	1
3	SHIM	MC-12500	1
2	JAM NUT	1/4-20	1
1	CLEVIS	MC-17	1
NO	PART NAME	INVENTORY NO	RECD

DRAWN BY: GARY P. LANGFORD
 CHECKED BY:

MASTER CYLINDER ASSEMBLY

MATCO INC.
 10110 1/2 ST. S.W.
 ANDERSON, ALA. 35606-7001





ACAD MC13

SCALE: 1" = 1/2"
 DATE: 01/20/90

3 OF 3

DRAWING CHANGES		
REV.	CHG. CHANGE NO.	DATE
1		

REVISION DESCRIPTION / REASON	
ORIGINAL	



ITEM NO.	DESCRIPTION	QTY	UNIT	REF. NO.	DATE	BY	CHKD.
1	COIL SPRING	1	EA				
2	COIL SPRING	1	EA				
3	COIL SPRING	1	EA				
4	COIL SPRING	1	EA				
5	COIL SPRING	1	EA				
6	COIL SPRING	1	EA				
7	COIL SPRING	1	EA				
8	COIL SPRING	1	EA				
9	COIL SPRING	1	EA				
10	COIL SPRING	1	EA				
11	COIL SPRING	1	EA				
12	COIL SPRING	1	EA				
13	COIL SPRING	1	EA				

GENERAL NOTE:
ALL FASTENERS ARE TO BE INSTALLED IN ACCORDANCE WITH A.C. 43-13.

SKYFOX AVIATION
BATTERY INSTALLATION
INSTALLATION DETAILS

DATE	01-04-95
SCALE	AS SHOWN
DESIGNED BY	W. J. M. PROCTOR
CHECKED BY	
APPROVED BY	

AERONAUTICAL DESIGNS AUSTRALIA PTY. LTD.
 10/172 STERLING RD. STERLING VIC 3416
 PHONE (07) 379 1001
 FAX (07) 379 1122
 AS 100
 THIS DRAWING AND THE DESIGN IT REPRESENTS ARE THE PROPERTY OF AERONAUTICAL DESIGNS AUSTRALIA PTY. LTD. IT IS TO BE KEPT IN CONFIDENCE AND NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF AERONAUTICAL DESIGNS AUSTRALIA PTY. LTD.
 Copyright © AERONAUTICAL DESIGNS AUSTRALIA PTY. LTD. All rights reserved 1995

MANUFACTURING OPERATIONS
 Reference [Except where otherwise stated]
 Between: 10.0 (0.0005)
 10-50mm (0.25-1.95) 10.0 (0.0018)
 50-125mm (1.25-5) 10.0 (0.004)
 OVER 125mm (5) 10.0 (0.008)

ANGULAR TOLERANCES (UNLESS OTHERWISE SPECIFIED)
 3° ± 0.15°
 5° ± 0.25°
 10° ± 0.5°
 15° ± 0.75°
 20° ± 1.0°
 30° ± 1.5°
 45° ± 2.25°
 60° ± 3.0°
 75° ± 3.75°
 90° ± 4.5°

WELDING
 REFER TO THE RELEVANT WELDING PROCEDURES
 W.P. 1

MATERIAL
 ALUMINUM

REVISIONS
 REVISION NO. 1 - 100% COMPLETION
 REVISION NO. 2 - 100% COMPLETION
 REVISION NO. 3 - 100% COMPLETION
 REVISION NO. 4 - 100% COMPLETION
 REVISION NO. 5 - 100% COMPLETION
 REVISION NO. 6 - 100% COMPLETION


SKYFOX AVIATION
 BATTERY INSTALLATION
 INSTALLATION DETAILS
 10813900-01

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKIDOR AVIATION

DIMENSIONS IN MILLIMETRES

DO NOT SCALE

PROJECTION



D. J. LEWELLYN
 Approved pursuant to C.A.R. 35
 at production issue No. 35
 as complying with the following
 Airworthiness Design Standard:
 302-01
 Date 27/1/93
 An authorised issuer 6256

9	SPRING CD 037-06
8	8-32 SCREENS INSTALLED WITH LOCATIVE 54
7	FUEL CAP VENT ASSY. 91-034
6	BACKPLATE CD 037-03
5	BRACKET CD 037-06
4	SPLIT PIN MS 24645-302
3	FLAP CD-037-04
2	FC 1544 FILLER NECK
1	FUEL CAP FC 2646

SCALE 1:1

DATE 19-5-97

ISS

DATE 27-01-93

PROJ NO 2097

CD

UNIT


DESIGN APPROVED

BY D

DATE

TITLE FILLER NECK VALVE ASSY.

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED OR REPRODUCED WITHOUT THE CONSENT OF SKYFOR AVIATION. DIMENSIONS IN MILLIMETRES DO NOT SCALE PROJECTION




Approved: *C.W. Whitney*
 Date: 25/5/95

1	NUT	ANS-77A
2	WASHER	ANS-514
3	WASHER	ANS-514
4	WASHER	ANS-514
5	SHAFT	ANS-20A
6	SUPPORT STRUT	ANS-20A

SCALE: 1:1 DATE: 25/5/95
 TITLE: MAIN U/C ASSEMBLY PARTS LIST
 DRAWN BY: [Signature] CHECKED BY: [Signature]
 U.C. NO: [Blank] U.C. REV: [Blank] U.C. DATE: [Blank]

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED OR REPRODUCED IN ANY MANNER WITHOUT CONSENT OF SKIFFER AVIATION


DIMENSIONS IN MILLIMETRES | DO NOT SCALE | PROJECTION



8	BUSH	AB-2-1
7	BOLT	AMS-17A
6	NUT	AMS-17A
5	BUSH	AB-2-2
4	WASHER	AM-960-S
3	BOLT	AMS-17A
2	UIC LEC	UIC-2
1	CROSS MEMBER	MSS-1

DATE: 4/9/95
 BY: [Signature]
 TITLE: [Signature]

SCALE: 1:1
 DATE: []
 DRAWING NO: UCA-1
 SHEET NO: []
 MAIN UIC ASSEMBLY PARTS LIST



① STOCK STRUT ASSEMBLY

② CROSSOVER STOCK STRUT ASSEMBLY


- WELDED JOINTS TO BE MADE TO THE FOLLOWING SPECIFICATIONS:
1. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 2. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 3. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 4. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 5. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 6. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 7. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 8. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 9. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:
 10. ALL WELDS SHALL BE MADE TO THE FOLLOWING SPECIFICATIONS:

GENERAL NOTES:
 1. ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SPECIFIED.
 2. ALL DIMENSIONS ARE TO BE TAKEN TO THE CENTERLINE UNLESS OTHERWISE SPECIFIED.
 3. ALL DIMENSIONS ARE TO BE TAKEN TO THE SURFACE UNLESS OTHERWISE SPECIFIED.

DETAIL OF PART NO. 10
 SHEET ONE
 P/N 10813210-02-03
 CABLE 1/8" 7 WIRE STAINLESS STEEL
 SWAGE RP 2172 (LOOPS) PER CURRENT MANUAL
 P/N 10813210-02-04

SKYFOX AVIATION 10813210-02	
PART NO. 10813210-02 REV. 001 DATE 03/05/98	QUANTITY 1000 UNIT PRICE \$1.13 TOTAL \$1130.00
ORDER NO. 10813210-02 ORDER DATE 03/05/98 ORDER TIME 10:00 AM	SKYFOX AVIATION 10813210-02 10813210-02
ORDERED BY: [Signature] ORDERED DATE: 03/05/98 ORDERED TIME: 10:00 AM	ORDERED BY: [Signature] ORDERED DATE: 03/05/98 ORDERED TIME: 10:00 AM

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED | DIMENSIONS IN MILLIMETERS | DO NOT SCALE | PROJECTION




12	Kudaak Peov	
11	doort	
10	CLAMP	SLF-1
9	FLANGE	C 141
8	SKIN	M52445-151
7	SPLIT PIN	AV 310-3
6	NUT	AV 410-10
5	WASHER	AV 310-3
4	BOIT	AV 310-3
3	STRAKKE	KF 614
2	NOSE LEG	
1	STEERING ARM	

PROJECTED DRAWING TO THE STEERING ASSEMBLY
 P. M. M. M. M.
 4/1/95

SOON P.L. STEERING ASSEMBLY L/H
 SCALE 1:1
 DATE 18/5/95
 DRAWING NO S.A-3

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED DIMENSIONS IN MILLIMETRES DO NOT SCALE PROJECTION WITHOUT CONSENT OF SKYFOR AVIATION




13	CLAMP	MS24665-151
12	SPLIT PIN	AN 310-3
11	NUT	AN 960-10
10	WASHER	AN 31-5
9	BOLT	AN 31-5
8	HEAT SLEEVE	
7	ROCKLE PEARL ASSEMBLY	RF 614
6	SHOCKLE	C191
5	SPRING	SLP-1
4	FLANGE	TAL-1
3	LINKAGE	
2	NOSE LEG	
1	STEERING ARM	

APPROVED FOR THE SKYFOR AVIATION

C. J. Whiting
 4/17/95

SCALE 1:1 ISS DATE 14/5/95
 DRAWING NO SA-2
 SKYFOR AVIATION
 STEERING ASSEMBLY R.H.

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKFEX, A DIVISION OF SKF CORPORATION
 DIMENSIONS IN MILLIMETRES DO NOT SCALE PROJECTION




7	NUT	AN 365-3
6	CLAMP	AN 960-10
5	WASHER	AN 3-4A
4	BOLT	T 234
3	BRACKET	
2	SPRING	
1	RUDDER PEDAL	

APPROVED FOR THE COMPANY
 DATE 5/17/45
 R. W. White
 DESIGNER

SCALE: 1" = 1" CITYRY
 SHEET NO. 26
 RUDDER RETURN L/H
 PROJECT NO. RR-2

<p>1. TITLE: SKYFOX AVIATION</p> <p>2. DRAWING NO.: 10813220-04</p> <p>3. DATE: 3-5-48</p> <p>4. DESIGNED BY: <i>L. W. M. [Signature]</i></p> <p>5. CHECKED BY: <i>[Signature]</i></p>		<p>6. MANUFACTURING OPERATIONS:</p> <p>7. MATERIALS:</p> <p>8. DIMENSIONS IN INCHES:</p> <p>9. FINISHES:</p> <p>10. WEIGHTS:</p> <p>11. PARTS LIST:</p>		<p>12. MANUFACTURER'S SPECIFICATIONS:</p> <p>13. TOLERANCES:</p> <p>14. FINISHES:</p> <p>15. WEIGHTS:</p> <p>16. PARTS LIST:</p>	
<p>17. MANUFACTURING OPERATIONS:</p> <p>18. MATERIALS:</p> <p>19. DIMENSIONS IN INCHES:</p> <p>20. FINISHES:</p> <p>21. WEIGHTS:</p> <p>22. PARTS LIST:</p>		<p>23. MANUFACTURER'S SPECIFICATIONS:</p> <p>24. TOLERANCES:</p> <p>25. FINISHES:</p> <p>26. WEIGHTS:</p> <p>27. PARTS LIST:</p>		<p>28. MANUFACTURING OPERATIONS:</p> <p>29. MATERIALS:</p> <p>30. DIMENSIONS IN INCHES:</p> <p>31. FINISHES:</p> <p>32. WEIGHTS:</p> <p>33. PARTS LIST:</p>	
<p>34. MANUFACTURING OPERATIONS:</p> <p>35. MATERIALS:</p> <p>36. DIMENSIONS IN INCHES:</p> <p>37. FINISHES:</p> <p>38. WEIGHTS:</p> <p>39. PARTS LIST:</p>		<p>40. MANUFACTURER'S SPECIFICATIONS:</p> <p>41. TOLERANCES:</p> <p>42. FINISHES:</p> <p>43. WEIGHTS:</p> <p>44. PARTS LIST:</p>		<p>45. MANUFACTURING OPERATIONS:</p> <p>46. MATERIALS:</p> <p>47. DIMENSIONS IN INCHES:</p> <p>48. FINISHES:</p> <p>49. WEIGHTS:</p> <p>50. PARTS LIST:</p>	
<p>51. MANUFACTURING OPERATIONS:</p> <p>52. MATERIALS:</p> <p>53. DIMENSIONS IN INCHES:</p> <p>54. FINISHES:</p> <p>55. WEIGHTS:</p> <p>56. PARTS LIST:</p>		<p>57. MANUFACTURER'S SPECIFICATIONS:</p> <p>58. TOLERANCES:</p> <p>59. FINISHES:</p> <p>60. WEIGHTS:</p> <p>61. PARTS LIST:</p>		<p>62. MANUFACTURING OPERATIONS:</p> <p>63. MATERIALS:</p> <p>64. DIMENSIONS IN INCHES:</p> <p>65. FINISHES:</p> <p>66. WEIGHTS:</p> <p>67. PARTS LIST:</p>	
<p>68. MANUFACTURING OPERATIONS:</p> <p>69. MATERIALS:</p> <p>70. DIMENSIONS IN INCHES:</p> <p>71. FINISHES:</p> <p>72. WEIGHTS:</p> <p>73. PARTS LIST:</p>		<p>74. MANUFACTURER'S SPECIFICATIONS:</p> <p>75. TOLERANCES:</p> <p>76. FINISHES:</p> <p>77. WEIGHTS:</p> <p>78. PARTS LIST:</p>		<p>79. MANUFACTURING OPERATIONS:</p> <p>80. MATERIALS:</p> <p>81. DIMENSIONS IN INCHES:</p> <p>82. FINISHES:</p> <p>83. WEIGHTS:</p> <p>84. PARTS LIST:</p>	
<p>85. MANUFACTURING OPERATIONS:</p> <p>86. MATERIALS:</p> <p>87. DIMENSIONS IN INCHES:</p> <p>88. FINISHES:</p> <p>89. WEIGHTS:</p> <p>90. PARTS LIST:</p>		<p>91. MANUFACTURER'S SPECIFICATIONS:</p> <p>92. TOLERANCES:</p> <p>93. FINISHES:</p> <p>94. WEIGHTS:</p> <p>95. PARTS LIST:</p>		<p>96. MANUFACTURING OPERATIONS:</p> <p>97. MATERIALS:</p> <p>98. DIMENSIONS IN INCHES:</p> <p>99. FINISHES:</p> <p>100. WEIGHTS:</p> <p>101. PARTS LIST:</p>	
<p>102. MANUFACTURING OPERATIONS:</p> <p>103. MATERIALS:</p> <p>104. DIMENSIONS IN INCHES:</p> <p>105. FINISHES:</p> <p>106. WEIGHTS:</p> <p>107. PARTS LIST:</p>		<p>108. MANUFACTURER'S SPECIFICATIONS:</p> <p>109. TOLERANCES:</p> <p>110. FINISHES:</p> <p>111. WEIGHTS:</p> <p>112. PARTS LIST:</p>		<p>113. MANUFACTURING OPERATIONS:</p> <p>114. MATERIALS:</p> <p>115. DIMENSIONS IN INCHES:</p> <p>116. FINISHES:</p> <p>117. WEIGHTS:</p> <p>118. PARTS LIST:</p>	
<p>119. MANUFACTURING OPERATIONS:</p> <p>120. MATERIALS:</p> <p>121. DIMENSIONS IN INCHES:</p> <p>122. FINISHES:</p> <p>123. WEIGHTS:</p> <p>124. PARTS LIST:</p>		<p>125. MANUFACTURER'S SPECIFICATIONS:</p> <p>126. TOLERANCES:</p> <p>127. FINISHES:</p> <p>128. WEIGHTS:</p> <p>129. PARTS LIST:</p>		<p>130. MANUFACTURING OPERATIONS:</p> <p>131. MATERIALS:</p> <p>132. DIMENSIONS IN INCHES:</p> <p>133. FINISHES:</p> <p>134. WEIGHTS:</p> <p>135. PARTS LIST:</p>	
<p>136. MANUFACTURING OPERATIONS:</p> <p>137. MATERIALS:</p> <p>138. DIMENSIONS IN INCHES:</p> <p>139. FINISHES:</p> <p>140. WEIGHTS:</p> <p>141. PARTS LIST:</p>		<p>142. MANUFACTURER'S SPECIFICATIONS:</p> <p>143. TOLERANCES:</p> <p>144. FINISHES:</p> <p>145. WEIGHTS:</p> <p>146. PARTS LIST:</p>		<p>147. MANUFACTURING OPERATIONS:</p> <p>148. MATERIALS:</p> <p>149. DIMENSIONS IN INCHES:</p> <p>150. FINISHES:</p> <p>151. WEIGHTS:</p> <p>152. PARTS LIST:</p>	
<p>153. MANUFACTURING OPERATIONS:</p> <p>154. MATERIALS:</p> <p>155. DIMENSIONS IN INCHES:</p> <p>156. FINISHES:</p> <p>157. WEIGHTS:</p> <p>158. PARTS LIST:</p>		<p>159. MANUFACTURER'S SPECIFICATIONS:</p> <p>160. TOLERANCES:</p> <p>161. FINISHES:</p> <p>162. WEIGHTS:</p> <p>163. PARTS LIST:</p>		<p>164. MANUFACTURING OPERATIONS:</p> <p>165. MATERIALS:</p> <p>166. DIMENSIONS IN INCHES:</p> <p>167. FINISHES:</p> <p>168. WEIGHTS:</p> <p>169. PARTS LIST:</p>	
<p>170. MANUFACTURING OPERATIONS:</p> <p>171. MATERIALS:</p> <p>172. DIMENSIONS IN INCHES:</p> <p>173. FINISHES:</p> <p>174. WEIGHTS:</p> <p>175. PARTS LIST:</p>		<p>176. MANUFACTURER'S SPECIFICATIONS:</p> <p>177. TOLERANCES:</p> <p>178. FINISHES:</p> <p>179. WEIGHTS:</p> <p>180. PARTS LIST:</p>		<p>181. MANUFACTURING OPERATIONS:</p> <p>182. MATERIALS:</p> <p>183. DIMENSIONS IN INCHES:</p> <p>184. FINISHES:</p> <p>185. WEIGHTS:</p> <p>186. PARTS LIST:</p>	
<p>187. MANUFACTURING OPERATIONS:</p> <p>188. MATERIALS:</p> <p>189. DIMENSIONS IN INCHES:</p> <p>190. FINISHES:</p> <p>191. WEIGHTS:</p> <p>192. PARTS LIST:</p>		<p>193. MANUFACTURER'S SPECIFICATIONS:</p> <p>194. TOLERANCES:</p> <p>195. FINISHES:</p> <p>196. WEIGHTS:</p> <p>197. PARTS LIST:</p>		<p>198. MANUFACTURING OPERATIONS:</p> <p>199. MATERIALS:</p> <p>200. DIMENSIONS IN INCHES:</p> <p>201. FINISHES:</p> <p>202. WEIGHTS:</p> <p>203. PARTS LIST:</p>	
<p>204. MANUFACTURING OPERATIONS:</p> <p>205. MATERIALS:</p> <p>206. DIMENSIONS IN INCHES:</p> <p>207. FINISHES:</p> <p>208. WEIGHTS:</p> <p>209. PARTS LIST:</p>		<p>210. MANUFACTURER'S SPECIFICATIONS:</p> <p>211. TOLERANCES:</p> <p>212. FINISHES:</p> <p>213. WEIGHTS:</p> <p>214. PARTS LIST:</p>		<p>215. MANUFACTURING OPERATIONS:</p> <p>216. MATERIALS:</p> <p>217. DIMENSIONS IN INCHES:</p> <p>218. FINISHES:</p> <p>219. WEIGHTS:</p> <p>220. PARTS LIST:</p>	
<p>221. MANUFACTURING OPERATIONS:</p> <p>222. MATERIALS:</p> <p>223. DIMENSIONS IN INCHES:</p> <p>224. FINISHES:</p> <p>225. WEIGHTS:</p> <p>226. PARTS LIST:</p>		<p>227. MANUFACTURER'S SPECIFICATIONS:</p> <p>228. TOLERANCES:</p> <p>229. FINISHES:</p> <p>230. WEIGHTS:</p> <p>231. PARTS LIST:</p>		<p>232. MANUFACTURING OPERATIONS:</p> <p>233. MATERIALS:</p> <p>234. DIMENSIONS IN INCHES:</p> <p>235. FINISHES:</p> <p>236. WEIGHTS:</p> <p>237. PARTS LIST:</p>	
<p>238. MANUFACTURING OPERATIONS:</p> <p>239. MATERIALS:</p> <p>240. DIMENSIONS IN INCHES:</p> <p>241. FINISHES:</p> <p>242. WEIGHTS:</p> <p>243. PARTS LIST:</p>		<p>244. MANUFACTURER'S SPECIFICATIONS:</p> <p>245. TOLERANCES:</p> <p>246. FINISHES:</p> <p>247. WEIGHTS:</p> <p>248. PARTS LIST:</p>		<p>249. MANUFACTURING OPERATIONS:</p> <p>250. MATERIALS:</p> <p>251. DIMENSIONS IN INCHES:</p> <p>252. FINISHES:</p> <p>253. WEIGHTS:</p> <p>254. PARTS LIST:</p>	
<p>255. MANUFACTURING OPERATIONS:</p> <p>256. MATERIALS:</p> <p>257. DIMENSIONS IN INCHES:</p> <p>258. FINISHES:</p> <p>259. WEIGHTS:</p> <p>260. PARTS LIST:</p>		<p>261. MANUFACTURER'S SPECIFICATIONS:</p> <p>262. TOLERANCES:</p> <p>263. FINISHES:</p> <p>264. WEIGHTS:</p> <p>265. PARTS LIST:</p>		<p>266. MANUFACTURING OPERATIONS:</p> <p>267. MATERIALS:</p> <p>268. DIMENSIONS IN INCHES:</p> <p>269. FINISHES:</p> <p>270. WEIGHTS:</p> <p>271. PARTS LIST:</p>	
<p>272. MANUFACTURING OPERATIONS:</p> <p>273. MATERIALS:</p> <p>274. DIMENSIONS IN INCHES:</p> <p>275. FINISHES:</p> <p>276. WEIGHTS:</p> <p>277. PARTS LIST:</p>		<p>278. MANUFACTURER'S SPECIFICATIONS:</p> <p>279. TOLERANCES:</p> <p>280. FINISHES:</p> <p>281. WEIGHTS:</p> <p>282. PARTS LIST:</p>		<p>283. MANUFACTURING OPERATIONS:</p> <p>284. MATERIALS:</p> <p>285. DIMENSIONS IN INCHES:</p> <p>286. FINISHES:</p> <p>287. WEIGHTS:</p> <p>288. PARTS LIST:</p>	
<p>289. MANUFACTURING OPERATIONS:</p> <p>290. MATERIALS:</p> <p>291. DIMENSIONS IN INCHES:</p> <p>292. FINISHES:</p> <p>293. WEIGHTS:</p> <p>294. PARTS LIST:</p>		<p>295. MANUFACTURER'S SPECIFICATIONS:</p> <p>296. TOLERANCES:</p> <p>297. FINISHES:</p> <p>298. WEIGHTS:</p> <p>299. PARTS LIST:</p>		<p>300. MANUFACTURING OPERATIONS:</p> <p>301. MATERIALS:</p> <p>302. DIMENSIONS IN INCHES:</p> <p>303. FINISHES:</p> <p>304. WEIGHTS:</p> <p>305. PARTS LIST:</p>	
<p>306. MANUFACTURING OPERATIONS:</p> <p>307. MATERIALS:</p> <p>308. DIMENSIONS IN INCHES:</p> <p>309. FINISHES:</p> <p>310. WEIGHTS:</p> <p>311. PARTS LIST:</p>		<p>312. MANUFACTURER'S SPECIFICATIONS:</p> <p>313. TOLERANCES:</p> <p>314. FINISHES:</p> <p>315. WEIGHTS:</p> <p>316. PARTS LIST:</p>		<p>317. MANUFACTURING OPERATIONS:</p> <p>318. MATERIALS:</p> <p>319. DIMENSIONS IN INCHES:</p> <p>320. FINISHES:</p> <p>321. WEIGHTS:</p> <p>322. PARTS LIST:</p>	
<p>323. MANUFACTURING OPERATIONS:</p> <p>324. MATERIALS:</p> <p>325. DIMENSIONS IN INCHES:</p> <p>326. FINISHES:</p> <p>327. WEIGHTS:</p> <p>328. PARTS LIST:</p>		<p>329. MANUFACTURER'S SPECIFICATIONS:</p> <p>330. TOLERANCES:</p> <p>331. FINISHES:</p> <p>332. WEIGHTS:</p> <p>333. PARTS LIST:</p>		<p>334. MANUFACTURING OPERATIONS:</p> <p>335. MATERIALS:</p> <p>336. DIMENSIONS IN INCHES:</p> <p>337. FINISHES:</p> <p>338. WEIGHTS:</p> <p>339. PARTS LIST:</p>	
<p>340. MANUFACTURING OPERATIONS:</p> <p>341. MATERIALS:</p> <p>342. DIMENSIONS IN INCHES:</p> <p>343. FINISHES:</p> <p>344. WEIGHTS:</p> <p>345. PARTS LIST:</p>		<p>346. MANUFACTURER'S SPECIFICATIONS:</p> <p>347. TOLERANCES:</p> <p>348. FINISHES:</p> <p>349. WEIGHTS:</p> <p>350. PARTS LIST:</p>		<p>351. MANUFACTURING OPERATIONS:</p> <p>352. MATERIALS:</p> <p>353. DIMENSIONS IN INCHES:</p> <p>354. FINISHES:</p> <p>355. WEIGHTS:</p> <p>356. PARTS LIST:</p>	
<p>357. MANUFACTURING OPERATIONS:</p> <p>358. MATERIALS:</p> <p>359. DIMENSIONS IN INCHES:</p> <p>360. FINISHES:</p> <p>361. WEIGHTS:</p> <p>362. PARTS LIST:</p>		<p>363. MANUFACTURER'S SPECIFICATIONS:</p> <p>364. TOLERANCES:</p> <p>365. FINISHES:</p> <p>366. WEIGHTS:</p> <p>367. PARTS LIST:</p>		<p>368. MANUFACTURING OPERATIONS:</p> <p>369. MATERIALS:</p> <p>370. DIMENSIONS IN INCHES:</p> <p>371. FINISHES:</p> <p>372. WEIGHTS:</p> <p>373. PARTS LIST:</p>	
<p>374. MANUFACTURING OPERATIONS:</p> <p>375. MATERIALS:</p> <p>376. DIMENSIONS IN INCHES:</p> <p>377. FINISHES:</p> <p>378. WEIGHTS:</p> <p>379. PARTS LIST:</p>		<p>380. MANUFACTURER'S SPECIFICATIONS:</p> <p>381. TOLERANCES:</p> <p>382. FINISHES:</p> <p>383. WEIGHTS:</p> <p>384. PARTS LIST:</p>		<p>385. MANUFACTURING OPERATIONS:</p> <p>386. MATERIALS:</p> <p>387. DIMENSIONS IN INCHES:</p> <p>388. FINISHES:</p> <p>389. WEIGHTS:</p> <p>390. PARTS LIST:</p>	
<p>391. MANUFACTURING OPERATIONS:</p> <p>392. MATERIALS:</p> <p>393. DIMENSIONS IN INCHES:</p> <p>394. FINISHES:</p> <p>395. WEIGHTS:</p> <p>396. PARTS LIST:</p>		<p>397. MANUFACTURER'S SPECIFICATIONS:</p> <p>398. TOLERANCES:</p> <p>399. FINISHES:</p> <p>400. WEIGHTS:</p> <p>401. PARTS LIST:</p>		<p>402. MANUFACTURING OPERATIONS:</p> <p>403. MATERIALS:</p> <p>404. DIMENSIONS IN INCHES:</p> <p>405. FINISHES:</p> <p>406. WEIGHTS:</p> <p>407. PARTS LIST:</p>	
<p>408. MANUFACTURING OPERATIONS:</p> <p>409. MATERIALS:</p> <p>410. DIMENSIONS IN INCHES:</p> <p>411. FINISHES:</p> <p>412. WEIGHTS:</p> <p>413. PARTS LIST:</p>		<p>414. MANUFACTURER'S SPECIFICATIONS:</p> <p>415. TOLERANCES:</p> <p>416. FINISHES:</p> <p>417. WEIGHTS:</p> <p>418. PARTS LIST:</p>		<p>419. MANUFACTURING OPERATIONS:</p> <p>420. MATERIALS:</p> <p>421. DIMENSIONS IN INCHES:</p> <p>422. FINISHES:</p> <p>423. WEIGHTS:</p> <p>424. PARTS LIST:</p>	
<p>425. MANUFACTURING OPERATIONS:</p> <p>426. MATERIALS:</p> <p>427. DIMENSIONS IN INCHES:</p> <p>428. FINISHES:</p> <p>429. WEIGHTS:</p> <p>430. PARTS LIST:</p>		<p>431. MANUFACTURER'S SPECIFICATIONS:</p> <p>432. TOLERANCES:</p> <p>433. FINISHES:</p> <p>434. WEIGHTS:</p> <p>435. PARTS LIST:</p>		<p>436. MANUFACTURING OPERATIONS:</p> <p>437. MATERIALS:</p> <p>438. DIMENSIONS IN INCHES:</p> <p>439. FINISHES:</p> <p>440. WEIGHTS:</p> <p>441. PARTS LIST:</p>	
<p>442. MANUFACTURING OPERATIONS:</p> <p>443. MATERIALS:</p> <p>444. DIMENSIONS IN INCHES:</p> <p>445. FINISHES:</p> <p>446. WEIGHTS:</p> <p>447. PARTS LIST:</p>		<p>448. MANUFACTURER'S SPECIFICATIONS:</p> <p>449. TOLERANCES:</p> <p>450. FINISHES:</p> <p>451. WEIGHTS:</p> <p>452. PARTS LIST:</p>		<p>453. MANUFACTURING OPERATIONS:</p> <p>454. MATERIALS:</p> <p>455. DIMENSIONS IN INCHES:</p> <p>456. FINISHES:</p> <p>457. WEIGHTS:</p> <p>458. PARTS LIST:</p>	
<p>459. MANUFACTURING OPERATIONS:</p> <p>460. MATERIALS:</p> <p>461. DIMENSIONS IN INCHES:</p> <p>462. FINISHES:</p> <p>463. WEIGHTS:</p> <p>464. PARTS LIST:</p>		<p>465. MANUFACTURER'S SPECIFICATIONS:</p> <p>466. TOLERANCES:</p> <p>467. FINISHES:</p> <p>468. WEIGHTS:</p> <p>469. PARTS LIST:</p>		<p>470. MANUFACTURING OPERATIONS:</p> <p>471. MATERIALS:</p> <p>472. DIMENSIONS IN INCHES:</p> <p>473. FINISHES:</p> <p>474. WEIGHTS:</p> <p>475. PARTS LIST:</p>	
<p>476. MANUFACTURING OPERATIONS:</p> <p>477. MATERIALS:</p> <p>478. DIMENSIONS IN INCHES:</p> <p>479. FINISHES:</p> <p>480. WEIGHTS:</p> <p>481. PARTS LIST:</p>		<p>482. MANUFACTURER'S SPECIFICATIONS:</p> <p>483. TOLERANCES:</p> <p>484. FINISHES:</p> <p>485. WEIGHTS:</p> <p>486. PARTS LIST:</p>		<p>487. MANUFACTURING OPERATIONS:</p> <p>488. MATERIALS:</p> <p>489. DIMENSIONS IN INCHES:</p> <p>490. FINISHES:</p> <p>491. WEIGHTS:</p> <p>492. PARTS LIST:</p>	
<p>493. MANUFACTURING OPERATIONS:</p> <p>494. MATERIALS:</p> <p>495. DIMENSIONS IN INCHES:</p> <p>496. FINISHES:</p> <p>497. WEIGHTS:</p> <p>498. PARTS LIST:</p>		<p>499. MANUFACTURER'S SPECIFICATIONS:</p> <p>500. TOLERANCES:</p> <p>501. FINISHES:</p> <p>502. WEIGHTS:</p> <p>503. PARTS LIST:</p>		<p>504. MANUFACTURING OPERATIONS:</p> <p>505. MATERIALS:</p> <p>506. DIMENSIONS IN INCHES:</p> <p>507. FINISHES:</p> <p>508. WEIGHTS:</p> <p>509. PARTS LIST:</p>	
<p>510. MANUFACTURING OPERATIONS:</p> <p>511. MATERIALS:</p> <p>512. DIMENSIONS IN INCHES:</p> <p>513. FINISHES:</p> <p>514. WEIGHTS:</p> <p>515. PARTS LIST:</p>		<p>516. MANUFACTURER'S SPECIFICATIONS:</p> <p>517. TOLERANCES:</p> <p>518. FINISHES:</p> <p>519. WEIGHTS:</p> <p>520. PARTS LIST:</p>		<p>521. MANUFACTURING OPERATIONS:</p> <p>522. MATERIALS:</p> <p>523. DIMENSIONS IN INCHES:</p> <p>524. FINISHES:</p> <p>525. WEIGHTS:</p> <p>526. PARTS LIST:</p>	
<p>527. MANUFACTURING OPERATIONS:</p> <p>528. MATERIALS:</p> <p>529. DIMENSIONS IN INCHES:</p> <p>530. FINISHES:</p> <p>531. WEIGHTS:</p> <p>532. PARTS LIST:</p>		<p>533. MANUFACTURER'S SPECIFICATIONS:</p> <p>534. TOLERANCES:</p> <p>535. FINISHES:</p> <p>536. WEIGHTS:</p> <p>537. PARTS LIST:</p>		<p>538. MANUFACTURING OPERATIONS:</p> <p>539. MATERIALS:</p> <p>540. DIMENSIONS IN INCHES:</p> <p>541. FINISHES:</p> <p>542. WEIGHTS:</p> <p>543. PARTS LIST:</p>	
<p>544. MANUFACTURING OPERATIONS:</p> <p>545. MATERIALS:</p> <p>546. DIMENSIONS IN INCHES:</p> <p>547. FINISHES:</p> <p>548. WEIGHTS:</p> <p>549. PARTS LIST:</p>		<p>550. MANUFACTURER'S SPECIFICATIONS:</p> <p>551. TOLERANCES:</p> <p>552. FINISHES:</p> <p>553. WEIGHTS:</p> <p>554. PARTS LIST:</p>		<p>555. MANUFACTURING OPERATIONS:</p> <p>556. MATERIALS:</p> <p>557. DIMENSIONS IN INCHES:</p> <p>558. FINISHES:</p> <p>559. WEIGHTS:</p> <p>560. PARTS LIST:</p>	
<p>561. MANUFACTURING OPERATIONS:</p> <p>562. MATERIALS:</p> <p>563. DIMENSIONS IN INCHES:</p> <p>564. FINISHES:</p> <p>565. WEIGHTS:</p> <p>566. PARTS LIST:</p>		<p>567. MANUFACTURER'S SPECIFICATIONS:</p> <p>568. TOLERANCES:</p> <p>569. FINISHES:</p> <p>570. WEIGHTS:</p> <p>571. PARTS LIST:</p>		<p>572. MANUFACTURING OPERATIONS:</p> <p>573. MATERIALS:</p> <p>574. DIMENSIONS IN INCHES:</p> <p>575. FINISHES:</p> <p>576. WEIGHTS:</p> <p>577. PARTS LIST:</p>	
<p>578. MANUFACTURING OPERATIONS:</p> <p>579. MATERIALS:</p> <p>580. DIMENSIONS IN INCHES:</p> <p>581. FINISHES:</p> <p>582. WEIGHTS:</p> <p>583. PARTS LIST:</p>		<p>584. MANUFACTURER'S SPECIFICATIONS:</p> <p>585. TOLERANCES:</p> <p>586. FINISHES:</p> <p>587. WEIGHTS:</p> <p>588. PARTS LIST:</p>		<p>589. MANUFACTURING OPERATIONS:</p> <p>590. MATERIALS:</p> <p>591. DIMENSIONS IN INCHES:</p> <p>592. FINISHES:</p> <p>593. WEIGHTS:</p> <p>594. PARTS LIST:</p>	
<p>595. MANUFACTURING OPERATIONS:</p> <p>596. MATERIALS:</p> <p>597. DIMENSIONS IN INCHES:</p> <p>598. FINISHES:</p> <p>599. WEIGHTS:</p> <p>600. PARTS LIST:</p>		<p>601. MANUFACTURER'S SPECIFICATIONS:</p> <p>602. TOLERANCES:</p> <p>603. FINISHES:</p> <p>604. WEIGHTS:</p> <p>605. PARTS LIST:</p>		<p>606. MANUFACTURING OPERATIONS:</p> <p>607. MATERIALS:</p> <p>608. DIMENSIONS IN INCHES:</p> <p>609. FINISHES:</p> <p>610. WEIGHTS:</p> <p>611. PARTS LIST:</p>	
<p>612. MANUFACTURING OPERATIONS:</p> <p>613. MATERIALS:</p> <p>614. DIMENSIONS IN INCHES:</p> <p>615. FINISHES:</p> <p>616. WEIGHTS:</p> <p>617. PARTS LIST:</p>		<p>618. MANUFACTURER'S SPECIFICATIONS:</p> <p>619. TOLERANCES:</p> <p>620. FINISHES:</p> <p>621. WEIGHTS:</p> <p>622. PARTS LIST:</p>		<p>623. MANUFACTURING OPERATIONS:</p> <p>624. MATERIALS:</p> <p>625. DIMENSIONS IN INCHES:</p> <p>626. FINISHES:</p> <p>627. WEIGHTS:</p> <p>628. PARTS LIST:</p>	
<p>629. MANUFACTURING OPERATIONS:</p> <p>630. MATERIALS:</p> <p>631. DIMENSIONS IN INCHES:</p> <p>632. FINISHES:</p> <p>633. WEIGHTS:</p> <p>634. PARTS LIST:</p>		<p>635. MANUFACTURER'S SPECIFICATIONS:</p> <p>636. TOLERANCES:</p> <p>637. FINISHES:</p> <p>638. WEIGHTS:</p> <p>639. PARTS LIST:</p>		<p>640. MANUFACTURING OPERATIONS:</p> <p>641. MATERIALS:</p> <p>642. DIMENSIONS IN INCHES:</p> <p>643. FINISHES:</p> <p>644. WEIGHTS:</p> <p>645. PARTS LIST:</p>	
<p>646. MANUFACTURING OPERATIONS:</p> <p>647. MATERIALS:</p> <p>648. DIMENSIONS IN INCHES:</p> <p>649. FINISHES:</p> <p>650. WEIGHTS:</p> <p>651. PARTS LIST:</p>		<p>652. MANUFACTURER'S SPECIFICATIONS:</p> <p>653. TOLERANCES:</p> <p>654. FINISHES:</p> <p>655. WEIGHTS:</p> <p>656. PARTS LIST:</p>		<p>657. MANUFACTURING OPERATIONS:</p> <p>658. MATERIALS:</p> <p>659. DIMENSIONS IN INCHES:</p> <p>660. FINISHES:</p> <p>661. WEIGHTS:</p> <p>662. PARTS LIST:</p>	
<p>663. MANUFACTURING OPERATIONS:</p> <p>664. MATERIALS:</p> <p>665. DIMENSIONS IN INCHES:</p> <p>666. FINISHES:</p> <p>667. WEIGHTS:</p> <p>668. PARTS LIST:</p>		<p>669. MANUFACTURER'S SPECIFICATIONS:</p> <p>670. TOLERANCES:</p> <p>671. FINISHES:</p> <p>672. WEIGHTS:</p> <p>673. PARTS LIST:</p>		<p>674. MANUFACTURING OPERATIONS:</p> <p>675. MATERIALS:</p> <p>676. DIMENSIONS IN INCHES:</p> <p>677. FINISHES:</p> <p>678. WEIGHTS:</p> <p>679. PARTS LIST:</p>	
<p>680. MANUFACTURING OPERATIONS:</p> <p>681. MATERIALS:</p> <p>682. DIMENSIONS IN INCHES:</p> <p>683. FINISHES:</p> <p>684. WEIGHTS:</p> <p>685. PARTS LIST:</p>		<p>686. MANUFACTURER'S SPECIFICATIONS:</p> <p>687. TOLERANCES:</p> <p>688. FINISHES:</p> <p>689. WEIGHTS:</p> <p>690. PARTS LIST:</p>		<p>691. MANUFACTURING OPERATIONS:</p> <p>692. MATERIALS:</p> <p>693. DIMENSIONS IN INCHES:</p> <p>694. FINISHES:</p> <p>695. WEIGHTS:</p> <p>696. PARTS LIST:</p>	
<p>697. MANUFACTURING OPERATIONS:</p> <p>698. MATERIALS:</p> <p>699. DIMENSIONS IN INCHES:</p> <p>700. FINISHES:</p> <p>701. WEIGHTS:</p> <p>702. PARTS LIST:</p>		<p>703. MANUFACTURER'S SPECIFICATIONS:</p> <p>704. TOLERANCES:</p> <p>705. FINISHES:</p> <p>706. WEIGHTS:</p> <p>707. PARTS LIST:</p>		<p>708. MANUFACTURING OPERATIONS:</p> <p>709. MATERIALS:</p> <p>710. DIMENSIONS IN INCHES:</p> <p>711. FINISHES:</p> <p>712. WEIGHTS:</p> <p>713. PARTS LIST:</p>	
<p>714. MANUFACTURING OPERATIONS:</p> <p>715. MATERIALS:</p> <p>716. DIMENSIONS IN INCHES:</p> <p>717. FINISHES:</p> <p>718. WEIGHTS:</p> <p>719. PARTS LIST:</p>		<p>720. MANUFACTURER'S SPECIFICATIONS:</p> <p>721. TOLERANCES:</p> <p>722. FINISHES:</p> <p>723. WEIGHTS:</p> <p>724. PARTS LIST:</p>		<p>725. MANUFACTURING OPERATIONS:</p> <p>726. MATERIALS:</p> <p>727. DIMENSIONS IN INCHES:</p> <p>728. FINISHES:</p> <p>729. WEIGHTS:</p> <p>730. PARTS LIST:</p>	
<p>731. MANUFACTURING OPERATIONS:</p> <p>732. MATERIALS:</p> <p>733. DIMENSIONS IN INCHES:</p> <p>734. FINISHES:</p> <p>735. WEIGHTS:</p> <p>736. PARTS LIST:</p>		<p>737. MANUFACTURER'S SPECIFICATIONS:</p> <p>738. TOLERANCES:</p> <p>739. FINISHES:</p> <p>740. WEIGHTS:</p> <p>741. PARTS LIST:</p>		<p>742. MANUFACTURING OPERATIONS:</p> <p>743. MATERIALS:</p> <p>744. DIMENSIONS IN INCHES:</p> <p>745. FINISHES:</p> <p>746. WEIGHTS:</p> <p>747. PARTS LIST:</p>	
<p>748. MANUFACTURING OPERATIONS:</p> <p>749. MATERIALS:</p> <p>750. DIMENSIONS IN INCHES:</p> <p>751. FINISHES:</p> <p>752. WEIGHTS:</p> <p>753. PARTS LIST:</p>		<p>754. MANUFACTURER'S SPECIFICATIONS:</p> <p>755. TOLERANCES:</p> <p>756. FINISHES:</p> <p>757. WEIGHTS:</p> <p>758. PARTS LIST:</p>		<p>759. MANUFACTURING OPERATIONS:</p> <p>760. MATERIALS:</p> <p>761. DIMENSIONS IN INCHES:</p> <p>762. FINISHES:</p> <p>763. WEIGHTS:</p> <p>764. PARTS LIST:</p>	
<p>765. MANUFACTURING OPERATIONS:</p> <p>766. MATERIALS:</p> <p>767. DIMENSIONS IN INCHES:</p> <p>768. FINISHES:</p> <p>769. WEIGHTS:</p> <p>770. PARTS LIST:</p>		<p>771. MANUFACTURER'S SPECIFICATIONS:</p> <p>772. TOLERANCES:</p> <p>773. FINISHES:</p> <p>774. WEIGHTS:</p> <p>775. PARTS LIST:</p>		<p>776. MANUFACTURING OPERATIONS:</p> <p>777. MATERIALS:</p> <p>778. DIMENSIONS IN INCHES:</p> <p>779. FINISHES:</p> <p>780. WEIGHTS:</p> <p>781. PARTS LIST:</p>	
<p>782. MANUFACTURING OPERATIONS:</p> <p>783. MATERIALS:</p> <p>784. DIMENSIONS IN INCHES:</p> <p>785. FINISHES:</p> <p>7</p>					



REV.	DESCRIPTION	DATE
1	ISSUED FOR PRODUCTION	10/1/58
2	REVISION TO DRAWING	10/1/58
3	REVISION TO DRAWING	10/1/58

SKYFOX AVIATION

PROJECT: SKYFOX-4000

DRAWING NO: 1081320-03

SHEET: 1

ABERONAUTICAL ENGINEERING

ALBERTA PTY. LTD.

1000 WEST 10TH AVENUE, CALGARY, ALBERTA, CANADA

TELEPHONE: 261-1111

TELETYPE: 261-1111

FAX: 261-1111

MANUFACTURING OPERATIONS

INSPECTION OPERATIONS

QUALITY CONTROL

REVISIONS

APPROVALS


DATE

BY


FOR

<p>GENERAL INFORMATION</p> <p>Part No. 10818220-02 Rev. 1 Date: 10/26/94</p> <p>Quantity: 1 Unit: 10818220-02</p> <p>Material: 10818220-02</p> <p>Manufacturer: 10818220-02</p> <p>Part Name: 10818220-02</p> <p>Part Description: 10818220-02</p> <p>Part Category: 10818220-02</p> <p>Part Status: 10818220-02</p> <p>Part Type: 10818220-02</p> <p>Part Material: 10818220-02</p> <p>Part Finish: 10818220-02</p> <p>Part Weight: 10818220-02</p> <p>Part Volume: 10818220-02</p> <p>Part Length: 10818220-02</p> <p>Part Width: 10818220-02</p> <p>Part Height: 10818220-02</p> <p>Part Diameter: 10818220-02</p> <p>Part Thickness: 10818220-02</p> <p>Part Area: 10818220-02</p> <p>Part Perimeter: 10818220-02</p> <p>Part Surface Area: 10818220-02</p> <p>Part Volume: 10818220-02</p> <p>Part Weight: 10818220-02</p> <p>Part Density: 10818220-02</p> <p>Part Modulus: 10818220-02</p> <p>Part Poisson's Ratio: 10818220-02</p> <p>Part Yield Strength: 10818220-02</p> <p>Part Tensile Strength: 10818220-02</p> <p>Part Elongation: 10818220-02</p> <p>Part Hardness: 10818220-02</p> <p>Part Fatigue Life: 10818220-02</p> <p>Part Creep Rate: 10818220-02</p> <p>Part Thermal Expansion: 10818220-02</p> <p>Part Thermal Conductivity: 10818220-02</p> <p>Part Thermal Capacity: 10818220-02</p> <p>Part Electrical Resistance: 10818220-02</p> <p>Part Electrical Capacitance: 10818220-02</p> <p>Part Electrical Inductance: 10818220-02</p> <p>Part Electrical Dielectric Constant: 10818220-02</p> <p>Part Electrical Loss Tangent: 10818220-02</p> <p>Part Electrical Breakdown Voltage: 10818220-02</p> <p>Part Electrical Surface Resistance: 10818220-02</p> <p>Part Electrical Volume Resistance: 10818220-02</p> <p>Part Electrical Surface Capacitance: 10818220-02</p> <p>Part Electrical Volume Capacitance: 10818220-02</p> <p>Part Electrical Surface Inductance: 10818220-02</p> <p>Part Electrical Volume Inductance: 10818220-02</p> <p>Part Electrical Surface Dielectric Constant: 10818220-02</p> <p>Part Electrical Volume Dielectric Constant: 10818220-02</p> <p>Part Electrical Surface Loss Tangent: 10818220-02</p> <p>Part Electrical Volume Loss Tangent: 10818220-02</p> <p>Part Electrical Surface Breakdown Voltage: 10818220-02</p> <p>Part Electrical Volume Breakdown Voltage: 10818220-02</p> <p>Part Electrical Surface Resistance: 10818220-02</p> <p>Part Electrical Volume Resistance: 10818220-02</p> <p>Part Electrical Surface Capacitance: 10818220-02</p> <p>Part Electrical Volume Capacitance: 10818220-02</p> <p>Part Electrical Surface Inductance: 10818220-02</p> <p>Part Electrical Volume Inductance: 10818220-02</p> <p>Part Electrical Surface Dielectric Constant: 10818220-02</p> <p>Part Electrical Volume Dielectric Constant: 10818220-02</p> <p>Part Electrical Surface Loss Tangent: 10818220-02</p> <p>Part Electrical Volume Loss Tangent: 10818220-02</p> <p>Part Electrical Surface Breakdown Voltage: 10818220-02</p> <p>Part Electrical Volume Breakdown Voltage: 10818220-02</p>	<p style="text-align: center;">DRAWING OF PART NO. 10818220-02-01</p>	<p>SKYFOX AVIATION</p> <p>10818220-02</p> <p>1</p>
<p>MANUFACTURING INFORMATION</p> <p>Part No. 10818220-02 Rev. 1 Date: 10/26/94</p> <p>Quantity: 1 Unit: 10818220-02</p> <p>Material: 10818220-02</p> <p>Manufacturer: 10818220-02</p> <p>Part Name: 10818220-02</p> <p>Part Description: 10818220-02</p> <p>Part Category: 10818220-02</p> <p>Part Status: 10818220-02</p> <p>Part Type: 10818220-02</p> <p>Part Material: 10818220-02</p> <p>Part Finish: 10818220-02</p> <p>Part Weight: 10818220-02</p> <p>Part Volume: 10818220-02</p> <p>Part Length: 10818220-02</p> <p>Part Width: 10818220-02</p> <p>Part Height: 10818220-02</p> <p>Part Diameter: 10818220-02</p> <p>Part Thickness: 10818220-02</p> <p>Part Area: 10818220-02</p> <p>Part Perimeter: 10818220-02</p> <p>Part Surface Area: 10818220-02</p> <p>Part Volume: 10818220-02</p> <p>Part Weight: 10818220-02</p> <p>Part Density: 10818220-02</p> <p>Part Modulus: 10818220-02</p> <p>Part Poisson's Ratio: 10818220-02</p> <p>Part Yield Strength: 10818220-02</p> <p>Part Tensile Strength: 10818220-02</p> <p>Part Elongation: 10818220-02</p> <p>Part Hardness: 10818220-02</p> <p>Part Fatigue Life: 10818220-02</p> <p>Part Creep Rate: 10818220-02</p> <p>Part Thermal Expansion: 10818220-02</p> <p>Part Thermal Conductivity: 10818220-02</p> <p>Part Thermal Capacity: 10818220-02</p> <p>Part Electrical Resistance: 10818220-02</p> <p>Part Electrical Capacitance: 10818220-02</p> <p>Part Electrical Inductance: 10818220-02</p> <p>Part Electrical Dielectric Constant: 10818220-02</p> <p>Part Electrical Loss Tangent: 10818220-02</p> <p>Part Electrical Breakdown Voltage: 10818220-02</p> <p>Part Electrical Surface Resistance: 10818220-02</p> <p>Part Electrical Volume Resistance: 10818220-02</p> <p>Part Electrical Surface Capacitance: 10818220-02</p> <p>Part Electrical Volume Capacitance: 10818220-02</p> <p>Part Electrical Surface Inductance: 10818220-02</p> <p>Part Electrical Volume Inductance: 10818220-02</p> <p>Part Electrical Surface Dielectric Constant: 10818220-02</p> <p>Part Electrical Volume Dielectric Constant: 10818220-02</p> <p>Part Electrical Surface Loss Tangent: 10818220-02</p> <p>Part Electrical Volume Loss Tangent: 10818220-02</p> <p>Part Electrical Surface Breakdown Voltage: 10818220-02</p> <p>Part Electrical Volume Breakdown Voltage: 10818220-02</p>	<p>ASSEMBLY INFORMATION</p> <p>Part No. 10818220-02 Rev. 1 Date: 10/26/94</p> <p>Quantity: 1 Unit: 10818220-02</p> <p>Material: 10818220-02</p> <p>Manufacturer: 10818220-02</p> <p>Part Name: 10818220-02</p> <p>Part Description: 10818220-02</p> <p>Part Category: 10818220-02</p> <p>Part Status: 10818220-02</p> <p>Part Type: 10818220-02</p> <p>Part Material: 10818220-02</p> <p>Part Finish: 10818220-02</p> <p>Part Weight: 10818220-02</p> <p>Part Volume: 10818220-02</p> <p>Part Length: 10818220-02</p> <p>Part Width: 10818220-02</p> <p>Part Height: 10818220-02</p> <p>Part Diameter: 10818220-02</p> <p>Part Thickness: 10818220-02</p> <p>Part Area: 10818220-02</p> <p>Part Perimeter: 10818220-02</p> <p>Part Surface Area: 10818220-02</p> <p>Part Volume: 10818220-02</p> <p>Part Weight: 10818220-02</p> <p>Part Density: 10818220-02</p> <p>Part Modulus: 10818220-02</p> <p>Part Poisson's Ratio: 10818220-02</p> <p>Part Yield Strength: 10818220-02</p> <p>Part Tensile Strength: 10818220-02</p> <p>Part Elongation: 10818220-02</p> <p>Part Hardness: 10818220-02</p> <p>Part Fatigue Life: 10818220-02</p> <p>Part Creep Rate: 10818220-02</p> <p>Part Thermal Expansion: 10818220-02</p> <p>Part Thermal Conductivity: 10818220-02</p> <p>Part Thermal Capacity: 10818220-02</p> <p>Part Electrical Resistance: 10818220-02</p> <p>Part Electrical Capacitance: 10818220-02</p> <p>Part Electrical Inductance: 10818220-02</p> <p>Part Electrical Dielectric Constant: 10818220-02</p> <p>Part Electrical Loss Tangent: 10818220-02</p> <p>Part Electrical Breakdown Voltage: 10818220-02</p> <p>Part Electrical Surface Resistance: 10818220-02</p> <p>Part Electrical Volume Resistance: 10818220-02</p> <p>Part Electrical Surface Capacitance: 10818220-02</p> <p>Part Electrical Volume Capacitance: 10818220-02</p> <p>Part Electrical Surface Inductance: 10818220-02</p> <p>Part Electrical Volume Inductance: 10818220-02</p> <p>Part Electrical Surface Dielectric Constant: 10818220-02</p> <p>Part Electrical Volume Dielectric Constant: 10818220-02</p> <p>Part Electrical Surface Loss Tangent: 10818220-02</p> <p>Part Electrical Volume Loss Tangent: 10818220-02</p> <p>Part Electrical Surface Breakdown Voltage: 10818220-02</p> <p>Part Electrical Volume Breakdown Voltage: 10818220-02</p>	<p>SKYFOX AVIATION</p> <p>10818220-02</p> <p>1</p>

Handwritten signature and date:
 3-15-94



NO.	DESCRIPTION	QTY.	UNIT
1	SKYFOX AVIATION		
2	SKYFOX AVIATION		
3	SKYFOX AVIATION		
4	SKYFOX AVIATION		
5	SKYFOX AVIATION		



KEY ON ORIGINAL TIME ONLY

GENERAL NOTES:
 1. THIS DRAWING IS THE PROPERTY OF SKYFOX AVIATION AND IS NOT TO BE REPRODUCED OR COPIED IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF SKYFOX AVIATION.
 2. ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED.
 3. ALL DIMENSIONS ARE TO CENTER UNLESS OTHERWISE SPECIFIED.
 4. ALL DIMENSIONS ARE TO BE TAKEN FROM THE CENTER OF GRAVITY UNLESS OTHERWISE SPECIFIED.
 5. ALL DIMENSIONS ARE TO BE TAKEN FROM THE CENTER OF GRAVITY UNLESS OTHERWISE SPECIFIED.

NO.	DESCRIPTION	QTY.	UNIT
1	SKYFOX AVIATION		
2	SKYFOX AVIATION		
3	SKYFOX AVIATION		
4	SKYFOX AVIATION		
5	SKYFOX AVIATION		

SKYFOX AVIATION

SKYFOX AVIATION
 1088 10220-01

A. W. Mulvaney
 3-2-59

WING GEAR MOUNTING

WING GEAR MOUNTING
 SEE DRAWING FOR DIMENSIONS
 ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED

NO.	DESCRIPTION	QTY.	UNIT
1	SKYFOX AVIATION		
2	SKYFOX AVIATION		
3	SKYFOX AVIATION		
4	SKYFOX AVIATION		
5	SKYFOX AVIATION		

MANUFACTURING ORDERING
 ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED
 ALL DIMENSIONS ARE TO CENTER UNLESS OTHERWISE SPECIFIED
 ALL DIMENSIONS ARE TO BE TAKEN FROM THE CENTER OF GRAVITY UNLESS OTHERWISE SPECIFIED


SKYFOX AVIATION
 1088 10220-01

THIS DRAWING IS REPRODUCED AND MUST NOT BE COPIED WITHOUT CONSENT OF SHIPFIX ASSOCIATION

DIMENSIONS IN MILLIMETRES


BE NOT SCALE PROJECTION

APPROVED pursuant to a direction given by regulation 3 of The 4th Navigation Regulations.
 for and on behalf of
G. W. WHITNEY PTY. LTD.
L. W. Whitney
 Design signatory
 Date 1-6-95



NOTE: R/A OPPOSITE

MAT: AS PER DRAWING NO. NWS-1



FIBREGLASS LAYOUT + SPEC SAME AS WOSE SPAT
 AFTER INSTALLATION CHECK THAT TYRE, WHEEL AND BRAKE DISL CLEAR SPAT BY AT LEAST 1/2".
 C.W.M.


SCALE	1:1	DATE	1-6-95
REVISION		DATE	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10	10	10	10
11	11	11	11
12	12	12	12
13	13	13	13
14	14	14	14
15	15	15	15
16	16	16	16
17	17	17	17
18	18	18	18
19	19	19	19
20	20	20	20
21	21	21	21
22	22	22	22
23	23	23	23
24	24	24	24
25	25	25	25
26	26	26	26
27	27	27	27
28	28	28	28
29	29	29	29
30	30	30	30
31	31	31	31
32	32	32	32
33	33	33	33
34	34	34	34
35	35	35	35
36	36	36	36
37	37	37	37
38	38	38	38
39	39	39	39
40	40	40	40
41	41	41	41
42	42	42	42
43	43	43	43
44	44	44	44
45	45	45	45
46	46	46	46
47	47	47	47
48	48	48	48
49	49	49	49
50	50	50	50
51	51	51	51
52	52	52	52
53	53	53	53
54	54	54	54
55	55	55	55
56	56	56	56
57	57	57	57
58	58	58	58
59	59	59	59
60	60	60	60
61	61	61	61
62	62	62	62
63	63	63	63
64	64	64	64
65	65	65	65
66	66	66	66
67	67	67	67
68	68	68	68
69	69	69	69
70	70	70	70
71	71	71	71
72	72	72	72
73	73	73	73
74	74	74	74
75	75	75	75
76	76	76	76
77	77	77	77
78	78	78	78
79	79	79	79
80	80	80	80
81	81	81	81
82	82	82	82
83	83	83	83
84	84	84	84
85	85	85	85
86	86	86	86
87	87	87	87
88	88	88	88
89	89	89	89
90	90	90	90
91	91	91	91
92	92	92	92
93	93	93	93
94	94	94	94
95	95	95	95
96	96	96	96
97	97	97	97
98	98	98	98
99	99	99	99
100	100	100	100

THIS DRAWING IS REPARABLE AND MUST NOT BE COPIED | DIMENSIONS IN MILLIMETRES | DO NOT SCALE | PROJECTION

CHANGE 2 - ADDITION OF FIN

APPROVED PURCHASE TO A DRAWING GIVEN
BY THE NAME OF THE AIR NAVIGATION

DESIGNED BY
C. M. WILKINSON LTD
C. M. Wilkinson
Design Sign
4/7/75



MAT: RESIN UNWAXED POLYESTER
SR 250

GLASS CLOTH CHOPPED STRAND
450 grams/m²

2ND LAYER ON EDGES
250 grams/m²

WEIGHT : 1.0 KG ± 100 grams

FIBREGLASS WORK TO SKYFOX SPEC 24
MANUFACTURE ON SKYFOX HOLDS WS1/WS2/WS3/W

AFTER INSTALLATION ON AIRCRAFT CHECK
THAT WHEEL CLEARS SPAT BY AT LEAST 1/2"
ALL ROUND (BY WHEEL - WHEEL TYRE IS MEANT)

SCALE	2	6/7/75
DATE		
ISSUE NO		
ISSUE DATE		
ISSUE BY		
ISSUED FOR	NOSE WHEEL SPAT	
APPROVED BY		
DATE		

THIS DRAWING IS COPYRIGHT AND MUST NOT BE COPIED WITHOUT CONSENT OF SKYWAY AVIATION


DIMENSIONS IN MILLIMETRES

DWG NOT SCALE

PROJECTION

RIVETS USED:
 CHERRY -
 A/D/S/L: 089 1661 - 0414
 WASHERS: 1/2" x 3/8" x 21.6
 ADHESIVE: 2216 B/A
 EPOXY

APPROVED PURSUANT TO
 REGULATION 35
 OF THE CIVIL AVIATION REGULATIONS
 SIGNED *[Signature]*
 (ALAN KERR)
 DATE 26/2/97
 JOB NUMBER REFERENCE



NOTE: REFER TO SKYWAY PLACES SPEC S43 FOR BONDING PROCEDURE.

ITEM	PART NO	DESCRIPTION	QTY
1	11-05	SEAT	1
2	11-05-2	SEAT CUSHION BASKET	2
3	91-05-3	SEAT KNUCKLE BASKET	2

SCALE 1:1

ISS DATE 1-11-96

DRAWING NO 91-05-1

SHEET

LIMITS


REVISION

DESCRIPTION

DATE

SEAT ASSY.

WITHOUT CONSENT OF SKYTEX AVIATION DIMENSIONS IN MILLIMETERS DO NOT SCALE PROJECTION




APPROVED PURSUANT TO
REGULATION 35
OF THE CIVIL AVIATION REGULATIONS
SIGNED (ALAN P. KERR)
DATE 26/2/93
JOB NUMBER REFERENCE

SCALE	2	135/5/92
DATE	1	18.12.92
ISSUE	1	18.12.92
DRAWING NO.	VI-27	

SKYTEX AVIATION
K-CAD DESIGN F.C. MILLS
DRAWN BY
APPROVED BY
DATE
JURY STRUT ASSEMBLY

THIS DRAWING IS UNLESS OTHERWISE SPECIFIED IN MILLIMETRES DO NOT SCALE PROJECTION

WASHOUT DETAIL A



APPROVED PURSUANT TO
 REGULATION 25 OF THE CIVIL AVIATION REGULATIONS
 SIGNED [Signature] (ALAN P. KERR)
 DATE 26/2/93
 JOB NUMBER REFERENCE

NOT TO SCALE

DATE 10-12-92

WASHOUT DETAIL A

CREATED BY [Name]

PROJECT [Name]

JOB NO. [Number]


SCALE [Scale]

DATE [Date]

JOB NO. [Number]

SCALE [Scale]

DATE [Date]



NOTES

- 1 Power wiring & grounds are 22 Gauge
- 2 All other wiring is 24 Gauge.
- 3 Antenna Co-ax is RG58 or higher spec
- 4 All wiring to G.A.O. 108.32 requirements
- 5 Wiring Spec M 27500 minimum
- 6 Encoder installation connections as per Trans-Cal Industries installation manual

APPROVED
 PURSUANT TO CAM 35/ CAM 138
[Signature]
 AUTHORIZED PERSONNEL
 DATE 5 JAN 96
 I.A. NO. 108813B
 JOB No. 4/21/96

SKY FOX AVIATION		DRAWING NUMBER
KT 76 A / SSD 120 Installation drawing		SKY - 76
ATC Transponder Altitude Encoder		
Issue OPIE Dated 1 January 1995		Ocean Turbo CVO Dover MA